

PRODUCED BY THE OPERATIONS DIRECTORATE OF ENERGY NETWORKS ASSOCIATION

1



Technical Specification 41-24

Issue <1> 2016

Guidelines for the Design, Installation, Testing and  
Maintenance of Main Earthing Systems in  
Substations

[www.energynetworks.org](http://www.energynetworks.org)

© <year of publication> **Energy Networks Association**

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of Energy Networks Association. Specific enquiries concerning this document should be addressed to:

**Operations Directorate  
Energy Networks Association  
6th Floor, Dean Bradley House  
52 Horseferry Rd  
London  
SW1P 2AF**

This document has been prepared for use by members of the Energy Networks Association to take account of the conditions which apply to them. Advice should be taken from an appropriately qualified engineer on the suitability of this document for any other purpose.

<Insert publication history here, e.g. "First published, December, 2011">

#### **Amendments since publication**

<b>Issue</b>	<b>Date</b>	<b>Amendment</b>
Issue <1>	<April, 2016>	Draft updated in line with comments from previous meeting. References to S34 highlighted for discussion at April Meeting. Some comments included in body for guidance. Other changes accepted and tracked changes removed [RW].
	June 2016	Minor changes for review at June meeting

1 **Contents**

2	Foreword .....	9
3	1 Scope.....	10
4	2 Normative references .....	10
5	3 Definitions .....	11
6	4 Fundamental Requirements .....	15
7	4.1 Function of an earthing system.....	15
8	4.2 Typical features of an earthing system.....	15
9	4.3 The effects of substation potential rise on persons.....	16
10	4.3.1 Touch potential .....	17
11	4.3.2 Step potential .....	17
12	4.3.3 Transfer potential.....	17
13	4.3.4 General .....	17
14	4.3.5 Limits for LV networks .....	18
15	4.3.6 Limits for Other systems .....	18
16	4.3.7 Limits for Telecommunications Equipment (HOT/COLD sites).....	18
17	4.4 Safety criteria .....	18
18	4.4.1 General 'permissible' design limits .....	18
19	4.4.2 Effect of electricity on animals .....	22
20	4.4.3 Injury or shock to persons and animals outside the installation .....	22
21	4.5 Electrical Requirements .....	23
22	4.5.1 Method of neutral earthing.....	23
23	4.5.2 Fault Current .....	23
24	4.5.3 Thermal effects - general.....	24
25	5 Design.....	26
26	5.1 General approach (flowchart) .....	26
27	5.2 Design Considerations .....	27
28	5.2.1 Limiting values for EPR .....	27
29	5.2.2 Touch and Step voltages .....	27
30	5.2.3 Factors to include in calculation of EPR and Safety Voltages .....	27
31	5.2.4 Transfer Potential.....	27
32	5.3 Preliminary Arrangement and Layout .....	28
33	5.4 Design Guidelines .....	28
34	5.4.1 Outdoor Substations .....	28
35	5.4.2 Indoor Substations .....	29
36	5.4.3 Shared Sites.....	30
37	5.4.4 Distribution (or 'Secondary') Substations .....	30
38	5.4.5 Metallic Fences .....	30
39	5.4.6 Provision of Maintenance/Test facilities .....	30
40	5.5 Design data .....	31
41	5.5.1 Soil Resistivity.....	31
42	5.5.2 Fault currents and durations for EPR and safety voltage calculations .....	32
43	5.5.3 Fault currents and clearance times for conductor size calculations .....	33

44	5.5.4	Fault currents and clearance times for electrode size calculations .....	34
45	5.6	Conductor and Electrode Ratings.....	37
46	5.6.1	Earthing Conductors .....	37
47	5.6.2	Electrode Surface Current Density Ratings .....	43
48	5.7	Design Assessment .....	45
49	5.7.1	Assessment Procedure.....	45
50	5.7.2	Methods to improve design (Mitigation measures) .....	46
51	5.7.2.1	EPR reduction.....	46
52	5.7.2.2	Touch Voltage reduction.....	47
53	5.8	Risk Assessment.....	47
54	ii	Construction of Earthing Systems.....	49
55	6.1	General Design Philosophy .....	49
56	6.1.1	Materials.....	49
57	6.1.2	Avoiding Theft.....	49
58	6.2	Jointing Conductors and Equipment Connections .....	50
59	6.2.1	General .....	50
60	6.2.2	Transition washers.....	50
61	6.2.3	Copper to Copper Connections.....	51
62	6.2.4	Copper to Earth Rods .....	51
63	6.2.5	Electrode Test Points.....	51
64	6.2.6	Copper to Equipment (Steel, or Galvanised Steel) Connections.....	51
65	6.2.7	Aluminium to Equipment Connections .....	51
66	6.2.8	Aluminium to Aluminium Connections.....	52
67	6.2.9	Aluminium to Copper Connections.....	52
68	6.2.10	Earthing Connections to Aluminium Structures.....	53
69	6.2.11	Steel Structures .....	53
70	6.3	Above Ground Earthing Installations .....	54
71	6.3.1	Fixing Above Ground Conductor to Supports .....	54
72	6.3.2	Prevention of Corrosion of Above Ground Conductors .....	54
73	6.3.3	Metal Trench Covers .....	54
74	6.3.4	Loops for Portable Earth Connections .....	54
75	6.4	Below Ground Earthing Installations .....	55
76	6.4.1	Installation of Buried Electrode within a Substation.....	55
77	6.4.2	Positioning of Buried Electrode .....	55
78	6.4.3	Other Earth Electrodes .....	56
79	6.4.3.1	Earth Rods .....	56
80	6.4.3.2	Earth Plates .....	56
81	6.5	Use of Structural Earths including Steel Piles and Rebar.....	57
82	6.5.1	Sheet Steel Piles.....	57
83	6.5.2	Horizontal Steel Reinforced Foundations.....	57
84	6.5.3	Vertical Steel Reinforced Concrete Columns.....	58
85	6.6	Metallic Fences .....	58
86	6.6.1	Independently Earthed Fences.....	58

87	6.6.2 Segregation between independently earthed fence and earthing	
88	system .....	58
89	6.6.3 Fences Bonded to the Substation Earthing System .....	60
90	6.6.4 Third Party Metallic Fences .....	61
91	6.6.5 Insulated Fence Sections .....	61
92	6.6.6 Chain Link Fencing (Galvanised or Plastic Coated) .....	61
93	6.6.7 Coated Fence Panels .....	62
94	6.6.8 Electric Security Fences .....	62
95	6.6.9 Anti-climbing Precautions .....	62
96	6.7 Specific Items .....	62
97	6.7.1 Water Services to Substations .....	62
98	6.7.2 Non-current carrying metalwork .....	62
99	6.7.3 Items normally bonded to the main earth grid:.....	63
100	6.7.4 Items NOT normally bonded to the Earth Grid.....	63
101	6.7.5 Non-standard bonding arrangements.....	63
102	6.8 Overhead Line Terminations.....	64
103	6.8.1 Tower Terminations Adjacent to Substation .....	64
104	6.8.2 Steel Tower Termination with Cable Sealing Ends.....	64
105	6.8.3 Terminal Poles with Stays Adjacent to Substation Fence .....	64
106	6.8.4 Down drop Anchorage Arrangement with Arcing Horns .....	64
107	6.8.5 Loss of Aerial Earth Wires .....	65
108	6.9 HV Cable Metallic Sheath / Armour Earthing .....	65
109	6.9.1 Insulated (Polymeric) Sheath Cables .....	65
110	6.9.2 Cables Entering Substations .....	66
111	6.9.3 Cables Within Substations.....	66
112	6.9.4 Outdoor Cable Sealing-Ends.....	66
113	6.9.5 Use of Disconnected, Non-Insulated Sheath/Armour Cables as an	
114	Electrode.....	66
115	6.10 Light-current Equipment Associated with External Cabling .....	67
116	6.11 Metal Clad and Gas Insulated (GIS) Substations.....	67
117	6.11.1 Metal Clad Substations.....	67
118	6.11.2 Gas Insulated Switchgear (GIS).....	67
119	6.12 Fault Throwing Switches, Earth Switches and Disconnectors .....	68
120	6.12.1 Background.....	68
121	6.12.2 Fault Throwing Switches (Phase - Earth).....	69
122	6.12.3 Earth Switches .....	69
123	6.12.4 Isolators.....	69
124	6.13 Operating Handles, Mechanisms and Control Kiosks .....	69
125	6.13.1 Background.....	69
126	6.13.2 Earth Mats (Stance Earths) .....	69
127	6.13.3 Connection of Handles to the Earth Grid and Stance Earths .....	69
128	6.14 Surge Arrestors and CVTs.....	70
129	7 Measurements .....	71
130	7.1 General.....	71

131	7.2	Safety .....	71
132	7.3	Instrumentation and Equipment .....	71
133	7.4	Soil Resistivity Measurements .....	72
134	7.4.1	Objective .....	72
135	7.4.2	Wenner Method .....	72
136	7.4.3	Interpretation of Results.....	72
137	7.4.4	Sources of Error.....	72
138	7.4.5	Driven Rod Method.....	73
139	7.5	Earth Resistance/Impedance Measurements .....	73
140	7.5.1	Objective .....	73
141	7.5.2	Method .....	74
142	7.5.3	Interpretation of Results.....	74
143	7.5.4	Sources of Error.....	75
144	7.6	Comparative Method of Measuring Earth Resistance.....	76
145	7.6.1	Objective .....	76
146	7.6.2	Method .....	76
147	7.6.3	Interpretation of Results.....	77
148	7.6.4	Sources of Error.....	77
149	7.7	Earth Connection Resistance Measurements (Equipment Bonding Tests).....	78
150	7.7.1	Objective .....	78
151	7.7.2	Method .....	78
152	7.7.3	Interpretation of Results.....	78
153	7.8	Earth Conductor Joint Resistance Measurements .....	79
154	7.8.1	Objective .....	79
155	7.8.2	Method .....	79
156	7.8.3	Interpretation of Results.....	79
157	7.9	Earth Potential Measurements .....	79
158	7.9.1	Objective .....	79
159	7.9.2	Method .....	80
160	7.9.3	Interpretation of Results.....	80
161	7.10	Earth Electrode Separation Test.....	80
162	7.10.1	Objective .....	80
163	7.10.2	Method .....	80
164	7.10.3	Interpretation of Results.....	80
165	7.11	Buried Earth Electrode Location .....	81
166	7.11.1	Objective .....	81
167	7.11.2	Method .....	81
168	<b>B</b>	<b>MAINTENANCE.....</b>	<b>82</b>
169	8.1	Introduction.....	82
170	8.1.1	Inspection.....	82
171	8.1.2	Maintenance and Repairs.....	82
172	8.2	Types of Inspection .....	83
173	8.2.1	Introduction .....	83
174	8.2.2	Frequent Visual Inspection .....	83

175	8.2.3	Infrequent Detailed Visual Inspection .....	83
176	8.2.4	Detailed Visual Inspection, Testing and Analysis .....	84
177	8.2.4.1	Testing .....	84
178	8.2.4.2	Selected Excavation and Examination of Buried Earth	
179		Electrode .....	85
180	8.2.4.3	Analysis and Recording of Test Results .....	85
181	8.3	Maintenance and Repair of Earthing Systems .....	86
182	8.4	Procedure for the Remaking Defective Joints or Repairing Conductor Breaks	
183		.....	87
184	8.4.1	Introduction .....	87
185	8.4.2	Joint Repair Methods .....	87
186	8.4.3	Flexible Braids .....	87
187	9	Ground Mounted Distribution Substation Earthing .....	88
188	9.1	Introduction.....	88
189	9.2	Relocation of Pole Mounted Equipment to Ground Level .....	88
190	9.3	General design requirements.....	88
191	9.3.1	Design Data Requirements.....	89
192	9.3.2	Conductor and electrode sizing [New].....	89
193	9.3.3	Target resistance .....	89
194	9.3.4	EPR design limit.....	90
195	9.3.5	Calculation of EPR.....	90
196	9.3.5.1	Factors to consider: .....	90
197	9.3.5.2	Transfer Potential from source .....	91
198	9.3.6	Step/Touch Potentials at the Substation .....	91
199	9.3.7	Simplified approach .....	91
200	9.4	Network and other contributions .....	92
201	9.4.1	Additional Electrode .....	92
202	9.4.2	Parallel contributions from interconnected HV and LV networks.....	92
203	9.4.3	Ascertaining Network Contribution .....	93
204	9.4.4	Global Earthing Systems .....	93
205	9.5	Transfer Potential onto LV network .....	94
206	9.5.1	General .....	94
207	9.5.2	Touch voltage on LV system as a result of HV faults .....	94
208	9.5.3	Stress Voltage.....	94
209	9.6	Combined HV and LV earthing .....	95
210	9.7	Segregated HV and LV earthing.....	95
211	9.7.1	Separation Distance .....	95
212	9.7.2	Transfer voltage to third parties.....	96
213	9.7.3	Further Considerations .....	96
214	9.7.4	Multiple LV electrodes on segregated systems.....	97
215	9.8	Situations where HV/LV systems cannot be segregated .....	97
216	9.9	Practical Considerations .....	97
217	9.10	LV installations near High EPR sites .....	98
218	9.11	Supplies to/from High EPR (HPR) sites .....	98

219	9.11.1 Special Arrangements .....	99
220	10 Pole Mounted Substation and Equipment Earthing .....	100
221	10.1 General Comments & Assumptions.....	100
222	10.2 Pole Mounted Transformers .....	100
223	10.3 Electrode Configuration for Pole Mounted Equipment .....	100
224	10.4 HV Earth Electrode Value .....	101
225	10.5 Electrode Arrangement Selection Method.....	101
226	10.6 Earthed Operating Mechanisms Accessible From Ground Level .....	102
227	10.7 Air Break Switch Disconnecter (ABSD) with an isolated operating mechanism	
228	.....	106
229	10.8 Surge Arresters .....	108
230	10.9 Cable Terminations .....	108
231	10.10 Operations at Earthed Equipment Locations.....	109
232	10.11 Installation .....	109
233	10.12 Inspection & Maintenance of Earth Installations .....	110
234	10.12.1 Items to Inspect.....	110
235	10.12.2 Items to Examine .....	110
236	10.12.3 Items to Test .....	110
237	11 Case studies / examples .....	112
238		
239		
240		

241 **Foreword**

242 This Technical Specification (TS) is published by the Energy Networks Association (ENA) and  
243 comes into effect from July, 2016>. It has been prepared under the authority of the ENA  
244 Engineering Policy and Standards Manager and has been approved for publication by the ENA  
245 Electricity Networks and Futures Group (ENFG). The approved abbreviated title of this  
246 engineering document is "ENA TS 41-24".

247 This Specification is to be used in conjunction with Engineering Recommendation S34 (2015).  
248 In this document account has been taken of:

- 249 (i) UK Adoption of IEC 50522:2010 (Earthing of Power Installations Exceeding 1kV  
250 a.c.), in particular with reference to acceptable touch/step voltage limits derived  
251 from IEC/TS 60479-1:2005 (Effects of current on human beings and livestock).
- 252 (ii) changes to earthing practice as outlined in ESQC (Electrical Safety, Quality, and  
253 Continuity) Regulations, 2002, in particular with regard to smaller 'distribution' or  
254 'secondary' substations. These are described in Section 10 and 11 of this  
255 specification.
- 256 (iii) the requirements for Protective Multiple Earthing systems as outlined in  
257 Engineering Recommendation G12. (The relevant items concerning substation  
258 earthing in EREC G12/4 have now been transferred to this document);
- 259 (iv) the increasing use of plastic sheathed cables;
- 260 (v) the differing requirements of earthing systems at various voltages and for differing  
261 types of substation installation.

262

263 **1 Scope**

264 This Specification applies to fixed earthing systems for all electricity supply systems and  
265 equipment earthing within EHV, HV and HV/LV substations.

266 It also applies to:

- 267 (i) terminal towers adjacent to substations and cable sealing end compounds;  
268 (ii) pole mounted transformer or air-break switch disconnecter installations;  
269 (iii) pole mounted reclosers with ground level control.

270 It does not apply to earthing systems for quarries and railway supply substations.

271 **2 Normative references**

272 The following referenced documents, in whole or part, are indispensable for the application of  
273 this document. For dated references, only the edition cited applies. For undated references,  
274 the latest edition of the referenced document (including any amendments) applies.

275 BS 7430:2011+2015 (Code of Practice for Protective Earthing of Electrical Installations)

276 ESQC (Electrical Safety, Quality, and Continuity) Regulations, 2002 (As amended)

277 IEC 50522:2010 (Earthing of Power Installations Exceeding 1kV a.c.)

278 IEC/TS 60479-1:2005 (Effects of current on human beings and livestock). (Part 1 – General  
279 Aspects)

280 IEC/TR 60479- 3 – (Effects of currents passing through the body of livestock)

281 ITU-T: Directives concerning the protection of telecommunication lines against harmful effects  
282 from electric power and electrified railway lines: Volume VI: Danger, damage and disturbance  
283 (2008)

284 CIGRE Working Group 23.10 Paper 151 (044) (Dec. 1993): Earthing of GIS – An Application  
285 Guide

286 Other references as included in this document: ER 134, S34, BS EN 62305, IEEE 80, IEEE  
287 81, BS EN 62561-2

288

289

290 **3 Definitions**

APPROVED EQUIPMENT	Equipment Approved in operational policy document for use in the appropriate circumstances.
AUXILIARY ELECTRODE	See SUPPLEMENTARY ELECTRODE
BACKUP PROTECTION	Protection set to operate following failure or slow operation of primary protection – see NORMAL PROTECTION below. For design purposes the backup protection clearance time may be taken as a fixed (worst case) clearance time appropriate to the network operator's custom and practice.
BONDING CONDUCTOR	A protective conductor providing equipotential bonding.
CROSS COUNTRY FAULT	Two or more phase-to-earth faults at separate locations and on different phases. Effectively this creates a phase-phase fault with current flowing through earth electrode and/or bonding conductors. The result can be an increased 'EARTH FAULT CURRENT' for design purposes at some locations. CROSS COUNTRY FAULTS are usually considered only if a first phase-earth fault does not automatically clear within a short period, or if significant phase voltage displacement (neutral voltage displacement) could occur. If an accurate figure is not available, a value of 85% of the double phase-to-earth fault current may be assumed.
EARTH	The conductive mass of earth whose electric potential at any point is conventionally taken as zero.
EARTH ELECTRODE	A conductor or group of conductors in intimate contact with, and providing an electrical connection to, earth.
EARTH ELECTRODE POTENTIAL	The difference in potential between the 'EARTH ELECTRODE' and a remote 'EARTH'.
EARTH ELECTRODE RESISTANCE	The resistance of an 'EARTH ELECTRODE' with respect to 'EARTH'.
EARTH ELECTRODE RESISTANCE AREA	That area of ground over which the resistance of an 'EARTH ELECTRODE' effectively exists. It is the same area of ground over which the 'EARTH ELECTRODE POTENTIAL' exists.
EARTH FAULT	A fault causing current to flow in one or more earth-return paths. Typically a single phase to earth fault, but this term may also be used to describe two phase and three phase faults involving earth.
EARTH FAULT CURRENT	The worst case steady state (symmetrical) RMS current to earth, i.e. that returning to the system neutral(s) resulting from a single phase to earth fault. This is normally calculated (initially) for the 'zero ohm' fault condition. Depending on the circumstances, the value can be modified by including 'earth resistance'. Not to be confused with 'GROUND RETURN'

current which relates to the proportion of current returning via soil.

In some situations, particularly 'CROSS COUNTRY FAULTS', a different single phase to earth fault at two separate locations can result in 'EARTH FAULT CURRENT' (as seen at the fault-point) that does not return to the system neutrals yet should still be considered at the design stage.

EARTH POTENTIAL RISE (EPR) OR GROUND POTENTIAL	The difference in potential which may exist between a point on the ground and a remote 'EARTH'. Formerly known as RoEP (Rise of Earth Potential). The term 'GPR' (Ground Potential Rise) is an alternative form, not used in this standard.
EARTHING CONDUCTOR OR EARTHING CONNECTION	A protective conductor connecting a main earth terminal of an installation to an 'EARTH ELECTRODE' or to other means of earthing.
EARTH MAT	Definition requested by WPD. Group to decide form of words, e.g.: A buried or surface laid mesh or other electrode, usually installed at the operator position close to switchgear or other plant, intended to control or limit hand-feet TOUCH POTENTIAL.
EARTHING SYSTEM	The complete interconnected assembly of 'EARTHING CONDUCTORS' and 'EARTH ELECTRODES' (including cables with uninsulated sheaths).
EHV	Extra High Voltage, typically used in UK to describe a voltage of 33kV or higher.
ELECTRODE CURRENT	The current entering the ground through the substation's electrode system under earth fault conditions. This term is generally used in the context of electrode sizing calculations and is slightly different to Ground Return Current since the ground return current may flow through alternative paths such as auxiliary electrodes etc. For design purposes the electrode current may be taken as the worst case current flowing into a substation's electrode system under foreseeable fault conditions including, where relevant, the loss of metallic return paths and/or cross country faults.
GLOBAL EARTHING SYSTEM	An earthing system of sufficiently dense interconnection such that all items are bonded together and rise in voltage together under fault conditions. No 'true earth' reference exists and therefore safety voltages are limited.
GROUND RETURN CURRENT	<p>The proportion of EARTH FAULT CURRENT returning via soil (as opposed to metallic paths such as cable sheaths or overhead earth wires)</p> <p>If there is a metallic return path for EARTH FAULT CURRENT (e.g. a cable screen or overhead earth wire), this will typically convey a large proportion of the earth fault current. The remainder will return through soil to the system neutral(s).</p>

Reduction factors for neutral current flows (multiple earthed systems) and sheath/earth wire return currents may be applied to calculate the GROUND RETURN CURRENT. The GROUND RETURN CURRENT is used in EPR calculations as it flows through the resistance formed by a substation's overall earth electrode system (and that of the wider network) and thus contributes to voltage rise of that system. Annex I of BS EN 50522 describes some methods for calculating this component. Further guidance is given in ENA **EREC S34**.

GROUND VOLTAGE PROFILE

The radial ground surface potential around an 'EARTH ELECTRODE' referenced with respect to remote 'EARTH'.

HOT / COLD SITE

A HOT site is defined as one which exceeds ITU limits for EPR, typically these thresholds are 650 V (for reliable fault clearance time  $\leq 0.2$  seconds), or 430 V otherwise. The requirements derive from telecommunication standards relating to voltage withstand on equipment.

Note: These thresholds have formerly been applied as design limits for EPR in some areas. The terms HOT and COLD were often applied as a convenience (on the basis that many COLD sites do achieve safe step/touch limits) but do not relate directly to safe design limits for touch and step voltages in substations. Refer to 'HIGH EPR' below.

HIGH EPR / HPR

High Potential Rise resulting from an earth fault. An EPR greater than twice the permissible touch voltage limit (e.g. 466 V for 1 second faults on soil or outdoor concrete).

HV (High Voltage)

A voltage greater than 1kV and less than 33kV. Typically used to describe 6.6kV, 11kV and 20kV systems in UK.

MES (Main Earthing System)

The interconnected arrangement of earth electrode and bonds to main items of plant in a substation.

NORMAL PROTECTION OPERATION

Clearance of a fault under normal (usual) circumstances. The normal clearance time will include relay operating time and mechanical circuit breaker delays for all foreseeable faults, and may be calculated for design purposes. Alternatively a network operator may work to the 'worst case' protection clearance time applicable to the network in a given area. This time assumes that faults will be cleared by normal upstream protection and does not allow for e.g. stuck circuit breakers or other protection failures/delays. Certain parts of an earthing design should consider slower 'BACKUP PROTECTION' operation (see above) which allows for a failure of normal protection.

NETWORK OPERATOR

Owner or operator of assets. Includes DNO (Distribution Network Operator), IDNO (Independent or 'Inset' DNO) and Transmission Network Operator (TNO) as defined in the Distribution Code (DCode) or System Operator Transmission Code (STC) as appropriate.

SUPPLEMENTARY ELECTRODE	Electrode that improves the performance of an earthing system, and may increase resilience, but is not critical to the safety of the 'as designed' system.
STEP POTENTIAL	See Section 4.3.2 for definition.
STRESS VOLTAGE	Voltage difference between two segregated earthing systems, which may appear across insulators/bushings etc. or cable insulation.
TOUCH POTENTIAL	See Section 4.3.1 for definition.
TRANSFER POTENTIAL	See Section 4.3.3 for definition.
WITHSTAND VOLTAGE	The maximum STRESS VOLTAGE that can be safely permitted between items of plant or across insulation without risk of insulation breakdown or failure.

292 **4 Fundamental Requirements**

293 **4.1 Function of an earthing system**

294 Every substation shall be provided with an earthing installation designed so that in both normal  
295 and abnormal conditions there is no danger to persons arising from earth potential in any place  
296 to which they have legitimate access. The installation shall be able to pass the maximum  
297 current from any fault point back to the system neutral whilst maintaining step, touch, and  
298 transfer potentials within permissible limits (defined in Section 4.3) based on normal\* protection  
299 relay and circuit breaker operating times. In exceptional circumstances where the above  
300 parameters may not be economically or practically kept below permissible limits a probabilistic  
301 risk assessment may be carried out. Where this shows the risk to be below accepted ALARP  
302 levels the level of earth potential rise mitigation may be reduced (refer to Section 5.8).

303 The earthing system shall be designed to avoid damage to equipment due to excessive  
304 potential rise, potential differences within the earthing system (stress voltages), and due to  
305 excessive currents flowing in auxiliary paths not intended for carrying fault current.

306 The design shall be such that the passage of fault current does not result in any thermal or  
307 mechanical damage [for backup protection clearance times] or damage to insulation of  
308 connected apparatus. It shall be such that protective gear, including surge protection, is able  
309 to operate correctly.

310 Any exposed normally un-energised metalwork within a substation, which may be made live  
311 by consequence of a system insulation failure can present a safety hazard to personnel. It is  
312 a function of the station earthing system to eliminate such hazards by solidly bonding together  
313 all such metalwork and to bond this to the substation earth electrode system in contact with  
314 the general mass of earth. Dangerous potential differences between points legitimately  
315 accessible to personnel shall be eliminated by appropriate design.

316 The earthing system shall maintain its integrity for the expected installation lifetime with due  
317 allowance for corrosion and mechanical constraints.

318 The earthing system performance shall contribute to ensuring electromagnetic compatibility  
319 (EMC) among electrical and electronic apparatus of the high voltage system in accordance  
320 with IEC/TS 61000-5-2.

321 **4.2 Typical features of an earthing system**

322 The earthing installation requirements are met principally by providing in each substation an  
323 arrangement of electrodes and earthing conductors which act as an earthing busbar. This is  
324 called the 'main earth grid' or 'main earth system' (MES) and the following are connected to it:

- 325 (i) all equipment housing or supporting high voltage conductors within the substation  
326 such as transformer and circuit breaker tanks, arcing rings and horns and metal  
327 bases of insulators;
- 328 (ii) neutral connection of windings of transformers required for high voltage system  
329 earthing. For high voltage systems the connections may be via earthing resistors  
330 or other current limiting devices, as described in Section 4.4. (The neutral earthing  
331 of low-voltage systems is separately considered in Section 9);

---

\* See 'Definitions' in Section 3

- 332 (iii) earth electrodes, additional to the main earth grid which may itself function as an  
333 earth electrode;
- 334 (iv) earth connections from overhead line terminal supports and the sheaths / screens  
335 of underground cables;
- 336 (v) earth mats, provided as a safety measure, to reduce the potential difference  
337 between points on the area of ground adjacent to manually operated plant and the  
338 metalwork including handles of that plant (but see also 10.6);
- 339 (vi) 'Grading Electrodes' (intended to reduce touch voltages on equipment), which as a  
340 minimum consist of a horizontal ring electrode around all items of earthed plant and  
341 the equipment and bonded to it. This often must be supplemented by additional  
342 grading electrodes inside the ring;
- 343 (vii) 'High Frequency Electrodes', conductors and electrodes specifically configured to  
344 reduce the impedance to lightning, switching and other surges at applicable  
345 locations, e.g. surge arresters, CVTs and GIS bus interfaces;
- 346 (viii) all other exposed and normally un-energised metalwork wholly inside the  
347 substation perimeter fence, e.g. panels (excluding floating fence panels), kiosks,  
348 lighting masts, oil tanks, etc. Conductive parts not liable to introduce a potential  
349 need not be bonded (e.g. metal window frames in brick walls). Items such as  
350 fences, cables and water pipes which are not wholly inside the substation are  
351 separately considered in Sections 6.6 and 6.7.
- 352 (ix) Fences may be bonded to the main earth system in some situations – refer to  
353 Section 6.6.

354 Substation surface materials, for example stone chippings which have a high value of  
355 resistivity, are chosen to provide a measure of insulation against potential differences occurring  
356 in the ground and between ground and adjacent plant. Although effective bonding significantly  
357 reduces this problem the surface insulation provides added security under system fault  
358 conditions. Permissible 'touch/step' voltages are higher where an insulated surface layer is  
359 provided – refer to 'Safety Criteria' below.

#### 360 **4.3 The effects of substation potential rise on persons**


361 During the passage of earth-fault current a substation earth electrode is subjected to a voltage  
362 rise (Earth Potential Rise, or 'EPR', sometimes denoted as  $U_E$ ). Potential gradients develop in  
363 the surrounding ground area. These gradients are highest adjacent to the substation earth  
364 electrode and the ground potential reduces to zero (or 'true earth potential') at some distance  
365 from the substation earth electrode.

366 A person will be at risk if he/she can simultaneously contact parts at different potential; thus in  
367 a well designed system the voltage differences between metallic items will be kept to safe  
368 levels regardless of the voltage rise (EPR) on the system.

369 Ground potential gradients around the electrode system, if great enough, can present a hazard  
370 to persons and thus effective measures to limit them must be incorporated in the design.

371 The three main design parameters relate to 'Touch', 'Step' and 'Transfer' voltages as defined  
372 below. These terms are shown as  $U_{VT}$ ,  $U_{VS}$  and 'A' in Figure 1.

373



374

375 **Figure 1 – Showing Touch, Step, and Transfer Voltages resulting from an earth fault**

376

377 **4.3.1 Touch potential**

378 This term describes the voltage appearing between a person's hands and feet. It arises from  
 379 the fact that the ground surface potential at a person's feet can be somewhat lower in value  
 380 than that present on the buried earth electrode (and any connected metalwork). If an earthed  
 381 metallic structure is accessible, a person standing on the ground 1 metre away and touching  
 382 the structure will be subject to the 'touch potential'. For a given substation the maximum value  
 383 of 'touch potential' can be up to two or three times greater than the maximum value of 'step  
 384 potential'. In addition, the permissible limits for step potential are usually much higher than for  
 385 touch potential. As a consequence, if a substation is safe against 'touch potentials', it will  
 386 normally be safe against 'step potentials'.

387 In some situations, the 'hand-hand' touch potential needs to be considered, for example if  
 388 'unbonded' parts are within 2 metres. The permissible limits for this scenario can be calculated  
 389 as described in IEC 60479-1, using the body impedance not exceeded by 5% of the population.  
 390 In general, such situations should be designed out, e.g. by increasing separation or introducing  
 391 barriers if the systems must be electrically separate, or by bonding items together. The siting  
 392 of fences needs consideration in this regard.

393 **4.3.2 Step potential**

394 As noted above, a potential gradient in the ground is greatest immediately adjacent to the  
 395 substation earth electrode area. Accordingly the maximum 'step potential' at a time of  
 396 substation potential rise will be experienced by a person who has one foot on the ground of  
 397 maximum potential rise and the other foot one step towards true earth. For purposes of  
 398 assessment the step distance is taken as one metre. This is shown as  $U_{s1}$  in Figure 1.

399 **4.3.3 Transfer potential**

400 **4.3.4 General**

401 A metallic object having length - a fence, a pipe, a cable sheath or a cable core, for example,  
 402 may be located so as to bring in ('import') or carry out ('export') a potential to or from the site.

403 By such means a remote, or 'true earth' (zero) potential can be transferred into an area of high  
 404 potential rise (HPR) or vice-versa. For example a long wire fence tied to a (bonded) substation  
 405 fence could export the site EPR to the end of the wire fence, where it may pose an electric  
 406 shock hazard to somebody standing on soil at 'true earth' potential. Similarly, a metallic water  
 407 pipe (or telephone cable, or pilot cable, etc.) could 'import' a zero volt reference into a

408 substation, where local voltage differences could be dangerous. Bonding the cable or pipe to  
409 the substation system might reduce local risk but could create a problem elsewhere; isolation  
410 units or insulated inserts (for pipework) are typical solutions that may need to be considered.

411 The limits for permissible transfer voltage relate to shock risk (Touch and Step Voltage), and  
412 equipment damage / insulation breakdown (Stress Voltage).

#### 413 **4.3.5 Limits for LV networks**

414 Safety criteria (as defined in Section 4.4.1) apply to the voltage that may be transferred to LV  
415 networks. Further information is given in Section 9.5.

#### 416 **4.3.6 Limits for Other systems**

417 Voltages carried to pipelines, fences, and other metallic structures during HV fault conditions  
418 must not exceed permissible touch and step voltage limits as defined below (Section 4.4.1).  
419 In some circumstances (for example pipelines connected to gas or oil pumping or storage  
420 facilities), lower limits may apply as defined in relevant standards.

#### 421 **4.3.7 Limits for Telecommunications Equipment (HOT/COLD sites)**

422 Care must be taken to ensure that telecommunications and other systems are not adversely  
423 impacted by substation or structure EPR; in general these systems must be routed so that the  
424 insulation withstand is not exceeded by passing through an area of high potential rise. Where  
425 the EPR on substations (or structures) exceeds certain levels, the operators of these systems  
426 must be notified. Refer to ENA ER S36 for more information.

427 ITU Directives<sup>†</sup> presently prescribe limits (for induced or impressed voltages derived from HV  
428 supply networks) of 430 V rms or, in the case of high security lines, 650 V rms. (High security  
429 lines are those with fast acting protection which, in the majority of cases, limits the fault duration  
430 to less than 200 milliseconds.) Voltages above and below these limits are termed 'HOT' and  
431 'COLD' respectively, although it should be noted that these terms do not relate directly to  
432 safety voltages.

433 For telecoms connections to 'HOT' sites, consultation with telecommunications provider may  
434 be necessary to arrive at a solution, e.g. isolation transformers or optic fibre links to ensure the  
435 telecoms system is segregated from the substation earth.

### 436 **4.4 Safety criteria**

#### 437 **4.4.1 General 'permissible' design limits**

438 An effective earthing system is essential to ensure the safety of persons in, and close to  
439 substations, and to minimise the risk of danger on connected systems beyond the substation  
440 boundaries. The most significant hazard to humans is that sufficient current will flow through  
441 the heart to cause ventricular fibrillation.

442 The basic criteria adopted in this specification for the safety of personnel are those laid down  
443 in BS EN 50522, which in turn derive from IEC/TS 60479-1. In addition, ITU-T directives are  
444 considered where relevant, and where their limits might be lower than BS EN 50522.

445 The relevant limits for touch and step voltages are given in Tables 1 and 2 below.

446 These use the body impedance values not exceeded by 5% of the population, and the 'C2'  
447 current curve as described in National Annexe NA of 50522:2010.

---

<sup>†</sup> (ITU-T: Directives concerning the protection of telecommunication lines against harmful effects from electric power and electrified railway lines: Volume VI: Danger, damage and disturbance (2008))

448 In selecting the appropriate limits, the designer must consider the type of surface covering,  
449 and if footwear will be worn. Within substations, it should be assumed that footwear will be  
450 worn. IEC/TS 60479-1 states that these design limits are sufficiently conservative to apply to  
451 all humans including children; however it is recommended that further reference be made to  
452 that standard, and relevant (lower) limits adopted as necessary if a substation is in close  
453 proximity to, or might otherwise impinge on high risk groups.

454

455 Table 1 – Permissible touch voltages for typical fault clearance times:

Permissible touch voltages V <sup>(A)</sup>	Fault clearance time, seconds																			
	0.1	.15	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	1.1	1.2	1.3	1.4	1.5	2	3	5	≥10 <sup>(B)</sup>
Contact area Bare feet (worst case) <sup>(C)</sup> Bare feet (with contact resistance) Shoes on soil or outdoor concrete Shoes on 75mm chippings Shoes on 150mm chippings or dry <sup>(D)</sup> concrete Shoes on 100mm Asphalt	405	362	320	247	185	135	106	89	78	72	68	65	63	64	59	58	55	52	50	50
	521	462	407	313	231	166	128	106	92	84	80	76	73	71	69	67	63	60	58	57
	2070	1808	1570	1179	837	578	420	332	281	250	233	219	209	200	193	188	173	162	156	153
	2341	2043	1773	1331	944	650	471	371	314	279	259	244	232	223	215	209	192	180	173	170
	2728	2379	2064	1548	1095	753	544	428	361	321	298	280	266	255	246	239	220	205	198	194
	13500	11800	10200	7600	5300	3600	2500	2000	1600	1400	1370	1300	1200	1100	1100	1080	990	922	885	866
NOTE: These values are based on fibrillation limits. Immobilisation or falls/muscular contractions could occur at lower voltages. Steady state or standing voltages may require additional consideration.																				
<p>A) Additional resistances apply based on footwear resistance as well as contact patch, as defined in BS EN 50522, i.e. each shoe is 4kΩ and the contact patch offers 3ρ, where ρ is the resistivity of the substrate in Ω-m. Thus for touch voltage, the series resistance offered by both feet is 2150 Ω for shoes on soil/wet concrete (effective ρ=100 Ω-m). For 75 mm chippings, each contact patch adds 1000 Ω to each foot, giving 2500 Ω (effective ρ=333 Ω-m). For 150mm chippings (and a conservative estimate for dry concrete), the total resistance is 3000 Ω (effective ρ = 670 Ω-m). Concrete resistivity typically will vary between 2,000-10,000 Ω-m (dry) and 30-100 Ω-m (saturated). For asphalt, an effective ρ =10,000 Ω-m gives 34kΩ per shoe.</p> <p>B) The &gt;= 10s column is an asymptotic value which may be applied to longer fault duration. This is a fibrillation limit only; it may be prudent to apply lower limits to longer duration faults or steady state voltages sufficient to limit body current to 'let-go' threshold values.</p> <p>C) This assumes no contact resistance but does apply the 'dry' body impedance values with large contact areas. For other scenarios (e.g. salt-water wet) refer to IEC 60479-1.</p> <p>D) Dry assumes indoors. Outdoor concrete, or that buried in normally 'wet' areas or deep (&gt;0.6m) below ground level should be treated in the same way as soil.</p>																				

**Commented [RW1]:**  
 No limits have been specified for continuously held currents

Group considers that C2 curve asymptotic value of 48mA acceptable for 10 seconds or greater.

IEEE 80 suggests that long term voltage should be that where current is below the threshold of let-go, since death by asphyxiation (rather than fibrillation) can occur for long durations if an individual's chest muscles contract to prevent breathing. This lower limit (approx. 10mA) reduces the touch voltage limit to around 35V on soil, or 44V on deep chippings/concrete. There is a limit of 80V in 50522 but this considers only fibrillation.

These factors are alluded to but not spelled out in footnote to tables.

457 **Table 2 – Permissible step voltages for typical fault clearance times:**

Permissible step voltages V <sup>(B)</sup>		Fault clearance time, seconds																			
		0.1	.15	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	1.1	1.2	1.3	1.4	1.5	2	3	5	≥10 <sup>(C)</sup>
Contact area	Bare feet (worst case) <sup>(D)</sup>	11131	9663	8357	6233	4360	2959	2100	1625	1354	1195	1101	1032	976	929	892	864	788	733	705	692
	Bare feet (with contact resistance)	22753	19763	17077	12715	8905	6044	4290	3320	2770	2434	2249	2098	1992	1897	1823	1771	1616	1503	1442	1412
	Shoes on soil or outdoor concrete	A)	A)	A)	A)	A)	A)	A)	A)	21608	19067	17571	16460	15575	14839	14267	13826	12629	11727	11250	11012
	Shoes on 75mm chippings	A)	A)	A)	A)	A)	A)	A)	A)	24906	21976	20253	18971	17951	17103	16445	15936	14557	13517	12967	12692
	Shoes on 150mm chippings or dry concrete	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	24083	22559	21347	20338	19555	18951	17311	16074	15420	15092
	Shoes on 100mm Asphalt	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)
NOTES:																					
1) As for touch voltage, these limits are calculated according to fibrillation thresholds. Immobilisation or falls / involuntary movements could occur at lower voltages. 2) In general, compliance with touch voltage limits will achieve safe step voltages.																					
A) Limits could not be foreseeably exceeded, i.e. 25kV or greater. B) Additional footwear / contact resistances appear in series (rather than parallel for the hand-foot case), and are therefore 4x those in equivalent touch potential case. C) The >= 10s column is an asymptotic value which may be applied to longer fault duration. This is a fibrillation limit only; it may be prudent to apply lower limits to longer duration faults or steady state voltages sufficient to limit body current to 'let-go' threshold values. D) This assumes no contact resistance but does apply the 'dry' body impedance values. For wet or salt-water wet, scenarios refer to IEC 60479-1.																					

459 The figures above give acceptable touch and step potentials as a function of fault current  
460 duration. Note that touch and step voltages are normally a fraction of the total EPR, and  
461 therefore if the EPR (for all foreseeable fault conditions) is below the limits above then it follows  
462 that the site will be compliant. (The full design assessment procedure is given in Section 5.)

463 Permissible limits are a function of normal protection clearance times. Figure B2 of BS EN  
464 50522 shows curves showing intermediate values, if required.

465 Touch and Step Voltages are sometimes collectively referred to as 'Safety Voltages' since they  
466 relate directly to the safety of persons or animals.

467 Substations shall be designed so that 'Safety Voltages' are below the limits defined in Table 1  
468 and Table 2 above. It will be appreciated that there are particular locations in a substation  
469 where a person can be subjected to the maximum 'step' or 'touch' potential. Steep potential  
470 gradients in particular can exist around individual rod electrodes or at the corner of a meshed  
471 grid.

472 The presence of a surface layer of very high resistivity material provides insulation from these  
473 ground potentials and greatly reduces the associated risks. Thus substations surfaced with  
474 stone chippings/concrete or asphalt are inherently safer than those with grass surfacing, and  
475 permissible limits are higher. These relate to the 'Additional Resistance' rows in the tables  
476 above.

#### 477 4.4.2 Effect of electricity on animals

478 The main focus of this document is human safety. However, horses and cattle are known to  
479 be particularly susceptible to potential gradients in soil. There are no safety limits prescribed  
480 for animals but technical report (IEC/TR 60479-3) provides some limited experimental data.  
481 Interpretation of this data suggests that voltage gradients (e.g. around remote electrodes or  
482 structures placed in fields) not exceeding 25 V/m will generally not result in animal fatality.

#### 483 4.4.3 Injury or shock to persons and animals outside the installation

484 (This from S34 – probabilistic approach. Safety voltage limits for animals should be considered  
485 only where necessary)

486 These can be introduced by metallic transfer (fence, pipe, cable) or via the soil. Where a  
487 hazardous transferred potential can occur due to metallically conductive means, that  
488 eventuality should be removed by the introduction of insulation or other protective measures  
489 (examples include insulated sections introduced into external metal fences). Where metal  
490 fences are bonded to the substation earthing system, the touch and step potentials external to  
491 them must be controlled by the design, such that they are within the acceptable limits. In other  
492 words, most risks should be managed by design. An ideal application for risk assessment is  
493 coated type fencing (such as expanded metal) where parts of the coating may degrade over  
494 time. Where HV and LV earthing systems are combined, the EPR is transferred from the  
495 installation into domestic, commercial or industrial properties and must be at a level that  
496 complies with the requirements of section 9.5.

497 *(We consider some research is needed to determine the threshold voltage for this from a safety  
498 perspective. At present it is 430 V – an ITU equipment limit value). [NB 466 V now introduced  
499 from 50522]*

500

501 [Review once project complete]

**Commented [RW2]:** [WPD SS]:  
This paragraph needs rewording as it refers to 'Some guidance is needed'. It would be helpful to keep the limit for transfer voltage at 430V/650V; perhaps this can be based on UK experience. Complete research/risk assessment and suitable guidance.

502 Issues include identification of the realistic shock scenarios in a range of property types, and  
503 the probability of this occurring and risking electrocution at a range of voltage levels. Where  
504 HV and LV systems are combined, the EPR (or part of it) will be transferred to the LV system.

505 For potentials transferred via the soil, the risk is related to the EPR magnitude (together with  
506 proximity of the person, animal or property to the installation), the likely presence of humans  
507 or animals and the degree/time of exposure. If the substation has an elevated EPR, obvious  
508 concerns are shock risk to humans who do not have appropriate footwear (beach-side or  
509 camping site locations) and if applicable electrocution to animals (such as a horse – especially  
510 one that is being trained/ridden at the time).

511 Some guidance is needed for areas of high EPR. The situation here is related to safe touch  
512 and step potentials, not equipment thresholds. For example – risk of shock in a house (similar  
513 scenario to the HV/LV bonded issue at a distribution substation), risk of shock in a field, risk of  
514 shock to a horse whilst being ridden in an adjacent field.

## 515 **4.5 Electrical Requirements**

### 516 **4.5.1 Method of neutral earthing**

517 The method of neutral (or 'star point') earthing strongly influences the fault current level. The  
518 earthing system shall be designed appropriate to any normal or 'alternative' neutral earthing  
519 arrangements, in a similar way that it will be necessary to consider alternative running  
520 arrangements that may affect fault levels or protection clearance times.

521 Note, if the system uses a tuned reactor (arc suppression coil (ASC) / Petersen coil) connected  
522 between the transformer neutral and earth, the magnitude of the current in the earthing system  
523 may be small due to the tuning of the ASC reactance against the capacitance to earth of the  
524 unfaulted phases. However, other conditions can occur that require a higher current to be  
525 considered. For instance, if the tuned reactor can be shorted out (bypassed), e.g. for  
526 maintenance or protection purposes whilst the transformer is still on load, then it is necessary  
527 to design for this (refer to sections 5.5.2 and 5.5.3). Furthermore, even if there is no alternative  
528 method of system earthing it is still necessary to consider the possibility of a neutral bushing  
529 fault on the tuned reactor effectively shorting out the tuned reactor. Such considerations also  
530 apply to all impedance earthed systems if there is a foreseeable risk of the impedance 'failing'  
531 and remaining out for any significant time.

532 The likelihood of phase-to-earth insulation failure is increased on ASC systems, particularly if  
533 earth faults are not automatically disconnected. This is because a first earth fault will cause  
534 phase displacement such that the two healthy phases will become at increased voltage relative  
535 to earth (approaching line-line voltage). Consideration should be given to a 'cross-country'  
536 fault where two phase-to-earth faults occur simultaneously on different phases. The current  
537 can approach phase-phase levels if the earth resistance at each fault site is minimal or if there  
538 is metallic interconnection between the sites.

### 539 **4.5.2 Fault Current**

540 BS EN 50522-1 describes the need to consider single phase to earth, two phase, and three  
541 phase to earth fault current flows, as well as 'cross country' faults in some situations.

542 The relevant currents for earthing design are summarised in Table 3 below. Further detail,  
543 including guidance on protection clearance times for design purposes, is given in Section 5.5.

544

545

546

**Table 3 – Relevant currents for earthing design purposes:**

**Commented [RW3]:** This table now simplified and references included to the relevant sections for more detail

Type of System Earth Supplying Fault	Relevant for thermal effects		Relevant for EPR and Safety Voltages
	Earth Electrode	Earthing Conductor	
Solid Earthing	<p>Maximum foreseeable <b>electrode current</b>.</p> <p>This is the <b>ground return current</b> or value between <b>ground return current</b> and <b>earth fault current</b>, taking into account the loss of any metallic return paths (cable sheath or overhead earth wire) where relevant.</p> <p>See sections 5.5.4 and 5.6.2</p>	<p><b>Earth fault currents</b> for all voltage levels at the substation. <b>Three phase (or phase-phase)</b> faults should be considered if phase-phase fault current can flow through earthing conductor (e.g. separately earthed items of plant, particularly single phase equipment).</p> <p>See section 5.5.3.</p>	<p>Worst case <b>earth fault current</b></p> <p><b>Ground return current</b> may be used if known, and if earth-return paths (e.g. cable sheaths and gland connections) are known to be reliable and rated for duty.</p> <p>See Section 5.5.2.</p>
Impedance Earthing	<p>Maximum foreseeable <b>electrode current</b> associated with bypass running arrangements (i.e. solid or impedance earthing) as described above.</p> <p>In addition to the solid/impedance fault currents above, the <b>electrode current</b> calculation must consider <b>cross-country</b> faults since these are more likely on ASC systems. <b>Solid earth-fault</b> level should be used if there is any doubt.</p> <p>Furthermore, long term (steady state) current flows can cause drying of soil, and must be considered in addition to normal faults. See section 5.5.4.</p>	<p><b>Worst-case fault currents</b> for all voltage levels at the substation, as described above for the relevant solid or impedance bypass system. See Section 5.5.3</p>	<p>Worst case of bypass (solid or impedance) <b>earth fault current</b> (as above) or <b>cross-country</b> fault current.</p> <p>Steady state currents (i.e. the maximum current that can flow in the earthing system without protection operation) may impose additional requirements on the designer.</p> <p>Refer to Section 5.5.2</p>
<p>Notes:</p> <p>Fault currents associated with all voltages levels in substations must be considered. The appropriate protection clearance times for each voltage level must be applied – refer to Section 5.5.2</p>			

547

548 Refer to Sections 5.5.2 and 5.5.3, or to Table 1 in BS EN 50522-1 for further details.

549 **4.5.3 Thermal effects - general**

550 The earthing system shall be sized according to the maximum foreseeable current flow and  
 551 duration to prevent damage due to excessive temperature rise. For main items of plant in  
 552 substations (switchgear, transformers, VTs, CTs, surge arrestors, etc.), consideration needs  
 553 to be given to the possibility of simultaneous phase-earth faults on different items of plant,  
 554 which could result in phase-phase current flows through the MES. Refer also to Section 5.5.3.

555 Any current flowing into an electrode will give rise to heating at the electrode and surrounding  
 556 soil. If the current magnitude or duration is excessive, local soil can dry out leading to an  
 557 increase in the resistance of the electrode system. Section 5.6.2 defines a 'surface current  
 558 density' limit (in terms of Amps per cm<sup>2</sup> of electrode area). In some situations, even if target


559 resistance and design EPR values are achieved, it may be necessary to increase the electrode  
560 contact surface area to ensure compliance with this requirement.

561

562 **5 Design**

563 **5.1 General approach (flowchart)**

564 The general approach is summarised in the flowchart below:



**Commented [RW4]:** [ROB TO DO - remove annotation and replace with references to section numbers, once these are finalised. Adjust alignment. Move to S34 when complete. NOT YET FINISHED]

566 **5.2 Design Considerations**

567 This section describes general arrangements applicable to all substations. Further discussion  
568 relating to those items specific to distribution substations is included in Section 10, and pole-  
569 mounted systems are further described in Section 11

570 **5.2.1 Limiting values for EPR**

571 The design shall comply with the safety criteria (touch, step and transfer voltages) and with the  
572 earthing conductor and earth electrode conductor current ratings, and will need to allow  
573 sufficient current flow for reliable protection operation.

574 There is no design requirement which directly limits the overall EPR of a substation to a  
575 particular value, however, the design will need to consider insulation withstand between  
576 different systems, and voltage contours in surrounding soil. The need to comply with these  
577 requirements, and safety limits, will naturally tend to restrict the acceptable EPR. In practice,  
578 an upper EPR limit may be applied by different network operators based on equipment  
579 specifications and/or proximity to third party systems.

580 **5.2.2 Touch and Step voltages**

581 Touch and Step voltages (collectively referred to as 'Safety Voltages') are the most important  
582 design criteria. A substation that fails to achieve permissible touch voltage limits will not be  
583 safe. Formulae for calculating touch and step voltages are presented in EREC S34.

584 **5.2.3 Factors to include in calculation of EPR and Safety Voltages**

585 For each operating voltage at a substation, two conditions of earth fault should be considered  
586 to determine the maximum value of earth electrode current. In one, the earth fault is external  
587 to the substation; here the current of concern is that returning to the neutral(s) of the  
588 transformer(s) at the substation under consideration. The other is for an earth fault in the  
589 substation; here the current of concern is now that value returning to the neutral(s) of the  
590 transformer(s) external to the substation under consideration. These currents are components  
591 of the system earth fault currents. If these return currents have available to them other  
592 conducting paths directly connected to the earthing system of the substation, for example  
593 overhead line earth-wires and cable sheaths, then the currents in these paths shall be  
594 deducted from the appropriate return current to derive the value of current passing through the  
595 earth electrode system of the substation. Evaluation of this 'ground-return' current component  
596 is described in EREC S34. See also Section 5.5.2.

597 **5.2.4 Transfer Potential**

598 A further factor that needs to be considered is 'transfer voltage' that may arise from a fault at  
599 the source substation(s), if there is a metallic connection (cable sheath or earth wire) between  
600 the substation earthing systems. Methods for calculating the transferred potential are  
601 described in ENA EREC S34.

602 A person at a remote location could theoretically receive the full (100%) EPR as a touch  
603 potential since he/she will be in contact with 'true earth'. This may be disregarded if the EPR  
604 at the source substation is known to meet the safety criteria, i.e. is within acceptable touch  
605 voltage limits. However, particular care is needed if there is a possibility of hand-hand contact  
606 between a transfer potential source, and other earthed metalwork. The possibility should be  
607 excluded by appropriate barriers (e.g. insulated glands, enclosures) or bonding. If this cannot  
608 be ensured, then lower voltage limits apply to the hand-hand shock case (refer to IEC/TS  
609 60479-1).

**Commented [RW5]:** Previous discussion with group decided not to include hand-hand touch potential limits, agreed to keep as such despite SS comments which raised the issue again.

Rob W's spreadsheet has numbers which could be inserted if required.

610 **5.3 Preliminary Arrangement and Layout**

611 In order to determine fully the requirements for and adequacy of an earthing system it is  
612 necessary to produce a preliminary design arrangement of that earthing system. From a site  
613 layout drawing showing the location of the plant to be earthed, a preliminary design  
614 arrangement of the earthing system for the substation should be prepared, incorporating the  
615 relevant 'functions' of Section 4.1 and the relevant 'features' of Section 4.2. The particular  
616 layout arrangement will be unique to each substation but all will have some dependence on,  
617 inter alia, a combination of the factors described in Section 5.5.3, relating to fault level, fault  
618 duration, electrode current and soil type.

619 **5.4 Design Guidelines**

620 This Section gives an outline of those features of earthing system arrangements which have  
621 proved to be most satisfactory in practice.

622 **5.4.1 Outdoor Substations**

623 Except for pole mounted equipment, it is recommended that the earthing arrangement be  
624 based on a bare 'perimeter electrode' (peripheral buried horizontal earthing electrode),  
625 generally encompassing the plant items to be earthed such that the perimeter earth electrode  
626 is at least 1m out from the plant items to provide touch voltage control at arm's reach. Internal  
627 connections shall connect from the perimeter electrode to the items of plant. These internal  
628 connections function as earthing conductor if not in contact with soil, or electrode otherwise.  
629 Where reasonably practicable, the amount run above the surface shall be minimized to deter  
630 theft. In addition, discrete earth electrodes, e.g. rods or plates, may be connected to this  
631 perimeter electrode. These may variously be employed to reduce the surface current and/or  
632 the electrode resistance of the overall earth electrode system. The overall electrode system is  
633 termed the Main Earthing System (MES).

634 The electrode system may be augmented with inter-connected, buried, bare cross-connections  
635 to form a grid. Such cross-connections increase the quantity of earth electrode conductor and  
636 mesh density of the grid, reduce touch voltages on plant within the grid, and provide local main  
637 conductors to keep equipment connections short; in addition they increase security/resilience  
638 of connections by introducing multiple paths for fault current, which is an important  
639 consideration.

640 In all substations it is recommended that duplicate connections are made from the Main  
641 Earthing System (MES) to main items of plant, in order to increase resilience (refer to Section  
642 5.5.3 for conductor sizing).

643 Where regular contact of an operator with an earthed structure is anticipated, e.g. at a switch  
644 handle, the earthing system shall be enhanced by providing an earth mat (or, if a mat poses  
645 difficulties, appropriate grading electrode) at or just below the surface of the ground and  
646 bonded to the metalwork, so arranged that the metalwork can only be touched while standing  
647 above the mat (or enhanced area).

648 Pole-mounted equipment presents a particularly difficult ground potential gradient problem and  
649 the special precautions noted in Section 10 shall be observed. It may be necessary to apply  
650 these precautions in some ground-mounted substations.

651 Fault current flowing through an earth electrode system to ground uses the outer extremities  
652 of the electrode system to a greater extent than the inner parts of the system. Thus, adding  
653 more earth electrode, whether as vertical rods or as horizontal tape, to the inner area of a small  
654 loop or well integrated grid electrode system, will have little impact in reducing earth resistance  
655 or the current density in the outer electrode conductors of the system (however this can help  
656 to control step/touch potentials around specific items of plant).

657 Such reductions (in overall earth resistance) as may be desirable are best achieved by  
658 extending the electrode system to cover a greater area of ground (e.g. by buried 'radial'  
659 electrodes), or by driving rods around the periphery of the system or by a combination of both.

660 The vertical rod electrode is most effective for use in small area substations or when low soil  
661 resistivity strata, into which the rod can penetrate, lies beneath a layer of high soil resistivity.  
662 Rods are least effective where there is a high resistivity layer beneath one of lower resistivity,  
663 e.g. where underlying bedrock is near to the surface. In these locations extended horizontal  
664 electrodes in the low resistivity surface layer are more effective.

665 For large area substations employing a grid electrode system, the addition of vertical rods,  
666 even when optimally installed around the periphery of the system, may make only a marginal  
667 improvement.

#### 668 **5.4.2 Indoor Substations**

669 The plant of indoor substations will normally be erected on a concrete raft, often containing a  
670 steel reinforcing mesh (re-bar). To control touch and step potentials around plant, it is common  
671 for re-bar to be bonded to the main earthing system, or for a dedicated 'grading mesh' (usually  
672 consisting of prefabricated steel or copper mesh) to be buried in concrete screed in the  
673 substation area. These measures are to control potential gradients and are not intended to  
674 act as an 'electrode' (they may be employed for example above basement areas); dedicated  
675 electrodes will also be required to provide a connection to the mass of earth and achieve the  
676 functional requirements. For new substation buildings a buried peripheral horizontal electrode  
677 may be conveniently installed around the building foundation and supplemented with vertical  
678 rod electrodes as required. Coordination with the civil engineering design can result in a cost-  
679 effective installation.

680 Where reinforcing mesh in concrete is to function as supplementary earth electrode, it must be  
681 designed to carry the current without cracking the concrete, be constructed with mesh panels  
682 welded together and be welded to the peripheral buried earth electrode at suitable intervals  
683 (e.g. 5 m).

684 The provision of a buried main earth bonding conductor within the confines of an existing  
685 building is often impractical and thus a surface mounted main earthing conductor loop, is  
686 normally installed with surface run (and duplicate) spur connections to the various items of  
687 plant. The earth electrode system employed with this arrangement may differ depending on  
688 the magnitude of earth fault current that the electrode system is required to carry. Marshalling  
689 earth bars are sometimes used in addition to, or instead of, a surface laid loop, and (if properly  
690 labelled) can facilitate measurement/maintenance. The convenience of such an arrangement  
691 often brings with it a high reliance on bolted connections and so the 'resilience' aspect needs  
692 to be balanced with convenience.

693 Substations in buildings may require a buried loop/ring electrode outside the building if any  
694 extraneous metalwork (e.g. metal cladding, steel joists, handrails, communications antennae  
695 etc.) is bonded to the substation earthing system and could otherwise present a touch potential  
696 issue to those outside the building. The same considerations apply where a substation is  
697 installed in an existing building (for example in the basement of a tower block), even if the  
698 building is not recognisable as a 'substation building'; in fact risks associated with members of  
699 the public will often be higher in such installations and warrant additional consideration.

700 Electrode systems (rod nests, etc.) should not be sited close to main access/egress routes  
701 without consideration of step and touch voltage in these areas.

702 Grading electrode (where required) should be positioned 1 m from metal-clad buildings, and  
703 bonded to the building's internal HV or EHV earthing system at two or more separate points.

704 If the building is to be provided with a lightning protection system that will be bonded to the  
705 main earthing system, the LPS electrodes may contribute to potential grading. Calculations  
706 and/or computer modelling will normally be necessary to demonstrate whether such measures  
707 can be used in place of dedicated grading electrodes.

708 Sparsely positioned rods (e.g. associated with a lightning protection system to BS EN / IEC  
709 62305-1) may serve this function if compliance can be demonstrated at the design stage.

710 A lightning protection electrode system if purposely designed with regard to power system fault  
711 currents and with closely spaced rods (or interconnecting electrode ring), could serve the dual  
712 purpose of lightning protection and potential grading. Care is needed to ensure that such a  
713 system cannot be disconnected from the building, e.g. by removal of test links.

714 Conversely, any earthing system designed for power system fault current may be used for  
715 lightning protection system if compliant with BS EN / IEC 62305-1, particularly with regard to  
716 high frequency components and down-conductor routing (free of tight bends etc.)

#### 717 **5.4.3 Shared Sites**

718 Where the customer operates HV (and/or EHV) switchgear, there will be a natural boundary  
719 between Network Operator's ownership, and customer ownership. Ideally the Network  
720 Operator should not rely on the customer's earthing system to ensure electrical safety around  
721 the Network Operator's assets, unless maintenance agreements can be made. In practice, the  
722 systems may need to be connected together, but each system should (where reasonably  
723 practicable) be designed to be safe (touch voltages) in the absence of any (electrode)  
724 contribution from the other system.

725 Neither party should rely on the other's earthing system unless regular maintenance/testing of  
726 both systems can be assured.

#### 727 **5.4.4 Distribution (or 'Secondary') Substations**

728 Distribution (HV:LV) substation earthing is particularly important given that LV system  
729 neutral/earth conductors may be connected to, or close to HV earthing systems and  
730 consequently could export 'transfer potential' to customer installations. Specific examples for  
731 ground mounted substations are given in Section 9, and pole mounted equipment is covered  
732 in Section 10.

#### 733 **5.4.5 Metallic Fences**

734 Substation fences are typically either a) Bonded to the MES, or b) Separately earthed. In  
735 general, a bonded design will be required if 2m separation (or barriers/effective insulation)  
736 cannot be established to prevent simultaneous contact (hand-hand) between the systems. A  
737 separately earthed system is preferable otherwise to minimise the EPR (and resulting touch  
738 voltage) that may be accessible externally.

739 In the case of bonded fences, consideration must be given to touch voltages that appear on  
740 the fence under fault conditions; an external peripheral electrode may be required 1m around  
741 the outside of the fence to achieve acceptable levels. Care must also be taken to ensure that  
742 voltage rise is not 'exported' via third party fences etc. that may be in contact with the fence.

743 Refer to Section 6.6 for more details.

#### 744 **5.4.6 Provision of Maintenance/Test facilities**

745 Facilities for Monitoring Earth System Efficiency (described in Section 6.2.5) should be  
746 included at the design stage. Refer to Section 7.5 for information on earth resistance  
747 measurements.

748 Test points (e.g. for clamp meter testing) should be shown on earthing drawings.

## 749 **5.5 Design data**

750 The final design of the earthing system can only be undertaken when sufficient knowledge is  
751 available of the proposed physical and electrical arrangements of the substation.

752 As a minimum, the designer must have knowledge of:

- 753 1) value of fault current
- 754 2) fault duration (or protection settings)
- 755 3) soil resistivity
- 756 4) substation dimensions

757 Any special features about the site, such as subsoil of a corrosive nature and the suitability of  
758 the site for driven earth rods or other forms of electrode, must be ascertained. Other relevant  
759 features, such as existing earth electrodes, nearby earthed structures, buried pipes or piled  
760 foundations are also required to be noted and taken into consideration.

761 In urban areas in particular the substation may be served by an underground cable network  
762 which (particularly if incorporating non-insulated sheaths/armours) will make a 'contribution'  
763 which may be taken into consideration. Refer to Section 9.4.3 for details on the contribution  
764 from typical 11kV networks.

### 765 **5.5.1 Soil Resistivity**

766 The value of the specific resistivity of the soil may be ascertained by reference to published  
767 data or by direct measurement. Table 4 (below) sets out typical values relating to types of soil  
768 but these should be used for very preliminary assessments only.

769 [Nationally available soil survey data can also be used for this purpose, e.g.

770 <http://mapapps.bgs.ac.uk/geologyofbritain/home.html> ].

**Commented [RW6]:** Move this link to bibliography. Group to say whether it should be deleted entirely, as websites are subject to move etc?

771  
 772

**Table 4 - Typical soil resistivity values**

Resistivity in  $\Omega \cdot m$

SOIL	RESISTIVITY ( $\Omega \cdot m$ )
Loams, garden soils, etc	5 – 50
Clays	10 – 100
Chalk	30 – 100
Clay, sand and gravel mixture	40 – 250
Marsh, peat	150 – 300
Sand	250 – 500
Slates and slatey shales	300 – 3,000
Rock	1,000 – 10,000

773

774 Multi-layer soil models and computer modelling may offer more effective / optimal designs than  
 775 typical or 'homogeneous' soil models. Except for some smaller substations, (where the  
 776 additional expense may not be warranted), direct measurement will normally be necessary  
 777 prior to detailed design. The recommended method, using the Wenner Array, is described in  
 778 Section 7.4.

779 It should be noted that the top layers of soil may be subject to significant seasonal variation  
 780 due to fluctuating moisture content. Designs should utilise deeper more 'stable' strata wherever  
 781 possible; the depth of this 'stable' layer is variable depending on soil type and weather/climate.

782 **5.5.2 Fault currents and durations for EPR and safety voltage calculations**

783 The fault current applicable to EPR calculation (and therefore safety voltage calculations) is  
 784 the maximum (symmetrical RMS) current to earth (**earth-fault current**) that the installation will  
 785 see under fault conditions.

786 Consideration should be given to future network alterations and alternative running  
 787 arrangements. A margin may be added to allow for future changes without detailed  
 788 assessment (e.g. 10-20% increase). **Normal operating time** of protection relays and breakers  
 789 should be used, rather than worst-case (back-up) protection clearance times.

790 Cable sheath or earth wire return paths should be included if they are reliable and rated for  
 791 duty, in which case the resultant (smaller) **Ground Return Current** may be used for design  
 792 purposes. Designs should consider touch voltage that may result under various failure  
 793 scenarios and for all voltage levels at a substation.

794 If specific protection settings are not available, the design should use 'upper bound' clearance  
 795 times associated with normal protection operation, as specified by the network operator.

796 These considerations apply whether the source substation (i.e. that supplying the fault) is  
 797 impedance or solidly earthed. EPR should be calculated for all voltage levels at any substation,  
 798 for faults at the substation and on circuits fed from it <sup>(Note 1)</sup>. LV faults can usually be shown to  
 799 be insignificant in this regard.

800 For substations with Arc Suppression Coils (ASCs), consideration should be given to the  
 801 alternative (bypass) running arrangements that may exist to allow for maintenance of the ASC

**Commented [RW7]:** WPD 33: Single layer or uniform models may be incorrect with regard to touch voltage assessment and Hot Zone contour assessment.

Suggest: Multi-layer soil models and computer modelling may offer more effective / optimal/accurate designs than typical or 'homogeneous' soil models. **Note that safety voltages and voltage contours calculated using 'homogeneous' soil models may be inaccurate.** Except for...  
 [REJECTED – refer this to S.34]

802 etc. In general terms the relatively low **ASC limited current must not be used for design**  
803 unless the ASC installation facilitates fast and automatic disconnection of earth faults without  
804 any bypass system <sup>(Notes 2,3,4,5)</sup>. The worst case (higher) of bypass earth-fault level and cross-  
805 country fault level shall be used for EPR and safety voltage calculations both at the substation  
806 and on circuits/substations supplied from it.

807 Substations (in particular those equipped with ASCs) supplying standing faults or unbalanced  
808 charging currents may be subject to a steady state EPR caused by unbalanced network  
809 charging current returning to the system neutral. The magnitude of this current should be used  
810 for 'steady state' EPR and current density (section 5.5.4) design calculations in addition to  
811 higher current, but shorter duration fault conditions described above. The touch voltages  
812 appropriate to the duration of such standing voltages shall be used as necessary (e.g. 153 V  
813 to limit fibrillation risk for long duration faults).

814 NOTES:

- 815 1) Or on in-feeds in the case of 132kV systems ~~with~~ earthed primary windings
- 816 2) The possibility of internal/bushing failures on an ASC (or other current limiting devices such as a resistor or reactor) should be  
817 considered. Whether to design for increased fault levels that can result from such failures is the subject of operational experience  
818 and risk assessment.
- 819 3) The source substation EPR and safety voltages must be calculated for all in-feeds to the substation, as well as for outgoing (feeder)  
820 faults.
- 821 4) The value for design purposes in such cases is the vector sum of residual earth fault current and summated ASC current ratings in  
822 the substation. Refer to EN 50522 Table 1 for more information.
- 823 5) Open circuit faults on neutral earthing impedances or ASCs are rare and consequently require no additional consideration in the  
824 context of earthing.

**Commented [RW8]:** All notes subject to further revision and group comment.

### 825 826 **5.5.3 Fault currents and clearance times for conductor size calculations**

827 Methods for calculating the appropriate values of fault current are included in **EREC S34**.

828 Conductor sizing calculations should be based on **backup** protection clearance time, i.e. the  
829 design shall allow for failure of primary protection without damage to the earthing system. In  
830 the absence of network specific data, the following operating times should be assumed, both  
831 of which may be considered to be more onerous than actual backup clearance times:

832 HV and EHV systems up to and including 132 kV: 3 seconds

833 275 kV and higher voltages: 1 second

834 Earthing conductors used to bond plant may be subject to higher currents than earthing  
835 electrodes used solely to provide contact with soil (e.g. which may be meshed and therefore  
836 subject to current division).

837 For earthing conductors and electrodes in substations it is recommended that the design fault-  
838 current value should be the worst case foreseeable value (earth fault, phase-phase, or three-  
839 phase) as described in Table 3, including that which may result from a broken or missing  
840 metallic return path (cable sheath or overhead earth wire).

841 The likely growth of fault current with time should be taken into consideration at the design  
842 stage, and measures put in place to ensure that the earthing system's rating is not exceeded.  
843 It may be appropriate to apply a 'growth factor' to allow for future development of the network,  
844 or to revisit/recalculate fault levels at future intervals to ensure ongoing compliance with  
845 Electricity at Work Regulations and ESQCR.

846 If fault levels are expected to approach the switchgear rating in the foreseeable future, the  
847 **switchgear rating may be used as the design figure**. In any case the rating of the earthing

848 system should be reviewed if plant is to be upgraded such that higher fault levels may be  
849 possible.

850 For thermal/sizing design purposes, this maximum fault current includes foreseeable phase-  
851 phase current which could flow between main items of plant, if two different phase-earth faults  
852 can happen simultaneously within a substation. This relatively rare event could occur (for  
853 example) as a result of displaced phase voltages immediately following a first earth fault.

854 As a guide, this maximum current is relevant for earthing conductors of all HV and EHV plant  
855 (between switchgear, insulators, surge arrestors, transformers, CTs/VTs, or other plant  
856 supporting or containing phase conductors or with single phase portable earth points) within  
857 the confines of a substation.

858 The maximum fault current applies wherever this may be borne by one spur connection, in  
859 which case that spur must be sized accordingly. In grid (mesh) earthing designs there will  
860 often be parallel paths to share the current; if the current is to flow in two or more paths (e.g.  
861 around a ring) then each individual path shall be sized to no less than 60% of the fault current.

862 Installations connected to, or part of the one where the highest fault current occurs, may only  
863 be required to carry a portion of that current and the earth conductors may be sized  
864 accordingly. For example, in lower voltage areas peripheral to a higher voltage one, their earth  
865 conductors must be sized to meet the lower voltage fault current and calculations may show  
866 that they are also adequate for their proportion of the HV or EHV fault current.

#### 867 **5.5.4 Fault currents and clearance times for electrode size calculations**

868 The discrete earth electrode shall at all times retain its functional properties, i.e. both its current  
869 carrying capability and its value of resistance to earth. For these reasons the temperature rise  
870 of the electrode conductor and the density of current dissipation from electrode to soil, during  
871 the passage of fault current through it, shall be limited.

872 The soil surrounding earth electrodes is of a much higher sensitivity than the electrode  
873 conductor material and thus the passage of current through the soil will develop, relatively, a  
874 much higher temperature rise. The effect of high temperature in the soil causes drying of the  
875 surrounding soil, thus further increasing its resistivity, or even the production of steam which  
876 can force a separation between the electrode conductor and its interfacing soil.

877 For this reason the current rating of an earth electrode is specified in terms of its surface current  
878 density (A/mm<sup>2</sup>). As a consequence the current rating of buried electrodes in practical  
879 installations is very much less than equivalent sized above-ground earthing conductors  
880 (Section 5.6.2 gives typical ratings).

881 Where a multi-mesh buried main earth grid is installed, the density of fault current in the earth  
882 electrode should rapidly reduce as the distance from the point of fault increases. Provided,  
883 therefore, that a sufficient quantity of grid conductor is buried and is well distributed, the surface  
884 current density will generally be satisfactory and high surface temperature restricted to a small  
885 area close to the fault point and thus have negligible effect on the value of total earth electrode  
886 resistance or on the efficacy of the earthing system as a whole.

887 The surface area of the main electrode through which the fault current flows to ground shall,  
888 as a minimum, be sufficient to disperse the maximum foreseeable electrode current.

889 Electrode sizing needs to consider the maximum **electrode current**, i.e. the current that will  
890 flow in the local electrode system. The calculated **ground return current** (i.e. the total current  
891 returning to source via local and connected electrode systems) may be used for this purpose,  
892 but cross-country faults can give rise to larger electrode current.

893 For ASC systems, the current used for design purposes should be the cross-country fault level,  
894 or bypass (solid or impedance) ground return current if this is higher.

895 For design economy, it is normal practice to assess the value of **electrode current** based on  
896 the value of earth fault current corresponding to the foreseeable future, up to the plant rating,  
897 but allowing for current division.

898 In most cases this requirement is satisfied by normal installation practice; care is needed for  
899 systems where a small electrode system is otherwise thought to be satisfactory. The  
900 appropriate fault current, as described in this section, should be divided by the surface area of  
901 the electrode system (as [NOT] described in EREC S34) to demonstrate that the current density  
902 at the electrode-soil interface is within limits given in Section 5.6.2.

903 
$$\text{Surface Current Density} = \frac{\text{Electrode Current}}{\text{Surface Area of Electrode}}$$

904 It is permitted to use the surface area of all connected electrodes (main and auxiliary) in this  
905 calculation. However, it is good design practice, wherever possible, to ensure that sufficient  
906 main electrode meets this requirement.

907 In some situations, the surface area of auxiliary electrodes (including metallic cable sheaths)  
908 may not be known. The analysis may be constrained to the (known) substation earthing system,  
909 in which case a factor (based on the ratio of resistances) can be applied to the Ground Return  
910 Current to represent the electrode current that will return through the substation's earthing  
911 system.

912 NOTE: In situations such as substations in urban areas where the overall Ground Return Current is significantly  
913 increased by interconnection to a larger network or other auxiliary electrode system, dividing this **overall ground**  
914 **return current** (returning via a wide area electrode system, shown as  $I_E$  in EREC S34 Figure 3.2) into the **local**  
915 **electrode surface area** will provide a safety margin. It is permissible, for design economy, to calculate the local  
916 electrode current (i.e. by evaluation of the ground return current 'split' between the local electrode system and other  
917 paths, shown as  $I_{ES}$  in S34 Fig 3.2), and dividing this resultant electrode current into the local electrode area. This  
918 approach should be used with caution, or combined with the risk assessment approach outlined in Section 5.8 as  
919 failure of auxiliary electrode connections etc. could result in overheating/failure of the local electrode system under  
920 fault conditions.

921 The fault current value for thermal rating of conductors is not to be used for this calculation;  
922 otherwise the installation cost and complexity will far outweigh the operational requirements.  
923 For older 'legacy' networks, or other systems where there may be increased risk of failure of  
924 the metallic earth-return path, it may be appropriate (and simpler) to use the full earth-fault  
925 current in this calculation; ultimately this decision is driven by appropriate risk assessment. If  
926 deemed appropriate, the design should withstand increased electrode currents (up to the **earth**  
927 **fault level**) that may result from broken or missing earth return path(s) such as a failed cable  
928 sheath / gland connection, overhead earth-wire or similar.

929 Backup protection clearance time should be used for all electrode sizing calculations, since  
930 primary protection may be slow to clear some earth faults (particularly with the loss of a metallic  
931 return path) and thus slow protection should not be considered as a 'second failure' in this  
932 case.

933 The design must take into account the worst case earth fault level that will result from  
934 maintenance or alternate running arrangements / network reconfiguration. Relatively rare  
935 faults (e.g. bushing failures or internal faults) which may cause an ASC or impedance to be  
936 shorted out should be considered if necessary, based on operational experience.

937 If significant ground-return current can flow for prolonged duration (i.e. without protection  
938 operation), the effect of this current should be considered separately; it can lead to drying at  
939 the electrode-soil interface and impose a steady state (or 'standing voltage') on plant which  
940 can require additional measures to ensure safety. This may be relevant for ASC systems where

941 earth faults are not automatically disconnected, or where moderate current can return via earth  
942 to the system neutral in normal circumstances due to un-balanced capacitance or leakage.  
943 The magnitude of this current may be taken as the ASC coil rating or earth-fault protection  
944 relay current settings.

945 NOTE: A maximum surface current density of 40 A/m<sup>2</sup> is appropriate for long term current flows. This is unlikely to cause drying at the  
946 electrode-soil interface.

947 Soil and existing earthing installation data required for calculations shall be obtained in  
948 accordance with the procedures set out in Sections 5.5.1 and 5.5.3.

949 Limiting values of surface current rating, calculated for some typical electrodes are given in  
950 Table 8 below.

951 **The following notes (carried from earlier table) to be deleted and incorporated into the body of the text, if necessary. Group to review.**

952 NOTE: Faults at all voltage levels in each substation must be considered.

953 NOTE 2: For all thermal ratings, three scenarios should be considered – a) long term loading (normal running), b) short term overload  
954 (fault), and c) long term overload (e.g. fault on ASC system or earth leakage below trip settings).

955 NOTE 3: For electrode surface current density calculations – the design current should be at least the highest (forecast) calculated ground  
956 return current for the substation; in addition the electrode design must allow for realistic worst case (backup clearance time and/or failure  
957 of metallic return paths) to limit the possibility of ground drying under onerous fault conditions. The maximum steady state earth fault  
958 current should also be calculated and considered with regard to electrode surface current density, refer to Note 5 below.

959 NOTE 4: It may be prudent to use a design figure somewhere between the ground return current value and the ultimate earth fault or  
960 double phase-earth fault values. The value to be used is subject to risk assessment and operational experience. The maximum current flow  
961 into individual electrode groups (where there is more than one) should be assumed to be 60% of the ultimate figure used above.

962 NOTE 6: Foreseeable growth in fault level throughout the life of the installation should be considered, and appropriate factors applied.

963 NOTE 7: It is permissible to use calculated ground return currents (for all foreseeable scenarios, where stated above) if this provides some  
964 design economy.

965 NOTE 8: Normal (ASC) limited current or ASC current ratings must not usually be used in this assessment in order to ensure safety should  
966 the ASC be bypassed or otherwise ineffective at limiting current (e.g. cross-country fault condition, faulted bushing, etc).

967 NOTE 9: Phase-phase fault currents flowing through a substation's earthing system, or via soil in the form of cross-country faults are  
968 considered more likely on ASC systems due to increased phase displacement and/or fault duration, which can stress insulation following a  
969 first earth fault. If automatic disconnection of earth faults does not occur within 3 seconds, conductor sizing and electrode sizing should  
970 consider cross-country fault level if this is likely to be greater than the solid/bypass value.

971 NOTE 10: Reduction factors for neutral current flows (multiple earthed systems) and sheath/earth wire return currents may be applied in  
972 the normal way.

973 NOTE 11: If the system relies on a single aerial earth return wire (or similar) then the likelihood of failure must be considered in any risk  
974 assessment and the full earth-fault current used (instead of ground return current) if necessary.

975 NOTE 14: In normal circumstances, earth fault levels associated with ASC systems are relatively low. Typically, ASCs can be by-passed by  
976 solid links or reactors. If such devices are present, the design fault current (including that for the electrodes) should be that for the relevant  
977 solid or impedance earthed system described above.

978 NOTE 17: Switchgear ratings may be used if these define the ultimate upper limit for the substation fault levels.

979 NOTE 18: The consideration of phase-to-phase fault current in this context allows for two simultaneous faults which may occur e.g. as a  
980 result of phase displacement. **The designer may** consider that phase-to-phase current is unlikely to flow through some parts of the system  
981 and this may lead to some design economies.

982 NOTE 19: 'Solid' earth fault level or phase-phase fault levels might be more onerous and can be applied for 'worst case' designs, if  
983 necessary to avoid the need to calculate accurate figures.

984 NOTE 20: Unless suitable protection/monitoring systems are in place to reduce the likelihood of such events.

985 **5.6 Conductor and Electrode Ratings**

986 The earthing system must remain intact following a protection failure, i.e. the earth conductors,  
987 electrodes and their joints must withstand the electrical and mechanical effects for the fault  
988 magnitude(s) and duration(s) as described in section 5.5.3.

989 **5.6.1 Earthing Conductors**

990 Earthing conductors should normally be selected from standard copper or aluminium sections;  
991 this does not exclude the use of other materials if longevity and resilience (especially to  
992 corrosion) can be demonstrated. For alkaline or acidic soils (i.e. those where the pH is greater  
993 than 10 or less than 4), or in other situations where corrosion is likely, it may be necessary to  
994 oversize electrodes, or to apply other measures to give a reasonable lifetime. Refer to BS 7430  
995 for further details.

996 Based on maximum fault clearance times, the conductor temperature should not exceed 405°C  
997 for copper and 325°C for aluminium based on an initial temperature of 30°C. A lower limit of  
998 250°C (absolute) is relevant for bolted connections, since extreme thermal cycling can lead to  
999 loosening over time.

1000 Table 4 and

1001 Table 5 (below) give declared current ratings for a range of standard conductor sizes for both  
1002 1 second and 3 second fault duration times. The short time rating of other conductors can be  
1003 calculated from formulae given in EREC S34.

1004

1005

**Table 5 - CONDUCTOR RATINGS (COPPER)**

1006

**(a) 405°C maximum temperature (Copper)**

These copper sizes are based on a temperature rise of 375°C occurring in 3 seconds and 1 second above an ambient temperature of 30°C (i.e. achieving a maximum temperature of 405°C) with the currents in columns (a) and (b) respectively applied to the conductors. For each substation it will be necessary to specify whether column (a) or (b) should apply.

Fault Current (kA) Not Exceeding		Copper Strip (mm)		Stranded Copper Conductor	
(a)	(b)				
(3 secs)	(1 sec)	Single (spur) Connections	Duplicate or Loop Connections	Single (spur) Connections	Duplicate or Loop Connections
4		25 x 4	25 x 4	35mm <sup>2</sup>	35mm <sup>2</sup>
8		25 x 4	25 x 4	70mm <sup>2</sup>	50mm <sup>2</sup>
12		25 x 4	25 x 4	95mm <sup>2</sup>	70mm <sup>2</sup>
13.2		31.5 x 4	25 x 4	120mm <sup>2</sup>	70mm <sup>2</sup>
18.5		40 x 4	25 x 4	150mm <sup>2</sup>	95mm <sup>2</sup>
22		50 x 4	31.5 x 4		120mm <sup>2</sup>
26.8		40 x 6.3	40 x 4		150mm <sup>2</sup>
40		-	50 x 4		
	40	50 x 4	31.5 x 4		
	60	50 x 6.3	50 x 4		
	63				

**NOTE:**  
 Equivalent sizes for stranded conductor include, but are not limited to the following, quoted as number of strands/strand diameter:  
 35mm<sup>2</sup>=19/1.53mm; 50mm<sup>2</sup>=19/1.78mm; 70mm<sup>2</sup>=19/2.14mm or 7/3.55mm(e.g. HDC); 95mm<sup>2</sup>= 37/1.78mm;  
 120mm<sup>2</sup>=37/2.03mm; 150mm<sup>2</sup>=37/2.25mm.

Consideration of corrosion risk may lead to the decision to specify minimum strand diameters (e.g. 1.7mm or larger as per BS EN 502164-2). A minimum strand diameter of 3mm is preferred by some DNOs for longevity of the electrode system particularly if corrosive soils exist.

1007

1008

1009

1010

**(b) 250°C maximum temperature (Copper) – bolted connections**

These copper sizes are based on a temperature rise not exceeding **250°C**, from an ambient temperature of 30°C with the currents in columns (a) and (b) respectively applied to the conductors. For each substation it will be necessary to specify whether column (a) or (b) should apply. These figures are generally applicable to bolted connections between tapes or lugs etc. which offer a relatively small thermal mass.

Fault Current (kA) Not Exceeding		Copper Strip (mm)		Stranded Copper Conductor	
(a)	(b)				
(3 secs)	(1 sec)	Single (spur) Connections	Duplicate or Loop Connections	Single (spur) Connections	Duplicate or Loop Connections
4		25 x 4		50mm <sup>2</sup>	35mm <sup>2</sup>
8		25 x 4		95mm <sup>2</sup>	50mm <sup>2</sup>
12		25 x 6		120mm <sup>2</sup>	95mm <sup>2</sup>
13.2		25 x 6		150mm <sup>2</sup>	95mm <sup>2</sup>
18.5		38 x 5		185mm <sup>2</sup>	120mm <sup>2</sup>
22		40 x 6			150mm <sup>2</sup>
26.8		50 x 6			185mm <sup>2</sup>
40		-	40 x 6		
	40	40 x 6	50 x 3		
	60	-	50 x 6		
	63	-	50 x 6		

NOTE:  
 Equivalent sizes for stranded conductor include, but are not limited to the following, quoted as number of strands/strand diameter:  
 35mm<sup>2</sup>=19/1.53mm; 50mm<sup>2</sup>=19/1.78mm; 70mm<sup>2</sup>=19/2.14mm or 7/3.55mm(e.g. HDC); 95mm<sup>2</sup>= 37/1.78mm;  
 120mm<sup>2</sup>=37/2.03mm; 150mm<sup>2</sup>=37/2.25mm.

Consideration of corrosion risk may lead to the decision to specify minimum strand diameters (e.g. 1.7mm or larger as per BS EN 502164-2). A minimum strand diameter of 3mm is preferred by some DNOs for longevity of the electrode system particularly if corrosive soils exist.

1011

1012

1013

1014

**Table 6 - CONDUCTOR RATINGS (ALUMINIUM)**

1015

**(a) 325°C maximum temperature (Aluminium)**

These aluminium sizes are based on a temperature rise of 295°C occurring in 3 seconds and 1 second above an ambient temperature of 30°C with the currents in columns 1(a) and 1(b) respectively applied to the conductors. For each substation it will be necessary to specify whether column 1(a) and 1(b) should apply.

Fault Current (kA) Not Exceeding		Aluminium Strip (mm)		Stranded Aluminium Conductor (mm)	
(a)	(b)				
(3 secs)	(1 sec)	Single (spur) Connections	* Duplicate or Loop Connections	Single (spur) Connections	Duplicate or Loop Connections
4		20 x 4	20 x 2.5	70mm <sup>2</sup>	35mm <sup>2</sup>
7.5		25 x 4	20 x 4	120mm <sup>2</sup>	70mm <sup>2</sup>
12		40 x 4	25 x 4		120mm <sup>2</sup>
13.2		50 x 4	25 x 4		120mm <sup>2</sup>
18.5		40 x 6	40 x 4		150mm <sup>2</sup>
22		50 x 6	50 x 4		
26.8		60 x 6	40 x 6		
40		60 x 6	50 x 6		
	40	50 x 6	50 x 4		
	60	80 x 6	50 x 6		

**NOTE:**  
 Equivalent sizes for stranded conductor include, but are not limited to the following, quoted as number of strands/strand diameter:  
 35mm<sup>2</sup>=19/1.53mm; 50mm<sup>2</sup>=19/1.78mm; 70mm<sup>2</sup>=19/2.14mm or 7/3.55mm; 95mm<sup>2</sup>= 37/1.78mm;  
 120mm<sup>2</sup>=37/2.03mm; 150mm<sup>2</sup>=37/2.25mm.

1016

1017

1018

1019

1020

1021

**(b) 250°C maximum temperature (Aluminium) – bolted connections**

These aluminium sizes are based on a temperature rise <b>not exceeding 250°C</b> in 3 seconds and 1 second <b>from an ambient (initial) temperature of 30°C</b> with the currents in columns 1(a) and 1(b) respectively applied to the conductors. For each substation it will be necessary to specify whether column 1(a) and 1(b) should apply. These figures are generally applicable to bolted connections between tapes or lugs etc. which offer a relatively small thermal mass.					
Fault Current (kA) Not Exceeding		Aluminium Strip (mm)		Stranded Aluminium Conductor (mm)	
(a)	(b)				
(3 secs)	(1 sec)	Single (spur) Connections	* Duplicate or Loop Connections	Single (spur) Connections	Duplicate or Loop Connections
4		20 x 4	20 x 2.5	70mm <sup>2</sup>	50mm <sup>2</sup>
7.5		25 x 5	25 x 3	120mm <sup>2</sup>	70mm <sup>2</sup>
12		50 x 4	25 x 5	185mm <sup>2</sup>	120mm <sup>2</sup>
13.2		50 x 4	25 x 5		120mm <sup>2</sup>
18.5		50 x 6	50 x 4		185mm <sup>2</sup>
22		60 x 6	50 x 4		
26.8		-	40 x 6		
40		-	60 x 6		
	40	60 x 6	40 x 6		
	60	-	60 x 6		
NOTE: Equivalent sizes for stranded conductor include, but are not limited to the following, quoted as number of strands/strand diameter: 35mm <sup>2</sup> =19/1.53mm; 50mm <sup>2</sup> =19/1.78mm; 70mm <sup>2</sup> =19/2.14mm or 7/3.55mm; 95mm <sup>2</sup> = 37/1.78mm; 120mm <sup>2</sup> =37/2.03mm; 150mm <sup>2</sup> =37/2.25mm. Duplicate or loop connections have been rated to carry 60 per cent of the full fault current.					

1022

1023

1024

**Table 7 - Cross sectional areas for steel structures carrying fault current**

<b>These sizes are based on the maximum temperature achieved after the passage of fault current for 3 seconds and 1 second from an ambient (initial) temperature of 30°C. For each substation it will be necessary to specify whether column 1(a) or 1(b) should apply.</b>			
<b>Fault Current (kA) Not Exceeding</b>		<b>250°C (applicable to bolted structures)</b>	<b>400°C (applicable to welded/continuous structures which are galvanised)</b>
<b>(a)</b>	<b>(b)</b>		
<b>(3 secs)</b>	<b>(1 sec)</b>	<b>mm<sup>2</sup></b>	<b>mm<sup>2</sup></b>
4		109	91
7.5		204	171
12		327	273
13.2		359	301
18.5		503	421
22		599	501
26.8		729	610
40		1087	910
	40	628	525
	60	942	789

1025

1026

1027

1028 **5.6.2 Electrode Surface Current Density Ratings**

1029 Table 8 below shows the current rating of typical electrodes. The limiting factor tends to be  
1030 heating at the electrode-soil interface, consequently the ratings are dependent on soil  
1031 resistivity.

1032

1033 **Table 8 - MAXIMUM CURRENT RATING OF TYPICAL ROD, TAPE AND PLATE ELECTRODES**

Soil Resistivity Ω·m	3 – Second Current Rating				1 - Second Current Rating			
	Rod 16mm Dia. A (per metre length)	Plate 915 x 915mm A	Plate 1220 x 1220mm A	25 x 4 mm tape	Rod 16mm Dia. A (per metre length)	Plate 915 x 915mm A	Plate 1220 x 1220mm A	25 x 4 mm tape
10	69.7	2322	3135	80.3	120.7	4022	6979	138.9
30	40.2	1340	2217	46.4	69.7	2322	4128	80.3
40	34.9	1161	1568	40.1	60.4	2011	3575	69.3
50	31.2	1038	1402	35.9	54	1799	3197	61.7
60	28.4	948	1280	32.7	49.3	1642	2919	56.8
70	26.3	878	1185	30.3	45.6	1520	2702	52.6
80	24.6	821	1108	28.3	42.7	1422	2528	49.2
100	22	734	991	25.4	38.2	1272	2261	44
150	18	600	810	20.7	31.2	1038	1846	35.9
200	15.6	519	701	17.9	27	899	1599	31.2
250	13.9	464	627	16	24.1	804	1430	27.8
300	12.7	424	572	14.6	22	734	1305	25.4

1034

1035 In most practical installations the actual values of surface current density will be considerably  
1036 less than the above limiting values, due to the quantity of bare buried conductor (electrode)  
1037 employed in the installation to provide effective bonding and in some installations where extra  
1038 electrodes have been added, to comply with the touch potential limits. **Further detail is given**  
1039 **in EREC S34**; note that this current density limit is independent on electrode material, and  
1040 therefore the limits can be applied to rebar/piling/other 'fortuitous' or auxiliary electrodes,  
1041 providing that temperature rise in these structures under fault conditions will not cause issues  
1042 such as cracking/distortion etc.

- 1043 Where an electrode is encased in a material such as concrete, or material/agent other than  
1044 surrounding soil, the surface area calculation should be carried out at the electrode-material  
1045 interface, using the surface area of the metallic electrode itself and the properties of the 'agent'.  
1046 In some cases it will also be necessary to carry out a similar calculation at the interface of the  
1047 'agent' with surrounding soil, noting that the larger surface area offered by the agent will apply.
- 1048 A well designed earthing system should provide sufficient surface area to satisfy this  
1049 requirement without reliance on rebar or other fortuitous / auxiliary electrodes.

1050 **5.7 Design Assessment**

1051 The assessment procedure outlined in 5.7.1 begins with an approximation which, if furnishing  
1052 satisfactory results, avoids the need for a more detailed assessment. If the results of this  
1053 approximate assessment indicate that the safety criteria could be exceeded or the rise of earth  
1054 potential is considered to be excessive, then the more refined assessment should be  
1055 employed.

1056 When an entirely theoretical approach is used for assessing the design of an earthing system,  
1057 doubts on the reliability of the result may arise due to uncertainties as to the correct value of  
1058 soil resistivity to be used or of the effects that other buried structures may have. In these  
1059 circumstances recourse may have to be had to direct measurement to obtain a more reliable  
1060 result.

1061 Recommended methods of measurement are given in Section 7.5. On the basis that the earth  
1062 electrode system will not yet be installed, measurement may be made on representative test  
1063 electrodes and the results extrapolated to the intended final design. Measurement may be  
1064 delayed until a sufficiently representative part of the intended system is installed to obtain a  
1065 better prediction of any improvements necessary. In any event a final check measurement of  
1066 the completed installation is recommended prior to energisation.

1067 **5.7.1 Assessment Procedure**

1068 An approximate assessment considers both the internal and external earth fault conditions as  
1069 explained above but disregards any contribution that external electrodes, e.g. overhead line  
1070 earth-wires or cable sheaths, may have. An approximate assessment may be all that is  
1071 required in many cases providing compliance with the safety criteria is demonstrated.

1072 By reference to the flowchart above:

- 1073 1) Establish the soil resistivity (by measurement or enquiry)  
1074 2) Estimate the resistance of the site electrode system (using computer modelling or  
1075 calculations as detailed in **EREC S34**),  
1076 3) Obtain the worst-case fault current flowing through the electrode system, disregarding  
1077 the effect of 'fortuitous' electrode systems or cable sheath/earthwire return paths.  
1078 4) Estimate the EPR, which is the product of resistance (point 2 above) and current  
1079 (point 3).  
1080 5) If the value derived in (4) above does not exceed 2x the permissible 'touch' potential  
1081 then no further assessment needs to be done. The finalised design of the earthing  
1082 system may be prepared taking into account the earthing and electrode conductor  
1083 ratings.

1084 If the value derived under (4) above exceeds the appropriate safety voltages by a factor of 2  
1085 or more, then a more refined assessment shall be made as detailed below.

- 1086 6) Determine the soil resistivity by measurement.  
1087 7) Estimate the value of the substation earth electrode system resistance, including the  
1088 contributions made by any overhead earthwires and/or earthed cable sheaths  
1089 radiating from the site using the preliminary design assessment layout and the data  
1090 provided in **EREC S34**.  
1091 8) Obtain the appropriate total values of system earth fault current for both an internal  
1092 and external earth fault and deduce the greater value of the two following quantities

- 1093 of earth fault current passing through the earth electrode system. Refer to EREC S34  
1094 for guidance on this evaluation.
- 1095 9) For an internal fault, establish the total fault current less that returning to any local  
1096 transformer neutrals and that returning as induced current in any earthwire or cable  
1097 sheath/armour.
- 1098 10) For an external fault, that returning to local transformers less that returning as  
1099 induced current in any earthwire or cable sheath/armour.
- 1100 11) Estimate the rise of earth potential (EPR) based on the product of items (7) and (9) or  
1101 (10) above, whichever is the greater.
- 1102 12) If the EPR value derived under (11) above exceeds 2x the appropriate touch or step  
1103 voltages, an assessment covering touch, step, and transfer potentials shall be made.  
1104 The design should consider LV, telecoms, and remote systems where relevant (ref:  
1105 **EREC S34 Section XXX**)
- 1106 13) If the earthing system is safe against 'touch' potential it will almost always be safe  
1107 against 'step' potential\*, although special consideration may be needed in certain  
1108 situations such as wet areas, livestock, etc.

1109 Reference should be made to **EREC S34** for equations giving ground surface potential  
1110 contours; the touch potential is the difference between EPR and ground surface potential up  
1111 to 1m from plant / bonded items. Computer modelling may be necessary for complex systems.

1112 Depending on the results of the evaluation, further improvements in the design of the earth  
1113 electrode system may be necessary until the appropriate safety criteria for touch, step and  
1114 transfer potentials are met and any necessary isolation or additional insulation is provided to  
1115 avoid contact with transferred potentials which exceed the appropriate safety limit.

#### 1116 **5.7.2 Methods to improve design (Mitigation measures)**

1117 Following assessment, if the safety criteria are not met, the designer shall consider ways to  
1118 either a) reduce overall EPR, or b) reduce the step/touch voltages.

##### 1119 **5.7.2.1 EPR reduction**

1120 As described in 4.4.1, there is no specified limit to the rise of earth potential of the substation  
1121 and the ultimate design limit is dependent on a number of factors. However, improvements  
1122 may sometimes be justified to lower this value by reducing the value of the earth electrode  
1123 resistance. If, for example, the surface potential outside the substation exceeds that which is  
1124 acceptable to third parties in that area (e.g. telecoms or pipeline operators), then lowering the  
1125 earth electrode resistance (and consequent EPR) may be considered.

1126 Reduction of earth resistance by extending electrode area may increase transfer potential onto  
1127 third party metallic services and this must be considered in the design. Note that it may be  
1128 cheaper and more practical instead to protect the other authorities' plant by isolation or  
1129 additional insulation.

1130 EPR (arising from local faults) can generally be reduced by one or more of: a) earth resistance  
1131 reduction, b) fault level reduction, or c) reducing the ground return component.

- 1132 a) Is probably more practical to achieve by installation of additional electrode.

---

\* As stated in BS EN 50522-1: As a general rule meeting the touch voltage requirements satisfies the step voltage requirements, because the tolerable step voltage limits are much higher than touch voltage limits due to the different current path through the body.

1133 b) Can be achieved by impedance earthing (section 4.5.1), or changes to running  
1134 arrangements, or possibly more accurate calculation of earth fault level including earth  
1135 resistance values (which may be of benefit in marginal situations).

1136 c) Can be achieved by lower impedance metallic return paths (e.g. enhanced cable  
1137 sheaths or earth-wires, or undergrounding a section of overhead line to make a  
1138 complete cable circuit).

1139 An excessive EPR arising from transfer voltage, e.g. carried along the cable sheath from the  
1140 source substation, can be reduced by lowering earth resistance as a) above, or by introducing  
1141 a sheath break into the cable (e.g. by using an insulated gland or un-earthed overhead line  
1142 section); special care is required in such circumstances to ensure that an individual cannot  
1143 contact two earthing systems simultaneously. There may be other considerations which make  
1144 a sheath break unacceptable or ineffective in some circumstances. Alternatively, measures  
1145 could be employed to lower the EPR at the source substation. In any case, the design must  
1146 be re-assessed to consider these revised arrangements.

#### 1147 5.7.2.2 Touch Voltage reduction

1148 If reduction of EPR is not practicable or economic, touch voltage can be reduced by adopting  
1149 measures to equalise potential between an operator's hands and feet; generally these  
1150 measures involve additional bonded grading electrode or mesh under the operator's position,  
1151 or insulated platforms.

1152 Equations are provided in **EREC S34** which give simple touch voltage calculations.

1153 The touch and step voltages must be re-calculated or re-modelled following any changes to  
1154 the electrode layout. The touch voltages appearing on external parts of a substation  
1155 (fences/doors/substations) must also be considered as these could cause issues for members  
1156 of public.

1157 In some circumstances, asphalt (tarmac) or similar ground coverings may be used to justify an  
1158 increase in the permissible limits so that the touch voltages are acceptable (see Section 4.4.1).  
1159 Protection enhancement (faster fault clearance) may be also explored in similar  
1160 circumstances, since permissible limits for touch/step voltage are higher if faster fault  
1161 clearance times can be achieved. These two measures should not be considered an  
1162 alternative to a properly designed earthing system and should be used only as a last resort, or  
1163 in conjunction with the risk assessment approach outlined below.

### 1164 **5.8 Risk Assessment**

1165

1166 [park for now]

1167

1168 [include worked examples here]

1169

1170 In some situations it may not be possible to achieve compliance with permissible safety  
1171 voltages, but (for example) in unmanned locations with restricted access, it may be deemed to  
1172 be an acceptably low risk. A risk-based approach needs to consider the statistical probability  
1173 of injury occurring, and to weigh this against the cost needed to mitigate against that risk.

1174

1175 Consideration Needed of: ESQCR Part(II) 8.2b – Gen or Dist shall ensure that.... installed in  
1176 a manner to prevent danger occurring in LV network as result of fault on HV....

1177

1178 [Make clear that Risk Assessment is a last resort – refer to flow chart].

1179

1180 [Refer to BS EN 50522:2010 National Annex NB]

1181

1182 [From new S34: *"It can be extremely expensive to control the risks of damage, shock or*  
1183 *electrocution to levels that are risk free. It is recognised in new standards that risks must be*  
1184 *accepted in order to provide electrical infrastructure to society. As set out in BS EN 50522, risk*  
1185 *assessment is one of the acceptable tools for analysis of situations where the cost of removing*  
1186 *an identified risk appears to be disproportionately high."* ]

1187

## 1188 **6 Construction of Earthing Systems**

### 1189 **6.1 General Design Philosophy**

1190 Above ground connections may use copper or aluminium conductors. Metal structures may  
1191 be used to provide connections between equipment and the earth grid where appropriate.

1192 Below ground earth grids will normally be installed using copper conductor.

1193 When designing and installing both above and below ground earthing installations the risk of  
1194 theft and corrosion must be considered and mitigation measures put in place where necessary.

#### 1195 **6.1.1 Materials**

- 1196 • The use of copper earthing conductor is preferable due to its electrical and material  
1197 properties.
- 1198 • Copper tape and (hard drawn) stranded copper conductor (min strand diameter 2mm)  
1199 may be used as buried electrode.
- 1200 • Bare aluminium or copper rope (fine braided) conductors must not be used underground  
1201 in any circumstances due to risk of accelerated corrosion.
- 1202 • Aluminium (which is less prone to theft) may be used at least 150mm above ground.
- 1203 • Galvanised steel may be used as supplementary electrode where it is already installed  
1204 for other reasons. Consideration should be given to the risk of corrosion over the lifetime  
1205 of the installation. [Galvanised steel has an electropotential different to that of copper  
1206 and can erode quickly if connected to a system which has copper electrodes ]
- 1207 • In very hostile environments it may occasionally be necessary to use more resilient  
1208 materials such as stainless steel.
- 1209

#### 1210 **6.1.2 Avoiding Theft**

1211 At the design stage all exposed copper electrode should be reduced to a minimum.  
1212 On new installations above ground exposed copper and aluminium sections should be fixed  
1213 using anti-theft fixing techniques. See Section 6.3.1 for conductor fixing detail.

1214 At new and existing high risk sites the use of additional anti-theft precautions must be  
1215 considered.

1216 Precautions above ground may include:

- 1217 • application of anti-climb paint on above ground sections and / or above ground copper  
1218 may be painted to look like aluminium or galvanised steel;
- 1219 • fitting galvanised steel anti-theft capping over the conductor to a height of at least 3 m or  
1220 the equipment position;
- 1221 • fitting steel banding around structures and pinning the fixings;
- 1222 • stamping copper tape electrode with the owner's name;
- 1223 • earth connections to such items as metal cladding, metal structures, metal door frames  
1224 or any other metallic panels should be made inside buildings;
- 1225 • additional site security precautions such as the application of alarms, electric perimeter  
1226 fences, CCTV etc.;
- 1227 • use of forensic traceable liquids;
- 1228 • avoiding yellow/green insulated coverings (use e.g. grey instead).
- 1229

1230 Precautions below ground may include:

- 1231 • placing concrete or concrete anchor blocks over buried electrode;
- 1232 • attaching earth rods every few metres to prevent removal of electrode;

**Commented [RW9]:** Chosen as consistent with 50522, group to consider also 'Installation' or 'Practical applications' etc

- 1233 • pinning electrode at least every 300 mm where it is installed in concrete trench work or
- 1234 over concrete plinths;
- 1235 • laying electrode in conductive concrete or similar materials.

1236 Earthing conductors located in pre-formed concrete trenches (or similar) containing power  
1237 and/or multicore cables should be fixed to the walls near the top (e.g. 100mm from the top).  
1238 Where possible they should be concealed or otherwise protected against theft.

## 1239 **6.2 Jointing Conductors and Equipment Connections**

### 1240 **6.2.1 General**

1241 Exothermic welded, brazed and compression type joints are acceptable above and below  
1242 ground.

1243 Bolted joints are only permissible above ground. For replacement work following theft this may  
1244 not be initially practical but any temporary bolted underground joints must be replaced to make  
1245 the repairs permanent.

1246 For connections made to equipment welded joints may be possible, but in the majority of cases,  
1247 bolted joints will be necessary. The provision of bolted earth connections on equipment needs  
1248 special consideration to achieve a low resistance arrangement which can withstand the  
1249 maximum earth fault current without deterioration. Purpose designed connections should  
1250 preferably be provided by the equipment manufacturer.

1251 Bolted connections should preferably be of the double bolt / double hole lug fixing type,  
1252 however this generally requires drillings to be provided at the equipment procurement stage.  
1253 Where single bolt / single hole lug fixings are provided the application of a washer and second  
1254 (lock) nut provides extra security.

1255 With aluminium conductors in particular surface preparation is critical to achieving connections  
1256 with ongoing low resistance.

1257 Nuts, bolts and washers are to be of high tensile stainless steel or galvanised steel, except for  
1258 transition washers used for joining dissimilar metals.

### 1259 **6.2.2 Transition washers**

1260 A transition washer may be used to minimise corrosion when joining dissimilar metals with a  
1261 bolted connection. Transition washers designed for copper-aluminium joints shall be surface  
1262 penetrating, grease protected washers manufactured from corrosion resistant copper alloy to  
1263 BS2874 (grade CZ121). They are designed to provide a stable corrosion resistant interface  
1264 between aluminium and copper or tinned copper, and are usually provided as a pack including  
1265 appropriate matched nuts, bolts and washers.

1266 Different transition washers may be required for connections from copper to galvanised metal.

1267 Transition washers tend not to be widely used for connections between aluminium and zinc  
1268 coated (galvanised) steel, because zinc and aluminium are very close in the galvanic series.  
1269 Such connections are likely to corrode however once the zinc coating has been lost, and  
1270 therefore precautions should be taken to exclude moisture by use of an appropriate grease or  
1271 paint applied after the joint is made.

1272 All bolted joints should be painted with two coats of bitumen paint, where practicable, as an  
1273 aid to preventing corrosion.

1274 **6.2.3 Copper to Copper Connections**

1275 Tape to tape connections must be brazed or exothermically welded.

1276 Stranded to stranded connections must be exothermically welded or joined using compression  
1277 joints.

1278 Stranded to tape connections must be exothermically welded or a lug must be compressed  
1279 onto the stranded conductor, which for underground use is bolted and then brazed or welded  
1280 onto the copper tape. For above ground purposes, the lug may be bolted to the tape but should  
1281 preferably have a double bolt fitting.

1282 Soft soldered joints (e.g. lead-tin or lead free solder) shall not be used.

1283 **6.2.4 Copper to Earth Rods**

1284 Connections must be brazed or exothermically welded. Bolting and U-bolts are not acceptable.  
1285 [Except for smaller distribution substations where hot works may not be practicable].

1286 **6.2.5 Electrode Test Points**

1287 Electrode test points may be required either at the rod top for long single rods or inline between  
1288 a rod group and the main earthing system. To allow individual rod resistance values to be  
1289 tested with a clip-on meter and facilitate electrode tracing all test points should be suitably  
1290 constructed to allow the test clamp to fit and to avoid corrosion.

1291 Test links are not recommended, but where installed special procedures must be adopted to  
1292 avoid inadvertent disconnection and to permit safe management/testing techniques.

1293 A test point associated with pile cap connections is useful but only if the design of the rebar is  
1294 electrically separated from the rest of the site. At most sites the rebar will be connected  
1295 together and while this provides an excellent earth, testing the individual pile cap earths is  
1296 impossible. In these cases separate earth pins should have been provided in the design  
1297 perhaps for high frequency and/or lightning protection which will allow testing between  
1298 individual earth rods and the main earth grid.

1299 **6.2.6 Copper to Equipment (Steel, or Galvanised Steel) Connections**

1300 Connections should, wherever possible, be in the vertical plane. Remove paint from the metal  
1301 at joint position on the equipment earth, sand metal smooth and apply neutral jointing  
1302 compound. Drill the copper tape to accommodate the bolts (normal diameter is 10 mm) and  
1303 then tin the complete contact area. The bolt holes must be less than one-third the width of the  
1304 tape. Failing this a copper flag must be jointed to the copper tape and the holes drilled into  
1305 this. A two bolt fixing is preferred, unless a suitably rated fixing is provided by the manufacturer.  
1306 Copper joint surfaces, once drilled should be cleaned using aluminium oxide cloth (grade 80).  
1307 Copper is tinned at all bolted connections; the tinning needs to be thin, and should not exceed  
1308 an average of 0.5 mm, otherwise it will 'flow' from bolted sections under pressure. Neutral  
1309 jointing compound is then to be applied to the joint faces.

1310 **The same procedure should be used when joining to galvanised steel, in which case the zinc**  
1311 **coating shall be removed from the joint faces.**

1312 **6.2.7 Aluminium to Equipment Connections**

1313 Aluminium conductor connections to equipment should, where possible be in the vertical plane.  
1314 In all cases joints must be made in accordance with Section 6.2.6 above. However, the  
1315 aluminium tape should not be tinned, and appropriate transition washers should be used at the  
1316 aluminium to steel interface.

1317 **6.2.8 Aluminium to Aluminium Connections**

1318 The preferred method is either inert-gas tungsten-arc (TIG) or inert-gas metal arc (MIG)  
 1319 welding provided that the area of the welded material at least matches that of the tape cross  
 1320 section. Bolted joints are acceptable since aluminium is only used above ground.

1321 For bolted joints the following applies:

- 1322 • All joints require a two bolt fixing.
- 1323 • Bolts must be high tensile galvanised steel, fitted with large diameter galvanised steel  
 1324 washers, or (optionally), transition washers designed to penetrate the aluminium  
 1325 oxide coating.
- 1326 • The surface aluminium must be cleaned using grade 80 aluminium oxide cloth or  
 1327 equivalent and coated with neutral compound grease. This may not be necessary if a  
 1328 transition washer is used, in which case manufacturer's guidance should be followed.
- 1329 • Bolts must be tightened using a torque wrench, to avoid over stressing in accordance  
 1330 with Table 9 below. It is important not to compress aluminium connectors by excessive  
 1331 tightening, as loss of 'elasticity' by plastic deformation can result in loosening of the  
 1332 connection when subject to thermal cycling.
- 1333 • All excess grease must be wiped off the finished joint.
- 1334 • The joint must be sealed with two coats of bitumastic paint or equivalent.

**Commented [C10]:** Grade 80 aluminium cloth or equivalent specified from previous electricity industry tests as it creates the optimum surface conditions for forming aluminium connections. Use has been carried forward into NG instructions.

1336 **Table 9 – Bolt sizes and torques for use on aluminium**

1337 Dimensions in millimetres

Bar Width	Bar Overlap	Bolt Diameter	Hole Size	Recommended Torque (Nm)	Washer Size	Washer Thickness
40	80	10	12	35	OD 25 ID 11	2.5
60	100	12	14	50	OD 28 ID 12.5	3.0

1338

1339 **6.2.9 Aluminium to Copper Connections**

1340 Connections are to be in the vertical plane, at least 150mm above the ground or concrete  
 1341 plinth. They must be located in positions where water cannot gather and the aluminium will be  
 1342 above the copper. Bimetallic joints must not be made on buried sections of electrode.

1343 All connections involving dissimilar metals must be cleaned with abrasive cloth and coated  
 1344 with neutral compound grease, before making a bolted connection. Copper must be pre-tinned.  
 1345 The finished joint should be sealed using bitumastic paint, compound, water proof tape or a  
 1346 heat shrink tube filled with neutral grease. A transition washer [section 6.2.2] may be used to  
 1347 minimise corrosion at bolted joints.

1348 Where joints have been made closer to ground level than 150 mm (usually following theft), a  
 1349 corrosion risk assessment is necessary. If the ground is well drained and there is little chance  
 1350 of water being retained around the joint then the above arrangement is acceptable. If not then  
 1351 the copper must be extended upwards to reduce risk of corrosion.

1352 **6.2.10 Earthing Connections to Aluminium Structures**

1353 The following procedures are necessary to ensure that aluminium structures used to support  
1354 substation equipment do not corrode:

1355 (i) The bottom surface of the structure base and the top surface where galvanised  
1356 steel or other equipment is to be fitted, must be painted with two coats of bitumastic  
1357 paint, prior to bolting into position on the concrete plinth. (Note - this reduces the  
1358 possibility of bimetallic action which would corrode the aluminium). A conducting  
1359 strap is required between any steel of the top level equipment support and the  
1360 aluminium structure.

1361 (ii) Provision should be made for connecting below ground conductor to the structure  
1362 via a suitable drilling and bi metallic connection (ref. 6.2.9).

1363 (iii) Except for fault throwers and high frequency earths (capacitor voltage transformers  
1364 and surge arresters) the aluminium structure leg(s) may be used to provide earth  
1365 continuity down to the connection to the main earth grid. The following is also  
1366 necessary:

1367 Any bolted sections of the structure that may be subject to bimetallic corrosion, and/or may be  
1368 of insufficient cross section, should be bridged using aluminium earth tape. The bridged joint  
1369 must be made as any other aluminium to aluminium earth connection. Totally tinned copper  
1370 straps can be used if necessary on connections to insulator supports from the aluminium. The  
1371 copper and completed connection must be painted to prevent moisture ingress and corrosion.

1372 The aluminium structure must be connected to the main substation earth grid, using copper  
1373 tape that is tinned at the joint position.

1374 Where the legs of the support structure are greater than two metres apart or the structure forms  
1375 a bolted TT (or goalpost type) formation, an earth connection must be made on two legs of the  
1376 structure.

1377 **6.2.11 Steel Structures**

1378 Steel structure legs should be used wherever practicable to provide the connection between  
1379 the earth grid and equipment at the top, except for fault throwers and earth switches. For  
1380 equipment requiring high frequency earths (e.g. capacitor voltage transformers and surge  
1381 arresters), refer to section 6.14.

1382 Ideally the structure should be of the welded type or have one or more legs formed with a  
1383 continuous section from ground to equipment level.

1384 If a steel structure is used to convey fault current, it must be reliable, and of sufficient current  
1385 carrying capacity to avoid excessive temperature rise. If there is reliance on a single joint or  
1386 leg, bolted shunts shall be considered. Where bolted shunts are used, the temperature rise of  
1387 bolted connections shall be limited to 250 °C. Refer to Section 0.

1388 Joints should be reliable. Galvanising (zinc coating) of the steel forms an oxide which  
1389 increases in thickness with age and could create a high resistance at steel - steel joint surfaces.

1390 Where aluminium tape is connected to a galvanised steel structure a transition washer is not  
1391 required, however adequate preparation of the joint surfaces, and protection from water  
1392 ingress is required in accordance with normal best practice. Refer to Section 6.2 for more  
1393 detail of jointing practices.

1394

1395 **6.3 Above Ground Earthing Installations**

1396 **6.3.1 Fixing Above Ground Conductor to Supports**

1397 Previous standards required that above ground copper or aluminium tape was fixed to  
1398 structures at 1m intervals using cleats. This is acceptable from a technical prospective;  
1399 unfortunately the cleats used provide a convenient way for the above ground conductor to be  
1400 stolen.

1401 To prevent theft, the following methods of fixing shall be used:

1402 Pinning at least every 300 mm for higher security using stainless steel pins. (The pins should  
1403 have plastic spacers to separate the pin from the conductor and in the case of aluminium,  
1404 plastic spacers to separate the aluminium from galvanised steelwork).

1405 Drilling and screwing with tamper proof screw heads. This method is more appropriate if the  
1406 concrete support may be damaged by use of percussion driven pins. Again a plastic spacer is  
1407 required to separate the screw from the metal. The screws should be stainless steel.

1408 It is important that the pins or screws are fitted such that water cannot gather and cause  
1409 corrosion. Aluminium should preferably not be in direct contact with concrete, so if practicable,  
1410 the back of the conductor should be coated with a high temperature aluminium grease or other  
1411 heat-proof coating to prevent this.

1412 Consideration must be given to the reduction of conductor cross sectional area and current  
1413 carrying capability due to drilling. Any holes introduced into the earth conductor should not  
1414 exceed 10mm in diameter and one third of the width.

1415 Note that the design final temperature of a bolted connection is 250 °C, compared to that of  
1416 405°C (copper) and 325°C (aluminium). Consequently earthing conductors with bolted  
1417 connections have a rating that is between 80% and 90% of their normal value.

1418 **6.3.2 Prevention of Corrosion of Above Ground Conductors**

1419 Copper strip conductor supported from or in contact with galvanised steel should either be  
1420 tinned or coated in a high temperature grease to prevent electrolytic action.

1421 Unless it is protected, aluminium earthing conductor should not be laid within 150 mm of  
1422 ground level.

1423 **6.3.3 Metal Trench Covers**

1424 Within substation buildings, trench covers need to be indirectly earthed. This is best achieved  
1425 by installing a copper strip (25mm x 3mm) along one edge of the trench top edge. The covers  
1426 will be in contact with this when in position. The copper strip should be bonded to the  
1427 switchgear earth bar or internal earthing system.

1428 [Feedback awaited re: Computer flooring / suspended flooring]

1429 **6.3.4 Loops for Portable Earth Connections**

1430 Earth loops of aluminium or copper strip conductor connected to the structure earth  
1431 connection, must be provided at appropriate locations where portable earth leads need to be  
1432 applied. The loops, if not provided as part of the structure shall preferably be formed separately  
1433 and jointed to the aluminium or copper tape. Recommended size should be not less than 230  
1434 mm long and 75 mm high.

1435 Loops must not be installed in the run of high frequency earths associated with CVTs and  
1436 surge arrestors since these will introduce a high impedance to high frequency/steep fronted  
1437 surges. A loop for portable earths may be added in parallel to the straight earthing conductor

Commented [RW11]: Don't think this is correct? Al  
electropotential similar to that of Zn, but Cu and Zn should be  
separated?

1438 rather than as a loop formed in the earthing conductor itself. 'D' loops should only be installed  
1439 on fully rated conductors.

1440

#### 1441 **6.4 Below Ground Earthing Installations**

##### 1442 **6.4.1 Installation of Buried Electrode within a Substation**

1443 The electrode must be installed at least 600 mm deep. This gives physical protection to the  
1444 electrode and connections. It also tends to place the electrode in moist soil below the frost line  
1445 so helping ensure its resistance is stable. The resistivity of ice is in the region 10,000 to  
1446 100,000 Ohm.m (e.g. compared with 10-1000 Ohm.m for most soils), therefore an earthing  
1447 system's resistance will increase significantly if it is not clear of frost.

1448 Buried earth electrode should be surrounded by 150 mm of fine texture non-corrosive soil,  
1449 firmly consolidated. The use of pulverised fuel ash (PFA) or coke breeze as backfill is not  
1450 recommended as it may induce rapid corrosion of buried electrode and metallic cable sheaths.  
1451 Where there is a risk of corrosion, the electrode size may need to be increased.

1452 If the indigenous soil is hostile to copper, i.e. acidic with a pH value of less than 6 or alkaline  
1453 with a pH value of more than 10, suitable surrounding soil should be imported. However, if  
1454 groundwater is present (which may serve to remove the imported soil) then other methods may  
1455 be necessary to protect the electrode. More regular testing or inspection may be required.

1456 When laying stranded conductor, care should be taken to avoid distorting and opening the  
1457 individual strands, because this increases the probability of accelerated corrosion.

1458

##### 1459 **6.4.2 Positioning of Buried Electrode**

1460 The laying of earth electrode close and parallel to hessian served power cables, multicore  
1461 cables, or bare metal pipes, is to be avoided. This is to reduce the risk of them being punctured  
1462 due to high currents or voltage transients on the electrode.

1463 Electrode must be at laid at least 300 mm away from hessian served power cables and bare  
1464 metal pipes and 150 mm away from plastic sheathed cables. Where a crossing is necessary,  
1465 PVC tape or a split plastic duct must be applied around the cable or pipe for 0.5 m either side  
1466 of a position where the cable or pipe crosses an earth electrode, or for the distance over which  
1467 the 0.3 m separation cannot be maintained.

1468 Where copper tape within the site is to be buried under proposed cable routes care must be  
1469 taken to ensure it is buried deep enough or otherwise protected in a duct so that it is not  
1470 damaged during cable installation.


1471 Where electrode connected to the earthing system is laid under metal fencing, and the fencing  
1472 is independently earthed, the electrode should be insulated for at least 2 m each side of the  
1473 fence.

1474 Earthing conductors laid near drainage pits or other civil works should maintain a separation  
1475 of at least 500 mm to avoid mechanical damage during subsequent works.

1476 Where bare electrode has to cross permanent trench routes:

- 1477 • short lengths of electrode may be laid under the trench for later connection to the
- 1478 grid;
- 1479 • a short duct may be laid under the trench to accommodate the electrode.

1480 Subsidiary connections to equipment may be laid at shallower depth. Due to variation of soil  
1481 resistivity near the surface, their contribution to the overall earth resistance should be ignored



Commented [RW12]:

1482 in the design. Their contribution towards reducing touch and step potentials should be  
1483 included.

1484 In cases where a concrete plinth covers the whole substation site, (e.g. 11 kV/LV unit type or  
1485 urban 33kV substations) earth electrodes should be installed prior to construction of the plinth.  
1486 Provision should be made to bring multiple connections out through the concrete. The extent  
1487 of the electrode mesh required will be influenced by whether steel reinforcing is used and  
1488 bonded, within the foundation.

1489 When routing bare electrode off site, either to reduce the overall earth resistance or to provide  
1490 a connection to external equipment such as terminal poles, routes that may be frequented by  
1491 people with bare feet or animals are to be avoided.

1492 If this is not possible, calculations or computer modelling should be used to confirm that the  
1493 step potentials in these areas are acceptable (a design figure of 25 V/m may be used for  
1494 livestock areas as described in Section 4.4.2). Where electrode crosses land that is ploughed  
1495 it should be installed a minimum of 1m deep.

1496 When rebar is installed in building and equipment foundations duplicate connections may be  
1497 made from the rebar to the grid for touch voltage control. (See section 6.5).

1498 Burying copper in concrete below ground level, and at a depth such that the moisture content  
1499 remains reasonably stable, does not reduce the effectiveness of the earthing [except where  
1500 damp-proof membranes are installed].

1501

## 1502 **6.4.3 Other Earth Electrodes**

### 1503 6.4.3.1 Earth Rods

1504 These are generally convenient to install where the subsoil is free from boulders and rock. Rod  
1505 electrodes and their connections should be in accordance with ENA TS 43-94. The earth  
1506 resistance of a rod or group of rod electrodes may be calculated from formulae given in **EREC**  
1507 **S34**.

1508 A number of rods may be connected in parallel but they should be installed with sufficient  
1509 spacing apart such that each is essentially outside the resistance area of any other. For  
1510 worthwhile results the mutual separation should be not less than the depth of the rod.

1511 The rods may be connected to the earth grid via a test chamber which is capable of accepting  
1512 a clip on resistance meter.

1513 Deep earth electrodes should, as far as possible, be driven into the earth vertically. If rods are  
1514 installed in drilled holes they may be backfilled with a proprietary low resistance backfill  
1515 material.

1516 Rods may be particularly advantageous if the earth resistivity falls with depth. If several deep  
1517 earth electrodes are necessary in order to achieve a required parallel resistance, then, where  
1518 space is available, the mutual minimum separation could usefully be double that of the effective  
1519 length of an individual earth electrode.

1520 Substations in large urban developments are often located below ground level in tanked  
1521 structures. In such situations special facilities for installing earth electrodes are required.

### 1522 6.4.3.2 Earth Plates

1523 Earth plates tended to be used in older earthing system designs when they were often situated  
1524 in groups or "nests" near the main transformers. Modern designs make little use of plates,  
1525 except where the soil is such that it is difficult to drive in earth rods or at the corners of the

1526 earth grid perimeter electrode. In this case a plate will be installed in the vertical plane and  
1527 acts as a replacement for a rod.

1528 In older sites, should an earth plate require replacement, it is likely that the earthing system  
1529 itself will require redesign and this may render the plate obsolete. Where there is any doubt,  
1530 the plate can be replaced on a like for like basis, or by several 2.4m rods in parallel, close  
1531 together. Plates are typically 1220 mm or 915 mm square in size, of ribbed cast iron and  
1532 approximately 12 mm thick.

### 1533 **6.5 Use of Structural Earths including Steel Piles and Rebar**

1534 Structural metalwork (piles and foundations) can make a valuable contribution to an earthing  
1535 system, specifically providing parallel paths for earth fault current, reducing overall earth  
1536 resistance and increasing resilience. Such contributions should be viewed as additional, rather  
1537 than instead of, a dedicated earthing system.

1538 Horizontal (meshed) rebar installed in concrete or in a screed below plant can provide good  
1539 control of touch voltages. In this sense it should be viewed in terms of touch voltage control,  
1540 rather than as an electrode system.

#### 1541 **6.5.1 Sheet Steel Piles**

1542 Sheets that are more than 3m long and 2m wide are to be bonded to the earthing system, as  
1543 specified by the Design Engineer. Stainless steel studs are to be exothermically welded to  
1544 each second sheet at a suitable height (normally 600mm below finished ground level) and a  
1545 strip of 40mm x 4mm copper tape will be bolted to these. The strip will in turn be connected to  
1546 the main substation earthing system. If the piles form a separate electrode connected to the  
1547 earthing system at one point, then the connection should be via a test chamber such that the  
1548 contribution of the piles may be monitored. Bolted connections should be avoided where  
1549 possible.

#### 1550 **6.5.2 Horizontal Steel Reinforced Foundations**

1551 For transformer and switch rooms, the most significant benefit of shallow rebar mesh is in  
1552 potential grading (touch voltage control). Where this is necessary to ensure operator safety  
1553 (i.e. in situations where the EPR exceeds safe touch voltage limits), it is important to ensure  
1554 the integrity of any connections.

1555 For touch voltage control, rebar will be installed normally at shallow depth (i.e. with the rebar  
1556 strips bound with soft steel wire, or as a prefabricated mesh), but with two or more rebar  
1557 connections left protruding from the concrete for approximately 150mm sufficient to allow  
1558 connection to copper or aluminium conductors. Alternatively connections may be provided  
1559 before concrete is poured using a rebar clamp with flexible earth conductor. In either case any  
1560 inaccessible rebar extension used for the final connections must be welded to the main rebar  
1561 assembly.

1562 Ideally the rebar should be arranged with welded connections along at least two orthogonal  
1563 edges such that welded joints connect each bar.

1564 If the rebar in concrete is to function as an auxiliary earth electrode (e.g. it is installed at  
1565 sufficient depth to make a contribution), then current rating considerations may mean that  
1566 exothermic welding is necessary for connections to the rebar and between rebar meshes.

1567 NOTE: Protruding rebar may not be acceptable in some circumstances due to concerns with water ingress etc.

1568 **6.5.3 Vertical Steel Reinforced Concrete Columns**

1569 Where these columns have steel reinforcing that extends further into the ground than it  
1570 possible to bury a conventional earthing system, then the design may require these to be  
1571 bonded to the earthing system. The easiest method is to leave a section of bonded rebar  
1572 150mm out of the concrete for a connection to be made later by the earth installers. This steel  
1573 reinforcing bar must have its electrical continuity maintained at joint positions by welding the  
1574 connection. Some designs require electrical connections between the piles made with rebar.  
1575 In this case supervision of the civil works will be required before concrete is poured.

1576 NOTE: Protruding rebar may not be acceptable in some circumstances due to concerns with water ingress etc.

1577 **6.6 Metallic Fences**

1578 Two alternative earthing arrangements may be applied to metallic substation fences. These  
1579 are:

- 1580 • an independently earthed (or segregated) fence arrangement where the fence is kept  
1581 electrically isolated from the substation main earth system (Figure 2) or:
- 1582 • a bonded fence arrangement where the fence is bonded to the substation main earth  
1583 system (Figure 3).

1584 Occasionally it may be appropriate to employ both methods on different fence sections at the  
1585 same site. In this case insulated sections are used to physically link the fences with different  
1586 earthing arrangements.

1587 Where the fence panels are supported by steel posts that are at least 1m deep in the ground,  
1588 the posts can be considered as earth electrodes.

1589 Where it is important (mainly overhead lines crossing or in parallel with the fence or proximity  
1590 to magnetic fields) to provide electrical continuity between adjacent panels, this can be  
1591 provided by attention to the bolt/fixing connections or by providing a separate continuity  
1592 conductor (buried or supported on the fence).

1593 **6.6.1 Independently Earthed Fences**

1594 Where the substation earthing system is effectively within the substation perimeter fence, the  
1595 fence should be separately earthed with rods approximately 2.4 m long located at:

- 1596 • all fence corners;
- 1597 • one metre either side of each point where HV overhead conductors cross the  
1598 fence;
- 1599 • additional locations such that the interval between rods sites shall not exceed 50m.

1600 Gate posts should be bonded together with below ground connections to ensure that difference  
1601 potentials do not arise when the two parts are bridged by a person opening the gates. Flexible  
1602 copper bonds (minimum 16mm<sup>2</sup> cu or equivalent) should also be used to bond the gates to the  
1603 posts as an additional safety measure.

1604 **6.6.2 Segregation between independently earthed fence and earthing system**

1605 A segregation distance above ground of at least 2 metres should be maintained between the  
1606 substation fence and the substation earthing system including all items connected to it. (This  
1607 is based on personnel avoiding simultaneous contact with the independently earthed fence  
1608 and equipment connected to the earthing system.) A similar distance shall be maintained  
1609 below ground, where practicable, taking into account the location of substation perimeter  
1610 electrodes etc.

1611 The 2m segregation between the independently earthed fence and the earthing system shall  
1612 be maintained on an ongoing basis. This must not be compromised by alterations such as the  
1613 addition of lighting or security installations, where e.g. cable armours can compromise the  
1614 segregation of the systems.

1615 Where the required segregation cannot be achieved then mitigation measures should be  
1616 considered (e.g. insulating paint or barriers (that do not compromise security)). Alternatively,  
1617 the risk assessment approach outlined in section 5.8 may be applied.

1618 Methods to calculate the transfer potential onto fences are described in **EREC S34.**


1619

1620

1621

1622 Figure 2 – Arrangement of separately earthed fence

1623 [RW to update: Rods as circles (show key); include gate; insulated ducts; palisade fence;  
1624 annotation to be added – not yet complete]



1625

1626

### 1627 6.6.3 Fences Bonded to the Substation Earthing System

1628 This arrangement is used where substation plant and equipment is located with 2m of a  
1629 metallic fence and where internal fences which are located within the area encompassed by  
1630 the substation earthing system. The fences should be connected to the earth grid using  
1631 discrete but visible connections located at:

- 1632
- 1633 • all fence corners;
  - 1634 • one metre either side of each point where HV overhead conductors cross the fence;
  - 1635 • additional locations such that the interval between connections does not exceed  
1636 50m.

1637 Where the fence which is connected to the substation earthing system is the perimeter fence,  
1638 and where the touch potential external to the fence could exceed the safety limits set out in  
1639 Table 1, then the following requirements apply.

- 1640
- 1641
- 1642
- 1643
- 1644
- 1645
- 1646
- 1647
- 1648
- A bare electrode conductor shall be buried in the ground external to the perimeter fence at approximately a distance of 1 metre away and at a depth of 0.5 metres. In agricultural locations risk of disturbance due to ploughing should be addressed;
  - The conductor should be connected to the fence and to the earthing system at intervals of 50 metres or less such that it becomes an integral part of the substation earthing system. One method to achieve this is to 'expand' the substation grid such that the fence is located within the area of this grid. (Figure 3);
  - Chippings or asphalt around the substation perimeter will provide additional protection to animals/persons outside the substation.

1649 At locations where fencing connected to the substation earth grid abuts with independently  
1650 earthed fencing and this presents a touch hazard, there should be electrical isolation between  
1651 the two fence systems. See para. 6.6.5 for methods of achieving electrical isolation between  
1652 fences using insulated fence sections.

1653

1654 **Figure 3 – Arrangement of bonded fence**

1655 [RW to do]

1656

1657 **Note S34 to contain drawing/calcs showing fence touch voltages**

1658

#### 1659 **6.6.4 Third Party Metallic Fences**

1660 Third parties shall not directly connect their metal fences to a metallic substation fence, as this  
1661 may introduce a transfer potential risk. Where such third party fences are present or are likely  
1662 to be present within 2 m of the substation, one of the options listed below should be  
1663 implemented to maintain electrical isolation between the two fence systems.

1664 Note: Security considerations may preclude this if the third-party fence could act as a climbing aid.

#### 1665 **6.6.5 Insulated Fence Sections.**

1666 Insulated fence sections to segregate lengths of fencing which are bonded to the main earth  
1667 grid from those which are independently earthed or connected to third party fences may be  
1668 used. The insulated sections may be formed by:

- 1669 a) Installing a 2 m (or longer) insulated fence panel made wholly of insulating material.
- 1670 b) Installing a 2 m (or longer) metal fence panel mounted on insulated supports / standoff  
1671 insulators. (The insulators need a voltage withstand capability in excess of the highest  
1672 EPR at the perimeter of the site whilst at least maintaining the equivalent physical  
1673 strength of the fence).

1674 Coated fences (section 6.6.7) must not be treated as insulated sections unless specifically  
1675 designed and tested for such purposes.

#### 1676 **6.6.6 Chain Link Fencing (Galvanised or Plastic Coated)**

1677 Such fencing should be earthed by bonding the support posts, fence and straining wires and  
1678 any anti-climbing devices to the independent or bonded fence earth electrode system as  
1679 appropriate. This may conveniently be achieved by the addition of an electrode run with the  
1680 fence to aid bonding/earthing. The fence shall be treated as if it were bare metal, i.e. no  
1681 insulation withstand should normally be assumed.

1682 If a touch potential issue exists with a plastic coated chain link fence it should be addressed  
1683 by installing a grading electrode rather than by relying on the integrity of the plastic fence  
1684 coating which may not be comprehensive and is also likely to deteriorate.

#### 1685 **6.6.7 Coated Fence Panels**

1686 These typically consist of galvanised steel support posts and galvanised steel mesh panels,  
1687 all of which are coated. When used for enclosing electrical apparatus or a substation, they  
1688 shall be earthed and precautions are necessary to cater against damage or erosion of the  
1689 coating. The support posts shall be earthed via a bolted connection and ideally the metal of  
1690 each panel should in turn be similarly connected to the post. Ideally these should be via  
1691 manufacturer provided facilities. The overall fence is connected to earth in a similar manner to  
1692 a separately earthed or bonded metal palisade fence.

1693 Such fences should not be treated as insulating, unless the covering is specifically designed  
1694 for this purpose and its longevity can be assured.

1695 If a touch potential issue exists with a coated fence it should be addressed by installing a  
1696 grading electrode.

#### 1697 **6.6.8 Electric Security Fences**

1698 When electric security fencing is installed on independently earthed fence installations, the  
1699 isolation of segregated fence sections from the main substation earthing system must be  
1700 maintained. This may require independent electric fence zones and special consideration of  
1701 electric fence earth connections.

#### 1702 **6.6.9 Anti-climbing Precautions**

1703 Where barbed wire or other metal anti-climbing devices are erected along the top of brick walls  
1704 or other non-metallic barriers they may be connected to earth using the same procedure as  
1705 with fencing. Note that metallic parts not liable to introduce a potential need not be bonded  
1706 (e.g. short lengths of barbed wire or spikes etc.).

1707 Care should be taken to ensure that anti climbing guards do not bridge fencing sections that  
1708 are designed to be separately earthed or isolated. This includes e.g. the metal centre rods of  
1709 plastic 'vane' guards etc.

### 1710 **6.7 Specific Items**

#### 1711 **6.7.1 Water Services to Substations**

1712 Water supplies to substations shall be run in non-metallic pipes. This avoids the substation  
1713 potential rise being transferred outside so endangering other users of the water supply system.  
1714 This is now largely a legacy issue at older sites as insulated pipes are used for new  
1715 construction. When such an existing site is being refurbished or upgraded at least a section of  
1716 insulated plastic pipe should be inserted in the incoming metallic water service.

1717 Any metallic pipe used within the substation site should be bonded to the substation earthing  
1718 system and adequately segregated from separately earthed fence sections.

#### 1719 **6.7.2 Non-current carrying metalwork**

1720 Most non-current carrying metalwork of all kinds within the perimeter fence shall be securely  
1721 bonded to the main earthing system to ensure that all such items are held to the same potential  
1722 and, if called upon to do so, will carry fault currents without damage. Exceptions apply to  
1723 conductive parts not liable to introduce a potential, and these need not be bonded.

1724 The cross section of any bonding conductors shall be as described in

1725 Table 5 and Table 6. If there is no likelihood of current flow or corrosion/erosion, equipotential  
1726 bonding conductors should be no smaller than 16mm<sup>2</sup> copper or equivalent.

1727 NOTE: Small metallic items (extraneous metalwork) that are unlikely to introduce or carry a significant potential,  
1728 need not be bonded to the main earthing system (ref: 4.2). Such items may include, but are not limited to, window  
1729 frames, signposts, wall brackets, small access steps/handrails etc.; However if there is any foreseeable likelihood  
1730 of them adopting a potential in service (sufficient to cause a touch voltage hazard), such items should be bonded  
1731 to the main earthing system.

1732 Larger items, even if some distance from current carrying metalwork, may adopt a stray voltage due to induction or  
1733 capacitive coupling and should always be bonded.

### 1734 **6.7.3 Items normally bonded to the main earth grid:**

1735 These include:

- 1736 • overhead line termination structures including towers, gantries and earthed wood pole  
1737 structures within or adjacent to the substation;
- 1738 • power cable sheaths and armours (at one or more points);
- 1739 • transformer and reactor tanks, coolers and radiators, tap changers, earthing resistors,  
1740 earthing reactors, high voltage transformer neutral connections;
- 1741 • metal clad switchgear assemblies and cases, isolators and earth switch bases;
- 1742 • metal gantries and structures and metalwork mounted on wood structures;
- 1743 • metallic building structures including steel frames (bonded at each corner), rebar and  
1744 piles. Miscellaneous metalwork associated with oil and air tanks, screens, steel structures  
1745 of all kinds;
- 1746 • all panels, cubicles, kiosks, LV AC equipment, lighting and security masts.

1747 Critical items such as transformer tanks and terminal towers shall have duplicate connections  
1748 to the main earth grid.

### 1749 **6.7.4 Items NOT normally bonded to the Earth Grid**

1750 The following list is not exhaustive, and includes some typical items that a designer may specify  
1751 to remain un-bonded.

- 1752 • The perimeter fence is only bonded to the main earth system if all or part of it cannot be  
1753 kept at least 2 m clear of earthed structures and the main earthing system. (Section 6.6)
- 1754 • Screens of telephone cables where they are taken into HOT sites. (Refer to 4.3.7);
- 1755 • Extraneous non-current carrying metalwork as described in Section 6.7.2
- 1756 • Parts intended to be isolated from earth (e.g. floating fence panels, some stay wires, etc.)
- 1757 • Some protection equipment, or equipment connected to (e.g.) frame leakage protection,  
1758 which must be connected to earth in a specific manner.
- 1759 • LV neutrals/earths in some circumstances.

### 1760 **6.7.5 Non-standard bonding arrangements**

1761 Sometimes it may be necessary to isolate cable sheaths and screens from the main substation  
1762 earth grid to avoid transfer potential issues. Such arrangements must be the subject of a  
1763 bespoke design and precautions taken at the earth isolation point to avoid touch potential  
1764 issues.

1765 NOTE: There may be other considerations which make a sheath break unacceptable or ineffective in some  
1766 circumstances. ENA EREC C55 provides further related information.

1767 **6.8 Overhead Line Terminations**

1768 **6.8.1 Tower Terminations Adjacent to Substation**

1769 Where the aerial earth wire of an incoming overhead line terminates on a steel tower / terminal  
1770 support adjacent to a substation, continuity shall be provided for current in the earth wire to  
1771 flow into the main earthing system. Continuity is to be provided by:

- 1772 • bonding the aerial earth wire to the top of the line gantry, or;  
1773 • bonding the aerial earth wire to the top of the tower, and bonding the base of the tower to  
1774 the main substation earthing system.

1775 The rating of the bonds must at least be equal to that of the aerial earth wire.

1776 If not bonded via aerial earth wire, the tower must be bonded to the main earth grid via two  
1777 continuous conductors which run from different tower legs via separate routes and connect to  
1778 two different points on the main earth grid. Each below ground conductor must be fully rated.  
1779 The bonds should be buried and be installed so as to minimise risk of theft. If the bonds run  
1780 under an independently earthed fence they must be insulated for a 2 metre distance on either  
1781 side of the fence.

1782 If the tower legs are located within 2 m of an independently earthed metal fence then the  
1783 section of fence adjacent to the tower should be bonded to the tower and electrically isolated  
1784 from the rest of the fence. Alternatively the relevant metal fence panels may be replaced by  
1785 insulated panels, or suitable insulating coating applied (ref: 4.4.3 and 6.6). If this is not  
1786 practicable a risk assessment should be carried out (section 5.8).

1787 **6.8.2 Steel Tower Termination with Cable Sealing Ends**

1788 Where an aerial earth wire terminates on a tower with a sealing end platform or an associated  
1789 cable sealing-end compound that is well outside the substation, continuity between the base  
1790 of the tower and the main earthing system will be provided by either the sheaths of the power  
1791 cables or by an earth continuity conductor laid and installed in accordance with ENA EREC  
1792 C55.

1793 **6.8.3 Terminal Poles with Stays Adjacent to Substation Fence**

1794 Stay wires that are external to the site and more than 2 m from the fence or earthed metalwork  
1795 may be left un-earthed, if this is in accordance with normal practice. They should be earthed  
1796 within the substation compound where possible to minimise risk from current leakage across  
1797 the stay insulator.

1798 Earthed stay wires can present a touch potential risk if the stay is in very close proximity to an  
1799 independently earthed fence, and may form an inadvertent connection between the  
1800 independently earthed fence and the main earth grid. To address this, in addition to installing  
1801 the normal upper stay insulator a second stay insulator should be installed as close to ground  
1802 level as possible leaving the centre section of the stay unearthed. 2 m segregation must be  
1803 achieved between the lower earthed section of the stay including the rod and the fence.

1804 Unless the earthed stay rod is inside the earth grid, a loop of buried electrode should be laid  
1805 around the rod at a 1m radius, and bonded to the rod/main earthing system to control touch  
1806 potential.

1807 **6.8.4 Down drop Anchorage Arrangement with Arcing Horns**

1808 Where it is necessary to have an assembly of ferrous fittings such as turn buckles, links,  
1809 shackles etc. between the insulators and an earthed structure or ground anchor point,  
1810 precautions may be required if the earth fault current is very large.

1811 The earthed end arc-ring (or horn) anchorage arrangement may be attached to the main earth  
1812 connection by means of a flexible copper shunt, in order to limit earth fault current flowing  
1813 through the discontinuous ferrous fittings. This prevents mechanical damage due to arcing.

#### 1814 **6.8.5 Loss of Aerial Earth Wires**

1815 If alterations are carried out to overhead lines which break an otherwise continuous aerial earth  
1816 wire between substation sites, consideration must be given to the increase in ground return  
1817 current and consequent increase in EPR which arises.

1818 There may also be a further increase in EPR due to reduction of the chain impedance  
1819 contribution. It may be necessary to consider the installation of an overhead or buried earth  
1820 conductor to provide continuity of the aerial earth wire.

#### 1821 **6.9 HV Cable Metallic Sheath / Armour Earthing**

1822 This section covers all HV power cables contained within or entering HV substations but  
1823 excludes those HV cables which feed HV/LV transformers located in the substation where the  
1824 LV supply is exclusively for use in the substation. The requirements for these latter cables are  
1825 dealt with under Section 9.

##### 1826 **6.9.1 Insulated (Polymeric) Sheath Cables**

1827 The metallic sheath/armour of cables can, due to their inductive coupling properties, provide a  
1828 very low impedance return path for earth fault current flowing in the cable phase conductors.  
1829 This can greatly reduce the current that returns to source though the ground and subject to the  
1830 sheath being continuous significantly reduce the EPR at associated terminal substations.

1831 To achieve this, the sheath/armour must be earthed at least at both ends. This arrangement  
1832 of earthing is generally satisfactory for three-core and TRIPLEX type high voltage cables  
1833 forming part of general distribution system circuits.

1834 Simply bonding sheaths/armours at both ends of single-core cables or very heavily loaded  
1835 circuits such as transformer interplant cables can cause de-rating as large steady-state  
1836 currents may flow in the sheath/armours, causing additional heating and risking damage.

1837 Consequently two methods of installation have been developed for single-core cables where  
1838 the length is sufficient to cause this problem.

1839 a) Single Point Bonding – where the sheaths are connected to earth at one point. A parallel  
1840 Earth Continuity Conductor may be laid with the cables to provide continuity between items  
1841 of plant.

1842 b) Cross bonding – where the sheaths are connected to earth at each end, and periodically  
1843 transposed to cancel circulating currents flowing in the sheaths.

1844 Single-point bonding preserves the rating of the cables, but permits a voltage to develop  
1845 between the sheaths/armours and earth at the unearthed ends of the cables which could, on  
1846 long cable runs, require shrouding or other measures to ensure safety.

1847 Cross-bonding provides a return path for earth fault current in the sheaths without permitting  
1848 significant steady-state de-rating current to flow or exceeding the sheath voltage rise limit. Care  
1849 is needed at link boxes/transposition points.

1850 Both methods, together with their merits and disadvantages are described in detail in ENA  
1851 EREC C55 “Insulated Sheath Power Cable Systems”, together with solutions to the problems  
1852 described above. A bespoke cable and earthing / bonding design is usually required for very  
1853 heavily loaded circuits (e.g. interplant cables) or circuits operating above 33 kV.

**Commented [RW13]:** To distinguish from earlier reference to sheath breaks which also relates to pilot cables and comms

1854 Methods for calculating the sheath return current and resulting ground return current (for  
1855 systems with sheaths earthed at both ends) are given in **ENA EREC S34**.

#### 1856 **6.9.2 Cables Entering Substations**

1857 The sheath/armour at the substation end of the cable should be earthed to the substation  
1858 earthing system.

1859 TRIPLEX, three-core, and fully cross-bonded cables will, in addition, be earthed at their remote  
1860 ends. This provides both a conductive and inductive path for fault current. With cross-bonded  
1861 single-core cables, it is the usual practice to install further additional sheath earths along the  
1862 route of the cable. The additional sheath earths will normally produce an insignificant benefit,  
1863 and can be ignored in the assessment of the substation earth resistance.

#### 1864 **6.9.3 Cables Within Substations**

1865 Three-core cables will have their sheath/armour earthed at both ends.

1866 Single-core cables will usually be short enough to allow single-point sheath/armour earthing,  
1867 without causing serious sheath voltage rise problems. The single sheath/armour bond to earth  
1868 should be located where personnel are most frequently present, for example at switchgear.  
1869 Screens should be shrouded at the unearthed end. An earth continuity conductor may be  
1870 required. Refer to ENA EREC C55 for further details.

1871 For the higher voltage systems, sheath voltage limiting devices (SVLs) may be installed  
1872 between the sheath and earth at the unearthed end of the cable to protect the integrity of the  
1873 sheath and its terminating point insulation against transient voltage surges on the sheath.

#### 1874 **6.9.4 Outdoor Cable Sealing-Ends**

1875 Where cables terminate at outdoor sealing-ends, pedestal-type insulators are fitted to insulate  
1876 the sealing-end base and gland from its support structure. If sheath earthing is made at this  
1877 location special earthing bonds are required in accordance with ENA TS 09-15 or EREC C55  
1878 as appropriate.

1879 When the standing sheath-voltage at a termination can exceed 10 volts to earth, the base  
1880 metalwork of the sealing-end shall be screened against accidental contact by means of an  
1881 insulating shroud of the type illustrated in EREC C55.

1882 Sealing-end support insulators should be used only for short single-core cable tails with an  
1883 earth bond made at the trifurcating point of any three-core cable.

#### 1884 **6.9.5 Use of Disconnected, Non-Insulated Sheath/Armour Cables as an Electrode**

1885 Metallic sheathed/armoured hessian served cables are often decommissioned or replaced with  
1886 insulated sheath cables. Where these are laid direct in soil, they can provide a valuable  
1887 electrode contribution. Where practicable (particularly if the buried length exceeds 200 m)  
1888 these redundant cables should be retained as earth electrodes to maintain their contribution  
1889 towards lowering overall substation earth resistance and EPR.

1890 If such sections are retained, the phase conductors and sheaths/armours of these cables, once  
1891 disconnected should be joined together to maintain their contribution to the electrode system.  
1892 The start ends should ideally be connected to the earth grid via test chambers to permit  
1893 continuity or resistance measurements. The remote ends should, if practicable, be connected  
1894 to the electrode system at a joint or distribution substation. Cable and earthing records should  
1895 be annotated to show such cables are being used as substation earth electrode.

1896 Constant-force springs (CFS) or plumbed joints may be appropriate for connecting stranded  
1897 copper conductor to lead sheathed cables; other types of connection may loosen in service as

1898 the lead continues to flow or 'creep' under contact pressure. In any case moisture should be  
1899 excluded from such joints using heat shrink boots or similar. Manufacturer's guidance should  
1900 be sought if connecting to sheaths of other cable types.

#### 1901 **6.10 Light-current Equipment Associated with External Cabling**

1902 All exposed conductive parts of light current equipment shall be earthed to the main earthing  
1903 system as required. Where pilot or communication cables operate between two remote points  
1904 and the rise of earth potential at each end of the circuit does not exceed the appropriate ITU-  
1905 T limit, any required circuit earth may be made at either end. If the rise of earth potential at  
1906 either end exceeds the appropriate ITU-T limit, then protective measures shall be applied to  
1907 those circuits. Refer to ENA EREC S36, and sections 4.3.7 and 6.9.3.

#### 1908 **6.11 Metal Clad and Gas Insulated (GIS) Substations**

##### 1909 **6.11.1 Metal Clad Substations**

1910 Metal clad substations will normally be erected on a concrete raft. The provisions for an earth  
1911 electrode system in these circumstances will be similar to those described under item 9.3.1.  
1912 Where touch potential is an issue consideration should be given to using an enclosure made  
1913 of insulating material and to using surface-laid earth mat/grating.

##### 1914 **6.11.2 Gas Insulated Switchgear (GIS)**

1915 Gas Insulated Switchgear (GIS) employing single-phase busbar enclosures require additional  
1916 earthing precautions incorporated into the design of the substation earthing system.

1917 Due to close coupling with individual phase conductors busbar enclosures can experience high  
1918 levels of induction. Steelwork used to support the enclosures and adjoining items of plant may  
1919 form closed paths in which induced inter-phase and earth currents flow under both steady-  
1920 state and fault conditions. These currents can be undesirably high and may approach the  
1921 phase conductor current. The flow of circulating current renders secondary wiring more  
1922 vulnerable to inductive interference.

1923 A further issue with GIS is the creation of surge voltages on the enclosures and associated  
1924 steelwork during switching or other transient/high frequency system disturbances.

1925 To help minimise the above effects it is recommended that an earth grid, well integrated and  
1926 with locally enhanced electrode (e.g. increased mesh density and vertical rods) in the regions  
1927 close to the plant, be laid over the raft from which short spur connections can then be taken to  
1928 the specific earthing points on the equipment. Typical arrangements are described in CIGRE  
1929 Paper 044/151 - "Earthing of GIS – An Application Guide", issued by Working Group 23.10  
1930 (December 1993).

1931 To retain current in the busbar enclosures, short circuit bonds, together with a connection to  
1932 the earthing system, should be made between the phase enclosures at all line, cable and  
1933 transformer terminations, at busbar terminations and, for long busbar runs, at approximately  
1934 20 metre intervals. Switchboards > 20 m long will require intermediate connections. Except  
1935 where adjacent enclosures are insulated from each other the interface flanges of the  
1936 enclosures should have bonds across them and the integrity of bolted joints of all bonds should  
1937 be checked.

1938 As a guide the resistance of the bonded flanges should not exceed 5 micro-ohm. At insulated  
1939 flanges consideration should be given to the installation of non-linear resistive devices to  
1940 prevent transient flash-over.

1941 **6.12 Fault Throwing Switches, Earth Switches and Disconnectors**

1942 **6.12.1 Background**

1943 Fault throwing switches, earth switches and disconnectors are normally mounted on steel,  
 1944 aluminium, steel reinforced concrete or wood pole structures.

1945 Metallic structures may be of electrically continuous all welded construction or assembled  
 1946 using several large pre welded sections or individual bolted members. In some cases though  
 1947 the structure is of bolted construction there may be a continuous metallic section from ground  
 1948 to equipment level. Where there is more than one metallic section in series in a fault current  
 1949 path continuity between sections needs to be considered.

1950 Where steel or aluminium support structures are used to support isolators and / or earth  
 1951 switches it is desirable to use the structure itself to carry earth fault current in order to reduce  
 1952 the need for above ground earth conductors with consequent risk of theft. This arrangement is  
 1953 only acceptable where the metallic structure can provide a reliable earth connection with  
 1954 adequate current carrying capacity.

1955 NOTE: Some Network Operators may not use support structures in lieu a dedicated earthing conductor. See also  
 1956 6.2.6

1957 When installing earth connections to **fault throwing switches**, earth switches and isolators the  
 1958 design will take in to account the magnitude and duration of the prospective earth fault currents  
 1959 involved. **Fault throwing switches shall have a dedicated earth connection, see 6.12.2.**

1960 The main earth connection to these devices carries earth fault current under the following  
 1961 conditions:

1962 **Table 10 – Conditions for the passage of earth fault current**

Device	Condition For Passage of Earth Fault Current
Fault Throwing Switch	By design when protection operates
Earth Switch	When there is an equipment failure or switching error. May also carry lightning induced current when closed.
Isolator	When the isolator or its connections fault, or when the isolator is used in a sacrificial mode if main protection fails.

1963  
 1964 The main options for earthing **fault throwers**, earth switches and isolators are to use either:

- 1965 • a fully rated earth conductor, fixed to the structure. This method is most applicable to higher  
 1966 fault current applications (e.g. systems operating at 90kV and above) or where the support  
 1967 structure cannot provide an adequate earth fault current path. See Table 5 and Table 6 for  
 1968 conductor ratings;
- 1969 • alternatively a metallic structure may be used to conduct earth fault current from the top of  
 1970 the structure equipment to the grid. This is subject to the structure having sufficient current  
 1971 carrying capability and being electrically continuous. The method is more applicable to  
 1972 lower fault current applications (e.g. 33 kV systems) which use welded or continuous  
 1973 metallic structures.

1974 The following earthing arrangements apply to fault throwing switches, earth switches and  
 1975 isolators located within secured substation sites fitted with earth grids.

**Commented [RW14]:** Delete this? It's described in next few paragraphs anyway. But the advice on fault throwers is contradictory. Use the structure or not?

1976 Different arrangements (e.g. insulated down-leads) may be required for equipment located  
1977 outside substations in areas accessible to the public.

#### 1978 **6.12.2 Fault Throwing Switches (Phase - Earth)**

1979 A direct earth connection shall be made from the switch earth contact to the main earth grid  
1980 using a conductor fixed to the structure.

#### 1981 **6.12.3 Earth Switches**

1982 Connections from earth switches to the main earth grid may be made by either:

1983 a) An earth conductor, fixed to the structure or:

1984 b) By using the metallic support structure as a conductor subject to the aluminium or steel  
1985 structure having sufficient current carrying capability and being electrically continuous.

#### 1986 **6.12.4 Isolators**

1987 Connections from isolator support metalwork to the main earth grid may be made by either:

1988 a) A fully rated earth conductor, fixed to the structure or:

1989 b) By using the metallic support structure as a conductor subject to the aluminium or steel  
1990 structure having sufficient current carrying capability and being electrically continuous.

### 1991 **6.13 Operating Handles, Mechanisms and Control Kiosks**

#### 1992 **6.13.1 Background**

1993 Earthing arrangements for operating handles of isolators, circuit breakers, earth and fault  
1994 throwing switches must provide touch and step potential control for the operator.

1995 These are critical locations which require careful consideration and sound construction.

1996 A full earth grid may not always be present at some older sites and additional precautions may  
1997 be required when operational work and/or minor alterations are being carried out to ensure  
1998 safe touch and step potentials. Generally, with exceptions outlined below, stance earths shall  
1999 be provided at all locations where operators may stand to operate high voltage equipment  
2000 handles, mechanisms and control equipment.

#### 2001 **6.13.2 Earth Mats (Stance Earths)**

2002 New installations will have touch and step potential control provided by a purpose designed  
2003 earth grid. If it can be demonstrated that such measures are adequate to ensure operator  
2004 safety, and if a network operator's operational policy allows, an additional stance earth may  
2005 not be required. In making this assessment, the likelihood of deterioration due to theft or  
2006 corrosion should be considered. Portable or visible (surface laid) stance earths may be  
2007 required in addition to any buried grading electrode as a risk reduction measure.

2008 NOTE: Surface-laid earth mats are preferred over buried earth mats; they give much better touch control and their  
2009 presence can readily be checked. The size and position of the mat must match the operator stance position(s) for  
2010 the given equipment. Galvanised steel grating earth mats can be readily extended to cover the operator path  
2011 followed with horizontal operation handles. Buried earth mats may be a suitable alternative to surface-laid earth  
2012 mats where the resulting touch voltage is sufficiently low.

#### 2013 **6.13.3 Connection of Handles to the Earth Grid and Stance Earths**

2014 The earth connection from the handle to the grid shall always be separate to that for the switch  
2015 metalwork and be as short as possible.

2016 The earth connection shall use standard copper conductor connected direct to the main  
2017 substation earth.

2018 In some cases an insulated insert may be fitted between the operating handle and the switch  
2019 metalwork to help prevent any fault current flowing down the handle and mechanism into the  
2020 earth grid.

2021 Refer also to Section 10.6 (Earthed Operating Mechanisms Accessible From Ground Level).

#### 2022 **6.14 Surge Arrestors and CVTs**

2023 Plant including surge arresters and CVTs (Capacitor Voltage Transformers), which are  
2024 connected between line and earth, present relatively low impedance to steep-fronted surges  
2025 and permit high-frequency currents to flow through them to earth.

2026 Unless a low impedance earth connection is provided, the effectiveness of the arrester could  
2027 be impaired and high transient potentials appear on the earthing connections local to the  
2028 equipment. The following installation earthing arrangements are recommended:

2029 Two connections to earth are required for both surge arresters and capacitive voltage  
2030 transformers (CVTs):

2031 • The first connection (for power frequency earthing) will use the structure to the main  
2032 substation earth grid.

2033 • The second (high frequency) connection should be direct to an earth rod, installed  
2034 vertically in the ground as near to the surge arrester base as possible, with a tee  
2035 connection to the support structure if metal. High frequency earth rods shall be driven  
2036 vertically into the ground to a depth of approximately 4.8m. Where this is not achievable,  
2037 a high density earth mesh arrangement or four (or more) long horizontally buried  
2038 conductors (nominally 10m in length, minimum depth 600mm) dispersed at 90° (or less,  
2039 equally spaced across the full 360°) may be used in place of the rod. Calculations must  
2040 be provided to demonstrate that any proposal is equivalent to the 4.8m long earth rods.  
2041 The high frequency connection shall be made to the centre of the alternative HF earthing  
2042 designs. Dedicated earth mats or similar may be considered in difficult circumstances.

2043 Refer to BS EN 62305 (Lightning Protection Standard) and BS EN 62561-2 (Lightning  
2044 Protection System Components – requirements for conductors and earth electrodes), or ENA  
2045 ER 134 for more information.

2046 The benefit of surge arresters over arc gaps is greatest when the resistance to earth is less  
2047 than 20 Ohms. When a surge arrester is provided at a cable termination, the earth side of the  
2048 arrester should be connected to the cable crucifix and thereby to the cable sheath. Surge  
2049 arresters should be sited as close as practical to the terminals of the plant, (e.g. transformer  
2050 bushings or cable sealing ends) which they are protecting.

2051 The support structure and plinth will be designed to allow the high frequency earth connection  
2052 to either pass through its centre, or through an angled slot to ensure that the connection is as  
2053 short and straight as possible. This will aid performance and deter theft. It is particularly  
2054 important to avoid sharp bends. This connection must not be enclosed within a steel support  
2055 tube or box.

2056 Fully rated conductors must be used for both high frequency and power frequency  
2057 connections. High frequency downleads should be insulated from the support structure  
2058 (except where bonded to the structure at low level) to accommodate surge counters, and also  
2059 to facilitate testing of the electrode with a clamp meter (Section 7.6.2(b)).

2060

**Commented [RW15]:** This text from Fraser, replaces: If a rod is not possible, several 2 m spur electrodes can be taken out from the injection point at 600 mm depth and spaced about 60 degrees apart. Dedicated earth mats or similar may be considered in difficult circumstances.

**Commented [RW16]:** Section 6.6 Surge Arresters "Surge Arresters should always be connected as close as practicable to the apparatus and the earth side fixed to or connected to the frame of the apparatus. Surge arresters should be positioned directly across the cable/sheath or transformer HV winding and tank.

**Commented [RW17]:** This para is from ER 134 and could be omitted?

2061 **7 Measurements**

2062 **7.1 General**

2063 This section describes some of the most common measurements which may be required  
2064 during the design, commissioning or maintenance of an earthing system at an electrical  
2065 installation. An overview of the important measurement and interpretation methods is provided  
2066 together with some guidance on avoiding sources of error. More detailed guidance and method  
2067 statements would be expected to be available in company manuals and operational  
2068 documentation.

2069 **7.2 Safety**

2070 The earthing related measurements described in this section are potentially hazardous. They  
2071 must be carried out by competent staff using safe procedures following a thorough assessment  
2072 of the risks. The risk assessment should include, but not be limited to, consideration of the  
2073 following aspects and the necessary control measures implemented, e.g. personal protective  
2074 equipment, special procedures or other operational controls.

- 2075 a) Potential differences that may occur during earth fault conditions between the  
2076 substation earthing system and test leads connected to remote test probes.  
2077 The likelihood of an earth fault occurring should be part of this assessment,  
2078 e.g. not allowing testing to proceed during lightning conditions or planned  
2079 switching operations.
- 2080 b) Potential differences that may occur between different earthing systems or  
2081 different parts of the same earthing system. In particular, approved safe  
2082 methods must be used when disconnecting earth electrodes for testing and  
2083 making or breaking any connections to earth conductors which have not been  
2084 proven to be effectively connected to earth\*.
- 2085 c) Potential differences occurring as a result of induced voltage across test leads  
2086 which are in parallel with a high-voltage overhead line or underground cable.
- 2087 d) Environmental hazards of working in a live substation or a construction site as  
2088 governed by the electricity company safety rules or the CDM regulations as  
2089 applicable.
- 2090 e) Injury when running out test leads for large distances in surrounding land.

2091  
2092 \* NOTE: Disconnection from earth can cause voltage differences to arise in the case of the path from tower line-  
2093 earthing system due to induction; as it is related to current in the tower line, and therefore present continuously, it  
2094 represents a particularly serious hazard.

2095

2096 **7.3 Instrumentation and Equipment**

2097 It is imperative that measurements are taken using the most suitable instrumentation for the  
2098 required task which is in good working order and has a valid calibration certificate. The  
2099 instrumentation will be used for field measurements in all weather conditions. It must therefore  
2100 be robust, have a sufficient level of water resistance and be suitably protected from electrical  
2101 transients (e.g. by fuses) and shielded for use in high-voltage installations. Further advice on  
2102 this may be sought from a reputable instrument manufacturer.

2103 Instruments shall be calibrated regularly (e.g. annually) to a traceable national standard.  
2104 Heavily used instruments should be checked more frequently, e.g. against other calibrated  
2105 instruments or standard resistors, between formal calibration periods. Instruments must be

2106 periodically serviced/safety tested and any identified damage or faults must be rectified before  
2107 re-use.

2108 Many of the measurements require ancillary equipment such as test leads, earth rods,  
2109 connection clamps, etc. and it is equally important that these are also fit-for-purpose and well-  
2110 maintained.

## 2111 **7.4 Soil Resistivity Measurements**

### 2112 **7.4.1 Objective**

2113 Site specific measurements are required to determine the resistivity of the materials (soil, rock,  
2114 etc.) that make up the ground where an earth electrode is installed. The results obtained can  
2115 be interpreted to provide a uniform equivalent resistivity for use in standard design equations  
2116 (EREC S34) or a multi-layer soil model, which can be used in commercially available computer  
2117 simulation tools. Important design parameters such as the earth resistance and EPR are  
2118 strongly dependent on the soil resistivity so it is essential for the accuracy of the design that  
2119 proper attention is given to these measurements and their interpretation as early as possible  
2120 in the design process.

### 2121 **7.4.2 Wenner Method**

2122 A four-terminal earth tester is used for these measurements. There are a number of available  
2123 measurement techniques which involve passing current through an array of small probes  
2124 inserted into the surface of the soil and measuring the resulting potentials at specified points.  
2125 Using Ohm's law a resistance can be calculated which may be related to the apparent  
2126 resistivity at a particular depth using suitable formulae. Varying the positions of the probes,  
2127 and hence forcing the current to flow along different paths, allows the apparent resistivity at  
2128 different depths to be measured. The most commonly used arrangement for earthing purposes  
2129 is the Wenner Array (Dr Frank Wenner, UK Bureau of Standards – now NIST) and this is  
2130 described in more detail in BS EN 50522 UK National Annex C.

2131 NOTE: There are variations on the Wenner Array method using uneven electrode spacings that can be used and  
2132 these include the Schlumberger Array method and the General Array method.

2133 For large substations it is important to take measurements at a number of different locations  
2134 around the site so that an average may be used. In urban areas meaningful measurements  
2135 may only be obtained from the nearest parks or open ground and so results from several  
2136 locations around the substation are essential.

### 2137 **7.4.3 Interpretation of Results**

2138 It is difficult to interpret measurement results by inspection other than for a uniform or two-layer  
2139 soil model. Formulae for interpretation of data for soils with three or more layers are  
2140 cumbersome and practically requires the use of software. There are a number of suitable  
2141 software tools available commercially. Because most of these are based on a curve-fitting  
2142 approach, geo-technical information such as borehole records are useful to reduce uncertainty  
2143 in the soil resistivity model by indicating layer boundary depths, materials, water table height,  
2144 bedrock depth, etc. and should be used where available.

2145 Knowledge of the soil resistivity at different depths is important when designing the most  
2146 effective electrode to reduce the substation earth resistance. For example, vertical rods are  
2147 better suited to a soil with a high resistivity surface layer and low resistivity material beneath.  
2148 Conversely, where there is low resistivity material at the surface with underlying rock then  
2149 extended horizontal electrodes will be more effective.

### 2150 **7.4.4 Sources of Error**

2151 There are a number of sources of measurement error which must be considered when planning  
2152 and carrying out these measurements. These include, but are not limited to:

- 2153 (a) influence of buried metallic structures such as bare cable armouring/sheaths, earth  
2154 electrodes, pipes, etc. Measurements taken above or near buried metallic services will  
2155 indicate lower resistivity values than actually exists. This can lead to under-designed  
2156 earthing systems which may be costly to rectify at the commissioning stage.  
2157 Measurement locations must be carefully planned to avoid interference from metallic  
2158 structures by consulting service records and, where there remains uncertainty, the use  
2159 of scanning methods on site. It is also important that measurements are taken at a  
2160 number of different locations (minimum of two) around the site of interest so that any  
2161 influenced results become apparent in comparison to unaffected results. Two  
2162 orthogonal sets of measurements can also help to indicate an error;
- 2163 (b) interference from stray voltages in the soil or induction from nearby electrical systems  
2164 may adversely affect measurement results, normally evident as an unstable reading on  
2165 the instrument or unexpectedly high readings. This may be reduced by avoiding test  
2166 leads running in parallel with high voltage power lines/cables or near other potential  
2167 sources of interference, e.g. electric traction systems.
- 2168 (c) the wenner spacings used must be appropriate for the size of the earthing system and  
2169 recommended spacings are provided in BS EN 50522 National Annex C. Spacings that  
2170 are too short may not identify the lower layer resistivities which can introduce large  
2171 positive or negative error into design calculations;
- 2172 (d) low resistivity soils, especially at long wenner spacings, require relatively small  
2173 resistances to be measured at the surface. Instrumentation with an inadequate lower  
2174 range may reach its limit and incorrectly indicate higher resistivity values than exist;
- 2175 (e) care must be taken in interpreting the measurement data. If using computer software  
2176 tools, it should be remembered that the result is a 'model' of the soil conditions which  
2177 is largely determined by automatic curve-fitting routines or user judgement. To increase  
2178 confidence it is good practice to 'test' the model by comparing it to other geological  
2179 data available for the site and the expected range of resistivity values for the materials  
2180 known to be present. Measured resistances of vertical rods installed at the site can also  
2181 be compared to calculated values obtained using the soil model to increase confidence.  
2182 It should be recognised that the soil resistivity model may need to be refined throughout  
2183 the project as more supporting information becomes available.

#### 2184 7.4.5 Driven Rod Method

2185 The driven rod method is an alternative to the Wenner Method which is particularly useful in  
2186 built-up urban areas where there is inadequate open land to run out test leads. This method  
2187 should be used with caution and measures must be taken to avoid the possibility of damage  
2188 to buried services, in particular HV cables. Where the absence of buried services cannot be  
2189 established, rods must not be driven. An earth rod is driven vertically into the ground and its  
2190 earth resistance measured as each section is installed using either of the methods from  
2191 Sections 12.5 and 12.6. Using a simple equation (for uniform soil equivalence – refer to ENA  
2192 **EREC S34**) or computer simulation (for multi-layer analysis) the soil resistivity may be deduced  
2193 from the measured rod resistance and its length in contact with the soil. This method can be  
2194 cost-effective as the rods can be used as part of the earthing installation. Where possible the  
2195 results from driven rods at a number of locations around the site should be used together with  
2196 any available Wenner Method data to improve confidence in the derived soil resistivity model.

### 2197 7.5 Earth Resistance/Impedance Measurements

#### 2198 7.5.1 Objective

2199 The substation earth resistance or impedance is normally measured where practicable on  
2200 commissioning of a new substation and subsequently at maintenance intervals. The

2201 measurement will include all earthing components connected at the time of the test and the  
2202 result represents the value which is normally multiplied by the ground return current to  
2203 determine the EPR. This method may also be used to measure the earth resistance or  
2204 impedance of individual electrodes, tower footings or tower line chain impedances. (Refer to  
2205 **ENA EREC S34** for details of chain impedance and relevant calculations).

#### 2206 **7.5.2 Method**

2207 The most commonly used method of measuring substation earth resistance or impedance is  
2208 the fall-of-potential method and this is described in BS EN 50522 UK National Annex C. It  
2209 requires temporary electrodes to be installed in the ground some distance from the substation  
2210 and connected back via trailing leads. A standard four-pole earth tester should be used (as  
2211 opposed to a three-pole tester – refer to 7.5.4(e) to inject a small test current into the earth  
2212 electrode and returned via a remote probe. A voltage gradient is set up around the electrode  
2213 and a second probe is used to measure this with respect to the electrode voltage rise. The  
2214 resistance is calculated and results are normally presented as a curve of resistance versus  
2215 distance from the substation along a particular route. Voltage measurements may be taken  
2216 along any route but traverses which are parallel or orthogonal to the current lead are most  
2217 commonly used and are more readily interpreted using standard methods.

2218 Most commercially available earth testers use a switched DC square wave signal. Where it is  
2219 possible to select a very low switching frequency (below 5 Hz) the measured values will  
2220 approach the DC resistance which will be accurate for small earth electrode systems in  
2221 medium to high soil resistivity. When higher switching frequencies are used (128 Hz is  
2222 common) inductive effects may be evident in the results. Where an appreciable inductive  
2223 component is expected and long parallel test leads are used it is advisable to use an AC  
2224 waveform, so that mutual coupling between the test lead may be subtracted and a true AC  
2225 impedance obtained. Because of the appreciable standing voltage commonly found on live  
2226 substation earth electrodes, AC test signals are normally selected to avoid the fundamental  
2227 and harmonic frequencies. For the most accurate results, measurements should be taken  
2228 using frequencies either side of the power frequency to allow interpolation. Additional guidance  
2229 may be found in IEEE 81 (add ref).

2230 It may not be possible to use the fall-of-potential method where no suitable routes exist for the  
2231 test lead / probe set up, e.g. in urban or industrial areas. Alternative methods must be used in  
2232 these locations as described in Section 7.6.

2233 The substation earth resistance or impedance can also be measured by injecting a current  
2234 from a generator connected to a remote substation earthing system via a de-energised power  
2235 line. The rise in electrode potential is then measured with respect to another remote earth  
2236 electrode such as a telecommunication circuit earth. This method is more costly in terms of  
2237 equipment resources and circuit outages; it is rarely used in the UK. Experience has shown  
2238 that care must be taken to ensure that there are no unwanted metallic paths between the  
2239 substation electrode and either of the reference electrodes as this will divert current and  
2240 introduce errors, unless the diverted current can be measured and a correction applied. This  
2241 is especially difficult to achieve in urban environments, otherwise this technique would be a  
2242 good option where no suitable area for a fall-of-potential measurement exist.

#### 2243 **7.5.3 Interpretation of Results**

2244 Earth resistance or impedance measurement results are normally in the form of a series of  
2245 points on a curve which must be interpreted using a mathematical rule or procedure. Care  
2246 must be taken in selecting a suitable method and their limitations must be understood. More  
2247 detail on the methods available is given in BS EN 50522 UK National Annex C.

2248 **7.5.4 Sources of Error**

2249 There are a number of sources of measurement error which must be considered when planning  
2250 and carrying out these measurements. These include, but are not limited to:

2251 (a) influence of buried metallic structures such as bare cable armouring/sheaths, earth  
2252 electrodes, pipes, etc. Measurements taken above or near buried metallic services will  
2253 generally underestimate the substation resistance. Measurement locations must be  
2254 carefully planned to avoid interference from metallic structures by consulting service  
2255 records and, where there remains uncertainty, the use of scanning methods on site.  
2256 Measurement results that have been influenced by a parallel buried metallic structure  
2257 will typically be lower than expected and the resistance curve will be flat. A metallic  
2258 structure crossing the measurement traverse at right-angles will result in a depression  
2259 in the resistance curve. If interference is suspected the measurement should be  
2260 repeated along a different route or an alternative method used;

2261 (b) the distance between the substation and the remote current probe is important to the  
2262 accuracy of the measurement. The theoretical recommended distance is between five  
2263 and ten times the maximum dimension of the earth electrode with the larger separations  
2264 required where there is underlying rock. In practice, where there is insufficient land to  
2265 achieve this, the current probe should be located as far away from the substation as  
2266 possible. Measurements taken using relatively short distances between the substation  
2267 and return electrode may not be accurately interpreted using standard methods and  
2268 require analysis using more advanced methods. Typical distances used range from  
2269 400 m for standard 33/11 kV Primary Substations up to 1000 m or greater for large  
2270 transmission substations or for large combined systems;

2271 (c) interference caused by standing voltage ('noise') on a substation earthing system may  
2272 result in standard earth testers failing to produce satisfactory results. This is normally  
2273 evident as fluctuating readings, reduced resolution or via a warning/error message.  
2274 Typical environments where this may be experienced include transmission substations  
2275 (275 kV and 400 kV), railway supply substations or substations supplying large  
2276 industrial processes such as arc furnaces or smelters;

2277 (d) results must be interpreted using an appropriate method and compared to calculations.  
2278 Where there is significant difference further investigation is required. Interpretation  
2279 using the 61.8% Rule or Slope Method may not be appropriate in all circumstances as  
2280 they are based on simple assumptions; Detailed analysis using computer software may  
2281 give greater accuracy where:

- 2282 • the soil resistivity is non-uniform, i.e. multi layered soils;
- 2283 • where the current return electrode is relatively near to the electrode under test,  
2284 e.g. less than five times the size of the earth electrode being tested;
- 2285 • for a large and irregular shaped electrode where the test is taken far away from  
2286 the centre of the electrode
- 2287 • where there are known nearby buried metallic objects that may have influenced  
2288 the measurements.

2289 (e) use of a three-pole earth tester is acceptable where the resistance of the single lead  
2290 connecting the instrument to the electrode is insignificant compared to the electrode  
2291 resistance. These instruments are generally suitable only for measuring small electrode  
2292 components such as rods or a small group of rods in medium to high resistivity soils.  
2293 For larger substations or low resistance electrodes a four-pole instrument is essential

2294 to eliminate the connecting lead resistances which would otherwise introduce a  
 2295 significant error.

2296 **7.6 Comparative Method of Measuring Earth Resistance**

2297 **7.6.1 Objective**


2298 To measure the earth resistance of small individual electrode components within a large  
 2299 interconnected earthing system. This method is most effective where a relatively high  
 2300 resistance electrode is measured in comparison to a 'reference earthing system' which has a  
 2301 much lower resistance.

2302 **7.6.2 Method**

2303 Two different approaches may be used as follows:

2304 (a) The first method, illustrated in Figure 12.1, requires that the electrode being tested is  
 2305 disconnected from the remainder of the substation earthing system, e.g. immediately after  
 2306 installation prior to the connection being made or via opening of a test link at existing sites.  
 2307 A standard four-pole earth tester may be used with terminals C1 and P1 connected to the  
 2308 electrode component being tested. Terminals C2 and P2 are connected to the 'reference  
 2309 earth'. Current is circulated around the earth loop containing the electrode and the  
 2310 reference earth resistances and the voltage developed across them is measured. Using  
 2311 Ohm's Law the series 'loop resistance' is calculated and if the reference earth resistance  
 2312 is sufficiently low relative to the electrode resistance the measured value will approach the  
 2313 electrode resistance.

2314 (b) The second method, illustrated in Figure 12.2 uses a similar principle but does not require  
 2315 disconnection of the electrode. A clamp type meter is placed around the connection to the  
 2316 electrode which generates and measures current and voltage in the electrode loop and  
 2317 displays the 'loop resistance'. The advantage of this method is that the earth electrodes  
 2318 may be tested without disconnection hence avoiding the associated safety risks and the  
 2319 need to apply earth disconnection procedures. This is the preferred method for safety and  
 2320 facilities should be included in the design to allow access to rods for testing with a clamp  
 2321 meter.  
 2322  
 2323



2324 **Figure 12.1 — Illustration of Earth Resistance Measurement using the Comparative Method and a Four-**  
 2325 **Pole Earth Tester (Test Electrode Disconnected).**

**Commented [PR18]:** Rob- I think the figure heading should be in Caption but 10pt instead of 9 (it's the same a figure headings but 1 pt. down and not centrally aligned) I think the title should be above with the figure reference below?

2324  
 2325

2326

2327

2328




Figure 12.2 Illustration of Earth Resistance Measurement using the Comparative Method and a Clamp Type Resistance Meter (Test Electrode Connected)

2336

### 2337 7.6.3 Interpretation of Results

2338 In order to accurately measure an electrode resistance via this method it is necessary to have  
2339 a very low reference earthing system resistance compared to the electrode resistance (10%  
2340 or lower is recommended). It is also necessary to have a reasonable physical separation  
2341 between the electrode and reference earth to reduce mutual coupling through the soil.

2342 If the reference earth resistance is too high the measured result will be significantly higher than  
2343 the Electrode resistance (if it is known it can be subtracted). If the electrode and reference  
2344 earths are too close together then a value lower than the electrode resistance may be  
2345 measured. These errors may be acceptable if the purpose of the measurement is a  
2346 maintenance check where it is only necessary to compare periodic readings with historical  
2347 results to identify unexpected increases, e.g. due to corrosion or theft.

2348 If several different electrodes can be tested with respect to the same reference earth more  
2349 detailed interpretation methods may be developed to increase confidence in the individual  
2350 electrode resistances and in some circumstances allow the reference earth resistance to be  
2351 deduced.

### 2352 7.6.4 Sources of Error

- 2353 (a) If the reference earth resistance is too high relative to the electrode resistance the  
2354 measured value may be significantly higher than the electrode resistance. An approximate  
2355 assessment of this may be made by comparing the physical area covered by the respective  
2356 earthing systems, e.g. a rod electrode measured with respect to a large substation earth  
2357 grid would be expected to provide a reasonable accurate resistance for the rod electrode.
- 2358 (b) Where the test electrode and reference earth are in close proximity to each other there will  
2359 be significant mutual coupling via the soil which may result in an apparently lower reading  
2360 than the true electrode resistance.
- 2361 (c) The electrode under test may be inadvertently in contact with the reference electrode below  
2362 ground level, or otherwise connected to it. The test current is then circulated around a loop  
2363 and does not represent the intended earth electrode resistance.
- 2364 (d) This method cannot be directly used to measure the overall substation earth resistance  
2365 which requires the use of the fall-of-potential method described in Section 12.6.
- 2366


2367 **7.7 Earth Connection Resistance Measurements (Equipment Bonding Tests)**

2368 **7.7.1 Objective**

2369 To measure the resistance between a plant item and the main substation earth electrode to  
2370 check bonding adequacy. This is essential during commissioning of a new substation to  
2371 confirm that each item of plant is effectively connected to the earth electrode system. It is also  
2372 useful as an on-going maintenance check and for operational procedures, e.g. post-theft  
2373 surveys.

2374 **7.7.2 Method**

2375 The procedure is based upon the principle of measuring the resistance between a set point (or  
2376 points) on the main electrode system and individual items of earthed equipment. A micro-  
2377 ohmmeter is used and the connection arrangement is illustrated in Figure 12.3. Measurements  
2378 can be taken from one central point (such as the switchgear earth bar) or, to avoid the use of  
2379 unduly long leads, once a point is confirmed as being adequately connected, it can be used  
2380 as a reference point for the next test and so on.



2381

2382 **Figure 12.3 Connections for Earth Bonding Conductor Resistance Measurements**

2383 To establish that a satisfactory connection exists between the grid and any exposed metalwork  
2384 it is necessary to measure in the micro-ohms or milli-ohms range. An injection current of at  
2385 least 100 mA is recommended.

2386 The probable path of the injected current must be considered and where the substation uses  
2387 a bus-zone protection scheme care must be taken to ensure that any test current does not  
2388 produce enough current to operate protection systems.

2389 Special procedures must be adopted when checking bonding between a substation earthing  
2390 electrode and a terminal transmission tower. If the bond is ineffective or missing a potential  
2391 difference may exist which may pose a shock hazard or damage to a test instrument. Normally  
2392 these methods will include checking current flow in the terminal tower legs prior to testing as  
2393 a higher proportion of current will flow in a leg with an effective connection to the substation.  
2394 This would be supplemented by voltage measurements using suitably insulated probes and  
2395 meters and buried electrode location techniques.

2396 **7.7.3 Interpretation of Results**

2397 The measured resistance between the two connection points will depend on the length, cross-  
2398 sectional area, material and number of earth conductors between them. Based on a maximum  
2399 distance of 50 m between connection points, a threshold value of 20 mΩ will provide a good  
2400 indication of when further investigation is required.

2401 **7.8 Earth Conductor Joint Resistance Measurements**


2402 **7.8.1 Objective**

2403 To measure the resistance across an earth conductor joint to check its electrical integrity. This  
2404 is normally performed for every joint created at a new substation prior to backfilling. It is also  
2405 carried out during periodic maintenance assessments.

2406 **7.8.2 Method**

2407 The method described uses a micro-ohmmeter to measure electrical resistance and is suitable  
2408 for bolted, compression, brazed and welded joints. It does not check the mechanical integrity  
2409 of welds or for voids inside a joint.

2410 Most micro-ohmmeters are supplied with standard leads with two sharp pins that can penetrate  
2411 through paint or surface corrosion to reach the metal underneath. The first set of leads is  
2412 connected to one side of the joint and the second set to the other as illustrated in Figure 12.4.  
2413 Ideally, the connectors should be no more than 25 mm either side of the joint. A suitable scale  
2414 must be selected on the instrument (normally a minimum current of 10 A is required to measure  
2415 in the micro-Ohm range) and an average value recorded after the test polarity has been  
2416 reversed.



2417

2418 **Figure 12.4 Connections for Earth Conductor Joint Resistance Measurements**

2419 Joints must also be mechanically robust and survive a firm tap with a steel hammer.

2420

2421 **7.8.3 Interpretation of Results**

2422 The measured resistance should not significantly exceed that of an equivalent length of  
2423 conductor without a joint. Joints which exceed this by more than 50% must be remade. Where  
2424 different sized tapes are involved, the threshold value used should be that of the smaller tape.

2425 At new installations it is recommended that a few sample joints are made under controlled  
2426 conditions (e.g. in a workshop), their resistance measured and the median of these values  
2427 used as the benchmark for all other similar joints made at the installation.

2428 **7.9 Earth Potential Measurements**

2429 **7.9.1 Objective**

2430 To measure Touch, Step and Transfer Voltages (e.g. 'Hot Zones') for comparison with  
2431 calculated values. These measurements may be required to confirm that the installed design  
2432 complies with the main safety limits (see Section 4.4). Advanced techniques and equipment  
2433 are required to perform these measurements at live substations and guidance on the different  
2434 methods available can be found in IEEE 81 (add ref).

2435 **7.9.2 Method**

2436 Earth potential measurements may be measured by injecting a current into the substation  
2437 electrode and returning through a remote electrode via a connecting conductor. The return  
2438 electrode may be another substation electrode connected via a de-energised power line or a  
2439 temporary test lead and set of probes. Providing the return electrode is located at a large  
2440 distance from the substation (relative to the size of the substation electrode) a potential profile  
2441 will be set up around the substation proportional to that which would exist during fault  
2442 conditions. The voltage between the substation electrode and different points on the surface  
2443 can then be measured and related to Touch Voltage. Step Voltage can also be determined  
2444 from measurements of the potential difference between points on the surface which are 1 m  
2445 apart. In both cases the actual touch voltage can be found by scaling in the ratio of the test  
2446 current and fault current.

2447 In a similar way, the potential gradients may be measured around the substation, for example  
2448 emanating out from each corner, and equipotential contours derived to provide Hot Zone  
2449 information. Measurements may also be carried out to determine the voltage transferred from  
2450 a substation electrode to a nearby metallic structure, e.g. a steel pipe or the earthing system  
2451 associated with a different electrical system.

2452 **7.9.3 Interpretation of Results**

2453 The measurement results must be interpreted by competent engineers and compared to  
2454 calculated values. It is recommended that a series of measurements are taken at a number of  
2455 locations around the substation where high touch or step voltages are expected (normally at  
2456 the corners or in areas where the electrode mesh is less dense). This will enable the trends in  
2457 the voltage gradients to be assessed to identify spurious data points. Where the return  
2458 electrode is not located sufficiently far away from the test electrode large errors may be  
2459 introduced. These errors may be corrected using a detailed computer model or by averaging  
2460 the measurements obtained using different current return electrode locations.

2461 **7.10 Earth Electrode Separation Test**

2462 **7.10.1 Objective**

2463 To assess the electrical separation of two electrodes in the soil by measurement, e.g.  
2464 segregated HV and LV electrodes at an 11 kV distribution substation or a substation earth  
2465 electrode and a separately earthed fence.

2466 **7.10.2 Method**

2467 This method requires that the earth resistances of the two electrodes ( $R_1$  and  $R_2$ ) have been  
2468 measured separately using the fall-of-potential method described in Section 12.5.

2469 Similar connections are then made as the bonding integrity checks (figure 12.3) and the 'earth  
2470 loop' resistance ( $R_3$ ) of the two electrodes via the ground is measured.

2471 **7.10.3 Interpretation of Results**

2472 If the two electrodes are separated by a large distance then the  $R_3$  will approach the series  
2473 resistance of  $R_1 + R_2$ . Lower measured values of  $R_3$  indicate a degree of conductive coupling  
2474 through the soil. Generally, for the purposes of checking satisfactory segregation of earth  
2475 electrodes the following test is used:  $R_3 > 0.9(R_1 + R_2)$ . Values lower than  $0.9(R_1 + R_2)$  may  
2476 indicate inadequate separation and further investigation is required (refer to Section 9.7.3).

2477 **7.11 Buried Earth Electrode Location**

2478 **7.11.1 Objective**

2479 At older substation sites, whilst an earthing system is in place, a record of its design may not  
2480 exist or may be out of date. An earthing record is desirable to ensure that the design is  
2481 satisfactory and to assist in the planning of new construction work. The record should include  
2482 the position of the electrode, its burial depth, material, size and installation method (e.g. above  
2483 ground, in ducts, or buried directly).

2484 Where existing electrode needs to be located within live substations, surface detection  
2485 methods are usually the lowest cost option.

2486 **7.11.2 Method**

2487 The most effective surface detection techniques, found by experience are documented below.  
2488 This includes commercially available low to medium frequency systems and Ground  
2489 Penetrating Radar (high frequency) systems. It should be noted that these methods are subject  
2490 to interference from other buried services and often need to be supplemented by trial  
2491 excavations.

2492 A low to medium frequency system comprises a transmitter and receiver, working at  
2493 frequencies from 50 Hz (detection of live mains cables) to nearly 100 kHz. The transmitter  
2494 injects a signal into the earthing system which is to be traced (the "target line"). As this signal  
2495 passes through the earth electrodes, it radiates an electric and magnetic field, one or both of  
2496 which can be detected and interpreted by coils in the receiver. Basic receivers simply emit an  
2497 audio tone as they are passed over the target line. More advanced receivers give information,  
2498 such as burial depth and test current magnitude. This feature can sometimes enable one to  
2499 distinguish between the target line and others which have erroneously picked up the  
2500 transmitter's signal through coupling.

2501 A ground penetrating radar system, used in conjunction with appropriate analysis software,  
2502 can also be used to produce a reasonable graphical image of structures below the surface.  
2503 Radar systems detect the dielectric contrast between a target and its surroundings and so are  
2504 well suited for detecting conductive, metallic electrodes against soil which is relatively resistive.  
2505 They are well suited to drained, high soil resistivity locations. The radar system is usually  
2506 guided over the trace area in a grid pattern, with detection results being stored for later analysis  
2507 by the computer.

2508 Where neither of the above methods are conclusive, e.g. in areas with a high density of buried  
2509 services, selected trial holes may be required.

2510

2511 **8 MAINTENANCE**

2512 **8.1 Introduction**

2513 Earthing systems shall be inspected, maintained and repaired so as to ensure they will operate  
2514 in the manner required on an ongoing basis.

2515 **8.1.1 Inspection**

2516 This falls into two main categories:

- 2517 (a) Visual Inspection
- 2518 (b) Detailed Physical Examination and Testing

2519 When setting inspection, testing and maintenance regimes for a substation consideration shall  
2520 be given to identifying and where necessary rectifying issues arising from:

- 2521 • physical deterioration and damage/theft;
- 2522 • inappropriate installation alterations or third party actions which prejudice the principal of  
2523 operation of the earthing system;
- 2524 • inappropriate installation / design;
- 2525 • changes to system operating regimes or construction which alter the magnitude, flow and  
2526 / or duration of earth fault current to values outside the original earthing system design  
2527 parameters;
- 2528 • magnitude of EPR and how close touch and step potentials are to safety limits.

2529 The frequency of inspection and testing should be set according to EPR, risk of theft, damage,  
2530 and deterioration. It may be revised from time to time if circumstances change.

2531 If an extraordinary event occurs (e.g. delayed fault clearance) then additional ad hoc inspection  
2532 and testing may be required

2533 **8.1.2 Maintenance and Repairs**

2534 When undertaking repairs or minor alterations to damaged earth conductor and buried  
2535 electrode the procedures adopted must take into account:

- 2536 • Broken conductors may operate at elevated voltages even when the rest of the  
2537 associated network is operating normally.
- 2538 • The possibility of transient or sustained system earths fault occurring while repairs are  
2539 being undertaken.

2540 Inspection, testing and maintenance work must be undertaken in accordance with company  
2541 operational and safety procedures. Where required risk assessments and method statements  
2542 will be prepared. Inspectors must wear company specified personal protective equipment and  
2543 only approach plant and equipment when it is safe to do so. See Sections 8.3 and 8.4 for  
2544 further issues.

2545

2546 **8.2 Types of Inspection**

2547 **8.2.1 Introduction**

2548 The main types of inspection may be summarised as:

- 2549 • a frequent basic visual inspection to check there is no visible damage, theft or obvious  
2550 impairment of the earthing system;
- 2551 • a less frequent and more detailed visual inspection to review the standard of construction  
2552 and condition as well as checking for damage, theft and impairment;
- 2553 • an infrequent more thorough visual inspection combined with testing, measurement and  
2554 analysis.

2555 For an open busbar substation typical areas to be inspected include earth connections  
2556 associated with:

- 2557 (i) aluminium, steel, concrete and wood structures;
- 2558 (ii) towers, earthed poles and above ground cable connections within or adjacent to  
2559 the substation site.
- 2560 (iii) isolator mechanisms, fault-throwing switches, earth switches and control kiosks  
2561 including associated surface and buried earth mats;
- 2562 (iv) transformers, reactors, VTs, CVTs, CTs, surge-arresters and arcing horns;
- 2563 (v) transformer neutral links and switches and associated connections to earth either  
2564 direct or via earthing resistors, reactors or earthing transformers;
- 2565 (vi) metallic Fencing and gates;
- 2566 (vii) indoor switchgear (if present) including connections to plant, cables, structural steel  
2567 work and earth bars.

2568

2569 **8.2.2 Frequent Visual Inspection**

2570 This can form part of a normal routine substation inspection procedure or be a part of the  
2571 procedures operation staff conduct when entering a substation. The objective is to frequently  
2572 and quickly check for visible damage, theft or obvious impairment of the earthing system.

2573 During routine visual inspections accessible earth connections associated with key items of  
2574 electrical plant in the substation should be checked. Procedures such as lifting trench covers  
2575 will normally be avoided unless the initial inspection gives cause for concern.

2576 **8.2.3 Infrequent Detailed Visual Inspection**

2577 Before commencing a detailed examination, the substation earthing records should be  
2578 checked to confirm they correspond to the actual layout. The inspector should be aware of the  
2579 fence earthing arrangement and whether it is independently earthed or bonded to the earth  
2580 grid or a mixture of both.

2581 The key items covered in the Frequent Inspection plus all other accessible connections to  
2582 plant, circuits and civil infrastructure should be inspected thoroughly. As well as condition, the  
2583 standard of construction should be reviewed against present practices and any inadequacies  
2584 reported. Checks for damage, theft and impairment of the earthing system should also be  
2585 carried out. Visual checks should be carried out on less accessible earthing conductors not

2586 covered in the Frequent Inspection such as those located under trench covers or located in  
2587 basements.

2588 The results of all inspections must be documented in accordance with company procedures.

2589 A pre-prepared check list for each site will assist consistent reporting and record keeping.

#### 2590 **8.2.4 Detailed Visual Inspection, Testing and Analysis**

2591 This consists of four related parts:

- 2592 • A thorough detailed visual inspection and review of the earth connections to all electrical  
2593 plant, circuits and civil infrastructure as per 8.2.3
- 2594 • Carrying out specific testing and measurement of the earthing installation as per 8.2.4.1
- 2595 • Selecting portions of the buried electrode system for examination via trial holes as per  
2596 8.2.4.2
- 2597 • Analysis and recording of results including review of EPR related issues as per 8.2.4.3
- 2598 •

##### 2599 8.2.4.1 Testing

2600 See Section 7 for specific measurement and analysis techniques.

2601 Testing may include:

- 2602 (i) Measurement of the overall substation earth resistance/impedance value;
- 2603 (ii) Measuring resistance of:
  - 2604 • Individual earth electrodes
  - 2605 • Rod and plate groups
  - 2606 • Fence earth rods
  - 2607 • Test electrodes (where fitted).
  - 2608 • Surge arrester, CVT and GIS high frequency earths;
- 2609 (iii) Measurement of soil resistivity;
- 2610 (iv) Resistance tests across a representative sample of important joints using a micro-  
2611 ohmmeter. The value should be recorded and compared with the values  
2612 recommended by the manufacturer, or taken for similar joints elsewhere. Any joint  
2613 where the resistance value is excessive will require to be broken down, cleaned  
2614 and remade, or replaced;
- 2615 (v) Confirmation of continuity between key items such as transformers, switchgear,  
2616 terminal tower(s) etc. and the main substation earth grid using a micro-ohmmeter.  
2617 This is especially important for items where corrosion, theft or damage is  
2618 considered to have prejudiced the integrity of the connection;
- 2619 (vi) Confirmation of continuity between adjacent site earthing systems;
- 2620 (vii) Confirmation of whether metallic fences are isolated from or bonded to the main  
2621 substation earth grid by carrying out a separation test;
- 2622 (viii) For substations fitted with frame leakage earth fault protection checking the integrity  
2623 of the segregation between earth zones by testing and/or visual inspection and also  
2624 testing across cable terminations where island glands are fitted;

**Commented [PR19]:** G0 - Sub divisions of lists should be in Roman numerals, consider changing main list to a, b, c and sub to i, ii etc.

- 2625 (ix) Measurement of Soil pH value;
- 2626 (x) Tracing of buried electrode if required to update the substation earthing drawing;
- 2627 (xi) Segregation tests and review of segregation between distribution substation HV
- 2628 and LV earths. (Refer to Sections 7.10 and 9.7);

#### 2629 8.2.4.2 Selected Excavation and Examination of Buried Earth Electrode

2630 Since the earth electrode system is largely buried, it is impracticable to carry out a detailed  
2631 examination of the whole installation. However, it cannot be assumed that the buried electrode  
2632 system, once installed will remain in good condition.

2633 Particularly where a substation site is associated with former industrial use such as a coal  
2634 power station or foundry which may have produced corrosive material used as landfill there is  
2635 enhanced risk of corrosion of buried copper conductor. A similar risk may also arise if material  
2636 from such sites is imported to construct a substation. It is recommended that representative  
2637 locations be chosen to excavate and expose the buried electrode, in order to check its  
2638 condition.

2639 These should include some below ground connections, e.g. an earth rod connection position,  
2640 or other locations where the electrode is jointed. Several connections from above ground plant  
2641 should be uncovered back to the connection to the buried earth tape/grid, to check their  
2642 condition through the layers of chippings and soil. Conductor size should be compared with  
2643 records.

2644 Whilst carrying out excavation, the soil pH value should be checked. This should lie between  
2645 6.0 and 10.0. For pH values outside these limits, it is probable that corrosion of the copper  
2646 conductors/connectors will be evident. In the past, power station ash has been used as  
2647 bedding for earth electrodes. This is known to be acidic, and is likely to cause corrosion of the  
2648 conductors.

2649 Where tests show the pH value of the soil to be outside the limits, if the copper electrode is  
2650 corroded, then repairs or a new electrode system and either some imported soil or an inert  
2651 backfill (such as bentonite) is required. If the electrode has limited corrosion, then a soil /  
2652 corrosion investigation is necessary to assess the risk of future corrosion and any precautions  
2653 necessary. Normally the corrosion rate will be uneven, with severe corrosion in some areas  
2654 and none in others. Severely corroded electrodes will need to be replaced, whilst that  
2655 elsewhere will need to be monitored and measures taken to limit corrosion in all important  
2656 areas.

2657 Should examination of the exposed conductors or connections give cause for concern, then  
2658 additional excavations elsewhere on site may be necessary to assess the extent of the  
2659 problem.

#### 2660 8.2.4.3 Analysis and Recording of Test Results

2661 Resistance values for the substation, individual electrode groups and for joints should be  
2662 recorded and where previous values are available compared to indicate any trend.

2663 The earthing drawing should be updated if required with revised electrode sizes and positions.

2664 Once a new substation earth resistance is obtained it should be used to recalculate the  
2665 substation EPR using up to date earth fault current data and earth fault current return paths  
2666 (earth wires/cable sheaths etc). Safety voltages and conductor current ratings should be  
2667 recalculated and any deficiencies identified.

2668 The presence (or otherwise), values and configuration of any resistances / impedances placed  
2669 in high voltage transformer neutrals should be recorded and aligned with those contained in  
2670 the company power system model.

2671 Defects should be listed and prioritised for remedial action.

### 2672 **8.3 Maintenance and Repair of Earthing Systems**

2673 In some cases, earthing related maintenance and repair work will be reactive, following theft  
2674 or damage revealed by an inspection.

2675 Before undertaking earthing system repair or measurement work, the responsible person in  
2676 charge of the work must familiarise themselves with the site specific risks and consequences  
2677 of:

- 2678 • Working on or touching unsound earthing systems;
- 2679 • Open circuiting (even for a short time) earth conductor circuits;
- 2680 • Extending (even temporarily) earthing systems from sites where touch and step potentials  
2681 are controlled;
- 2682 • Working on broken earthing conductors;
- 2683 • An earth fault occurring on the system being worked on. For primary substations  
2684 supplying extended high voltage rural overhead line networks this can be a relatively  
2685 frequent occurrence (e.g. at least once a week). Supervisors should avoid work or testing  
2686 being carried out in high risk periods such as during storms or fault switching.

2687 There is risk of serious or fatal electric shock when working on intact and depleted/damaged  
2688 earthing systems. The responsible person in charge of any remedial work should be suitably  
2689 qualified to undertake this area of work. Network Operators should develop their own  
2690 policies/procedures for dealing with depleted earthing systems.

2691 Specialised equipment including insulated rods, shorting leads and conductor clamps are  
2692 required to make repairs. PPE including insulated footwear and gloves must be available if  
2693 required.

2694 High voltages can appear on earth system conductors even under normal running conditions.  
2695 Items requiring particular caution include connections associated with CVTs, transformer  
2696 neutrals, underground cable bonding arrangements and connections between main earth grids  
2697 and overhead line towers.

2698 Examples of situations requiring remedial work include:

- 2699 • broken or damaged below ground earthing conductors which have been exposed in the  
2700 course of excavation work;
  - 2701 • broken or damaged bonding conductors on underground cable systems (such as cross-  
2702 bonding connections that can be expected to carry significant current under normal  
2703 operating conditions);
  - 2704 • repairs to/replacement of high resistance earth connections (Para 8.4);
  - 2705 • minor alterations to/diversions of earthing systems for construction work;
  - 2706 • repairs after theft of earthing conductors (Remedial work on depleted earthing systems is  
2707 normally the subject of a bespoke company instruction and is outside the scope of this  
2708 document).
- 2709

2710 **8.4 Procedure for the Remaking Defective Joints or Repairing Conductor Breaks**

2711 **8.4.1 Introduction**

2712 It may be necessary to remake a joint or repair a break on the earth electrode system at a  
2713 substation for a number of reasons:

- 2714 (a) The joint is obviously damaged.
- 2715 (b) The joint has failed a micro-ohmmeter test.
- 2716 (c) An earth electrode has been severed.
- 2717 (d) A minor diversion of the electrode system or other repair work may be proposed.

2718 Should a fault occur during the period when a repair is being carried out, to prevent danger  
2719 from a high voltage, which could appear across the joint, precautions must be taken.

2720 The design of the earth grid (if present) may or may not be adequate to eliminate danger to  
2721 personnel when touching a bare broken conductor even after a temporary earth continuity  
2722 conductor has been applied.

2723 Before carrying out any repairs, the joint or break to be repaired must be short-circuited by  
2724 connecting a fully-rated conductor to positions either side of the break or defective joint. This  
2725 short must be applied using an approved procedure involving insulated rods.

2726 If company policy so states or any doubt exists the operator shall wear insulating footwear and  
2727 gloves designed for electrical application when handling earth conductor to make a permanent  
2728 repair.

2729 Whilst carrying out work, the operator should stand within the boundaries of the earth grid, or  
2730 immediately above a bare buried earth conductor.

2731 For example, if a terminal tower earth connection is broken, a significant potential difference  
2732 may be present between the tower and earth grid. Arcing and current flow will occur when  
2733 trying to remake the connection. Insulated rods and approved connectors are required to apply  
2734 the initial short-circuit. The repairs, as detailed in the next paragraph, can then be carried out.

2735 Similarly high voltages may appear across open circuited cross bonding conductors on high  
2736 voltage underground cable circuits.

2737 **8.4.2 Joint Repair Methods**

- 2738 (i) Compression Joint – Cannot be repaired, must be replaced.
- 2739 (ii) Mechanical Connector - Disconnect, clean all contact surfaces, apply a company  
2740 approved contact lubricant, reconnect and re-tighten.
- 2741 (iii) Cold-weld/Exothermic weld Joint - If defective this type of joint must be replaced.

2742 On completion of repair of any joint, having first connected the instrument across the joint, the  
2743 temporary earth continuity conductor\* should be removed; a micro-ohmmeter resistance test  
2744 must then be carried out across the joint.

2745 \* Shorting strap

2746 **8.4.3 Flexible Braids**

2747 Flexible bonding braids or laminations should be inspected for signs of fracture and corrosion  
2748 and changed as required. A protective compound may be applied to flexible braids where  
2749 corrosive conditions exist.

2750 **9 Ground Mounted Distribution Substation Earthing**

2751 **9.1 Introduction**

2752 Whilst the general principles of earthing can be applied to all voltage levels, small (distribution)  
2753 substations providing supply to LV networks can present their own additional challenges. The  
2754 key earthing related differences between distribution (or 'secondary') substations, and larger  
2755 ('primary', or 'grid' substations) include:

- 2756 • high voltage distribution apparatus is often located in densely populated areas in close  
2757 proximity to the public;
- 2758 • earth fault clearance times on distribution systems are usually longer;
- 2759 • many older 'legacy' installations do not have the benefit of a comprehensive earth grid  
2760 environment, as they rely on metallic sheath cable systems to control touch and step  
2761 potentials;
- 2762 • low-voltage earth connections may be combined with HV earthing systems, or in close  
2763 proximity to them;
- 2764 • connections from the low voltage distribution system are taken into almost every property;
- 2765 • for new connections distribution network operators have a legal obligation to provide a  
2766 low voltage earth terminal to their customers as long as it is safe to do so;
- 2767 • the low voltage system must be earthed such that earth potential rise due to high voltage  
2768 earth faults does not cause shock or injury (to installation users, public or staff) or  
2769 damage to internal electrical installations, distribution equipment or telecommunication  
2770 systems.

2771 The design issues, therefore, can be summarised as: a) achieving safety in and around the  
2772 HV:LV substation, and b) ensuring that danger does not arise on the LV system as a  
2773 consequence of HV faults.

2774 The design approach outlined in Section 5.1 applies equally to distribution substations, and  
2775 special considerations are described below.

2776 **9.2 Relocation of Pole Mounted Equipment to Ground Level**

2777 Due to the high EPR that can appear on pole mounted equipment, metallic items must not be  
2778 re-located at ground level (e.g. replacing a pole transformer with a small padmount substation)  
2779 without appropriate modifications to the earthing system.

2780 Ground mounted substations will introduce a touch potential risk that is absent from pole  
2781 mounted installations, and consequently require an electrode system that not only limits EPR,  
2782 but controls touch and step voltages to safe limits.

2783 Similarly, care should be exercised if other earthed equipment on the pole (e.g. auto-reclose  
2784 relay cabinet) is within reach of those on the ground.

2785 Section 10 describes pole mounted installations in detail. In either case, the decision to  
2786 operate with combined HV and LV, or otherwise, must consider the voltage that will be  
2787 impressed on the LV system under HV fault conditions (Section 9.5).

2788 **9.3 General design requirements**

2789 In common with any earthing system, the design of any new build substation must satisfy  
2790 requirements for EPR, touch/step voltages, transfer voltages, and stress voltages. If major

2791 changes are to be made to an existing substation, the effects of these proposed changes on  
2792 the existing earthing system need to be considered. A significant consideration in all cases is  
2793 the transfer potential that will be impressed on the LV network under HV fault conditions. See  
2794 9.5

### 2795 9.3.1 Design Data Requirements

2796 The data required is similar to that described in Section 5.5, as necessary to determine the  
2797 current flow into the electrode system, and the fault duration. These include:

- 2798 1) fault level at the new substation, or at the source (primary);
- 2799 2) resistance of the earthing system at the primary substation ( $R_a$ ), and at the new  
2800 distribution substation ( $R_b$ );
- 2801 3) circuit length and cable type(s);
- 2802 4) whether there is any overhead line in the circuit.

2803 For worst case studies, if there is any overhead line, the ground return current ( $I_{gr}$ ) can be  
2804 assumed equal to the earth fault current at the distribution substation (i.e.  $I_{gr}\% = 100\%$ ).

### 2805 9.3.2 Conductor and electrode sizing [New]

2806 Earth conductors at distribution substations will usually connect key items of plant such as  
2807 transformer(s), ring main unit / switchgear, and low voltage cabinets. In many 'unit substations'  
2808 these items may be supplied with bonding connections in place. These bonds must be sized  
2809 as described in 5.6.1; in general they must be sized for the maximum foreseeable earth fault  
2810 level. For ASC systems the limited ASC current must not be used. DNOs may wish to use the  
2811 earth fault level at the primary substation, or higher value allowing for growth and uncertainty,  
2812 up to the 3-phase fault current.

2813 Electrodes must have sufficient surface area to meet the requirements of Sections 5.5.4 and  
2814 5.6.2. The worst case foreseeable 'electrode current' should be used for design purposes, this  
2815 may be taken as the maximum earth-fault current at the substation or its source, or the larger  
2816 of cross-country fault current or bypass fault current on ASC systems.

2817 Note: If detailed modelling of current distribution is carried out, it will be seen that the 'ground return current', if  
2818 calculated using a contribution from a wide area network, will be significantly higher than the local 'electrode current'.  
2819 The electrode current or ground return currents may be used for electrode design purposes, providing that  
2820 connection to the wider network contribution is reliable. If any doubt exists as to the prolonged integrity of sheath  
2821 return paths and/or auxiliary electrode connections, the larger earth fault level (calculated for a zero ohm fault)  
2822 should be used.

### 2823 9.3.3 Target resistance

2824 A HV electrode system must be established for the substation, that is of sufficiently low  
2825 resistance to ensure reliable protection operation and to limit EPR (and touch/step voltages)  
2826 to acceptable levels. The design process in this respect is no different to that outlined in  
2827 Section 5.4. The resistance that must be achieved is termed the 'target resistance', and may  
2828 be specified with and without contribution from parallel systems. Use of a target resistance for  
2829 the substation's earthing system, which ensures compliance with the safety criteria, is useful  
2830 as it is a more readily understood parameter that can be achieved and tested by installers.  
2831 'Network contribution' is discussed in Section 9.4.3.

2832 For ground mounted substations, traditional custom and practice (permitted by previous  
2833 versions of this standard) was to apply a target resistance (before connection to the network)  
2834 of 1 ohm. If this could be achieved, it was permissible to combine the HV and LV earthing  
2835 systems. No perimeter or grading electrodes were installed in such 'legacy' systems, and often  
2836 only one vertical rod or horizontal electrode would be installed. This approach relied heavily

Commented [PR20]: All lists starting with a colon with incomplete sentences no full stops (except on the last line) or capitals.G0 pg.25

2837 on contributions from lead sheathed cables radiating away from the substation, and often  
2838 passing under the operator's position. In this way, these cables provided a degree of potential  
2839 grading (thus reducing touch potentials) as well as reducing the overall (combined) earth  
2840 resistance of the substation. Experience has shown that this approach is no longer applicable,  
2841 particularly given the now widespread use of polymeric (insulated sheath) cables.

2842 Network operators may find that different 'target values' for earth resistance are generally  
2843 applicable in different geographical areas, and for overhead or underground networks, and  
2844 thus may choose to adopt a 'rule of thumb' to assist designers and other connections providers.  
2845 In any case, calculations or measurements sufficient to demonstrate that the installed system  
2846 will be safe must be carried out at the design stage. Refer to 9.3.7.

2847 Target resistance values should consider all foreseeable running arrangements or network  
2848 configurations, especially if the network is automated or remote controlled. Refer to Section  
2849 9.9.

#### 2850 **9.3.4 EPR design limit**

2851 A natural EPR design limit is imposed by a) consideration of transfer voltage onto the LV  
2852 systems for combined HV/LV systems, and b) insulation withstand (stress voltage) between  
2853 the HV and LV systems for segregated systems. See section 9.5 for more detail regarding  
2854 separation distances. These considerations may for example, lead to typical design EPR limits  
2855 of 3 kV (or higher, depending on equipment withstand voltage) for segregated systems, and  
2856 466 V\* for combined systems.

#### 2857 **9.3.5 Calculation of EPR**

2858 The EPR for a distribution substation, for faults at that substation, is calculated in the  
2859 conventional manner, i.e. by multiplying the ground return current by the overall (combined)  
2860 substation earth resistance.

##### 2861 9.3.5.1 Factors to consider:

2862 The ground return current value is influenced by the earth fault current 'split' between the soil  
2863 return path and the cable sheath. The impedance of the cable sheath(s) is made up of a 'self  
2864 impedance' (fixed), and a 'mutual impedance' that is dependent on a number of factors.

2865 The earth fault current is influenced by the resistance of the earthing system and the  
2866 impedance of the cable sheath. The source impedance (primary substation), the resistance  
2867 of the primary substation earthing system, and in particular the method of neutral earthing will  
2868 have an effect.

2869 For most accuracy, some form of iterative calculation or computer model will be required to  
2870 explore the relationship between fault current, EPR, and substation resistance. However, in  
2871 any such design there are often other factors or unknowns / variables which may be of more  
2872 significance. For this reason it may be sufficient for a design to err on the side of caution by  
2873 using a 'zero-ohm' earth fault level (the maximum theoretical fault level at the distribution  
2874 substation calculated using zero sequence impedances for the circuit). Fault impedance can  
2875 then be introduced only if necessary to achieve an economic or practicable solution.

2876 ENA EREC S34 provides a detailed discussion of EPR calculations and includes worked  
2877 examples to assist with the calculation of ground return current.

**Commented [MD21]:** Check if this is covered in S.34 and if so delete from 41-24

\* This value is 2x the 1 second touch voltage limit of 233 volts, and replaces the previous design figure of 430 Volts.

2878 9.3.5.2 Transfer Potential from source

2879 A second contribution to EPR comes from **Transfer Potential** 'exported' from the source  
2880 substation, since any EPR at the source will be conveyed along the cable sheath and will  
2881 appear (in part) at the new substation.

2882 Transfer potential need not been considered if there is any overhead line in the circuit, or if the  
2883 new substation is not the first on the feeder and transfer potential is known to be of no  
2884 significance at previous distribution substations.

2885 In determining the acceptable transfer potential from source, the relevant protection clearance  
2886 time at the source should be used in touch/step calculations.

2887 **9.3.6 Step/Touch Potentials at the Substation**

2888 Many network operators or connection providers opt for a 'standard' design of distribution  
2889 substation, and it is possible to establish, by modelling or calculation, the step and touch  
2890 potentials as a % of EPR for each 'standard' layout. These values are influenced to a small  
2891 degree by the depth of rods and the proximity of other earthed metalwork, but for design  
2892 purposes can be taken as fixed for each layout. Typical values for touch potential within a  
2893 3x3m 'unit substation' that has a perimeter 'grading ring' and corner electrodes are 20-40% of  
2894 EPR. A substation built on a fine (and bonded) rebar mesh might present a touch voltage in  
2895 the region of 10% or less of EPR.

2896 Substations that employ a single rod electrode, or similar 'legacy' design, are unlikely to limit  
2897 touch potentials to less than 75% of EPR away from the electrode, and may have unacceptably  
2898 high step potentials (gradients) in the vicinity of the electrode, depending on its depth of burial.  
2899 Computer modelling using an appropriate package and soil model will normally be necessary  
2900 to demonstrate safety unless the system is simple enough to permit 'first principle' calculations  
2901 such as those presented **in EREC S34 or other relevant standards.**

2902 The appropriate design limits for touch and step potential are given in Table 2 and are  
2903 dependent on normal (calculated or worst case) protection operation.

2904 **9.3.7 Simplified approach**

2905 In some cases, a safe system can be achieved without detailed design calculations; DNOs  
2906 may wish to instead adopt simple rules in certain geographic areas, provided these rules can  
2907 be shown to produce a site with acceptable touch, step and transfer voltages. For example, a  
2908 'standard' layout (perhaps consisting of a perimeter electrode and corner rods) might be  
2909 appropriate if:

- 2910 a) 11 kV fault current is limited by reactor or resistor, and;
- 2911 b) there is a continuous cable connection to the primary substation, and;
- 2912 c) there is interconnection to the wider (HV and LV) network, and;
- 2913 d) the transfer potential from the Primary Substation is below the permissible touch  
2914 voltage (taking into consideration clearance times at the primary);
- 2915 e) there is some 'potential grading' to limit step/touch to 50% or less of EPR (this assumes  
2916 that site EPR will not exceed 2x permissible touch voltage limits).

2917 This approach is broadly consistent with that outlined in the design flowchart (Section 5.1).

2918

2919 Circumstances where the simplified approach is not appropriate:

2920 More detailed assessments might be needed if one or more of the following apply:

- 2921 a) there is any overhead line in circuit, or other break in the earth-return path;
- 2922 b) the substation is not interconnected to the HV or LV network;
- 2923 c) the secondary winding of the main transformer at the primary substation is solidly  
2924 earthed.
- 2925 d) dedicated earth fault protection is not installed;
- 2926 e) the primary substation is a site where the EPR is greater than twice the permissible  
2927 touch voltage limit for the applicable fault clearance times and there is a cable  
2928 connection giving a transfer voltage consideration.

2929 In difficult circumstances a 'HPR\*' but 'Safe (step/touch) voltage' design is allowable by  
2930 appropriate use of grading electrode/mesh to control step and touch voltages. Alternatively,  
2931 the EPR may be reduced by appropriate means (refer to Section 5.7.2 - Methods to improve  
2932 design).

2933 \* High (earth) Potential Rise

#### 2934 **9.4 Network and other contributions**

2935 Distribution substations are commonly connected to larger metallic systems which can serve  
2936 as an electrode. The following sub-sections describe typical contributions which may be  
2937 included in design calculations.

##### 2938 **9.4.1 Additional Electrode**

2939 In many cases it will be possible to supplement the substation's electrode system by laying  
2940 bare copper, or a long 'rod nest' beneath incoming or outgoing cables (subject to  
2941 separation/segregation where required), although when there are several parties involved in a  
2942 project it may not be possible for the substation installer to do so without agreement with the  
2943 cable installers (and landowners) at the design stage. Test facilities (e.g. an accessible loop)  
2944 may be provided so that the integrity of buried horizontal electrode can be tested periodically.

2945 Electrode contribution such as this may be considered in calculations for EPR, touch/step  
2946 voltages, and surface current density. It should not be included in design calculations if it is  
2947 vulnerable to theft and/or damage. Suitable precautions should be taken to ensure the integrity  
2948 of any such connections if they are safety critical.

##### 2949 **9.4.2 Parallel contributions from interconnected HV and LV networks**

2950 If it is not practicable to achieve a 'safe' (compliant) design based on HV electrode (and  
2951 additional electrode) contribution alone, then a reasonable 'parallel' contribution from the HV  
2952 network may be included in the design (Section 9.4.3 below). However, this '**network  
2953 contribution**' must not be the sole means of earthing and it is recommended that the local  
2954 (HV) electrode contribution does not exceed **40 Ohms** or value sufficient to ensure reliable  
2955 protection operation. In this way, there is some protection against failure of cable  
2956 sheath/glands.

2957 The LV network contribution may also be used if it can be shown that it is safe to combine the  
2958 HV and LV networks. Consideration should be given to the magnitude of fault current that will  
2959 flow into other (parallel) systems, particularly in the case of solidly earthed HV systems, to  
2960 ensure that the thermal ratings of any conductor or cable sheath are not exceeded.

2961 The thermal rating and surface current density requirements of sections 0 and **Error!**  
2962 **Reference source not found.** should ideally be satisfied where possible without reliance on

2963 network contribution, thus allowing the earthing system to withstand fault current without  
2964 damage should the cable sheath/gland connections fail.

#### 2965 9.4.3 Ascertaining Network Contribution

2966 The HV network or LV network, (if applicable), can serve as an effective electrode system, and  
2967 will provide a reduction in earth resistance when combined with the substation earth.

2968 The 'Network Contribution' element is difficult to establish accurately at the design stage, and  
2969 measurements of the LV and HV network may be necessary to inform the design. However,  
2970 due to the relatively routine nature of most 11 kV (or HV) connections, a conservative estimate  
2971 is often made to expedite the design process.

2972 The contribution from the network is (for older networks) made up of horizontal electrodes (un-  
2973 insulated cable sheaths) and 'point' electrodes at distribution substations.

2974 The cable connected distribution substations (whether connected with polymeric HV cables or  
2975 otherwise) can be modelled as a 'ladder network', with cable sheath impedances forming the  
2976 series elements, and earth electrode resistances forming the parallel parts. This is termed the  
2977 'chain impedance', and is akin to the treatment of metal EHV towers in ENA EREC S34. The  
2978 'chain impedance' contribution from the HV network substations falls as distance increases  
2979 from the new substation. In practice the substations within a 1-2 km radius are those which  
2980 need to be considered.

2981 The 'horizontal electrode' contribution from any lead sheathed or hessian served HV cable  
2982 sheaths can be treated in the same way as a buried horizontal conductor (EREC S.34). In  
2983 practice, each conductor will have an effective length, beyond which no additional contribution  
2984 can be assumed. A practical HV network will radiate from a substation in more than one  
2985 direction, and a contribution can be assumed from each 'leg' provided their areas of influence  
2986 do not overlap. In cases of doubt, these systems should be modelled using appropriate  
2987 computer software, or measurements carried out (taking care to use a method appropriate to  
2988 the size of the network).

2989 Calculated values for network contribution are often pessimistic in dense urban areas, where  
2990 numerous parallel contributions (such as water and gas pipes, building foundations, etc.) may  
2991 exist. If this is so, the designer may commission a measurement of network contribution (if  
2992 possible), or may use an estimated value for network contribution, or may be able to  
2993 demonstrate that the area is a Global Earthing System (GES) – see next section.

2994 [Include reference to worked example here – focussing on 'ladder network' for distribution s/s  
2995 with plastic sheathed cables – or to S34?]

#### 2996 9.4.4 Global Earthing Systems

2997 A 'Global Earthing System' (GES), is a system where all equipment is bonded together, and  
2998 the ground is saturated with metallic 'electrode contributions' in the form of metallic cable  
2999 sheaths or bare conductors laid direct in soil. In such a system, the voltage on the surface of  
3000 the soil will rise in sympathy with that of bonded HV steelwork under fault conditions, and the  
3001 voltage differences (leading to touch voltage risk) are minimal. The term is often used to  
3002 describe dense urban networks where measurements or detailed calculation of network  
3003 contribution is not practical. Refer to annex O (informative) in BS EN 50522-1 for more detail.

3004 Network operators may wish to designate certain geographic areas as 'GES', in which case  
3005 they will need to carry out measurements or analysis to demonstrate that the designation is  
3006 appropriate. In addition they should carry out calculations to assess the 'target resistance'  
3007 required in these areas; this is most easily achieved by assuming a low value of network  
3008 contribution and designing an electrode system that is sufficient to satisfy protection operation,

Commented [RW22]: Remove duplication – already said earlier

3009 current density and thermal ratings in the absence of this network contribution. A standard  
3010 design using perimeter electrode/rebar mesh etc. is usually still warranted for these reasons,  
3011 using an appropriate resistance value to ensure safety.

3012 GES networks by definition operate with combined HV/LV earthing. It should be noted that  
3013 touch potentials in GES networks can arise from transferred sources that may not be locally  
3014 bonded, e.g. cable sheaths bonded to remote systems, metallic gas/water pipes with insulated  
3015 covering, pilot/communications cables, and HV or LV insulated sheathed cables connected to  
3016 metallic plant that is not bonded to the local 'global' earthing system. Such arrangements can  
3017 cause 'islands' of higher potential inside a 'GES', and thus the benefits of a GES do not apply.

## 3018 **9.5 Transfer Potential onto LV network**

### 3019 **9.5.1 General**

3020 ESQC Regulations (2002) require that danger will not arise on the LV system as a  
3021 consequence of HV faults. In practice, this means that the HV and LV earthing systems must  
3022 be separated if the HV EPR cannot be limited to the applicable limit.

3023 NOTE: Previously, a design limit of 430 V has been applied, i.e. the HV and LV systems could be combined if the  
3024 HV EPR was  $\leq 430$  V; in practice, this EPR would be impressed on the LV neutral/earth (star point). The voltage  
3025 ultimately transferred to a consumer's LV earth terminal would be less than this, and the touch voltage appearing  
3026 within an installation would be even lower.

### 3027 **9.5.2 Touch voltage on LV system as a result of HV faults**

3028 EN 50522 Section 6.1 Table 2 introduces the concept of 'F' factors. In order to combine HV  
3029 and LV earthing systems, the HV EPR must not exceed  $F \times U_{Tp}$ , where  $U_{Tp}$  is the acceptable  
3030 touch voltage as a function of HV fault clearance time.

3031 The 'F' factor described above relates to the percentage of EPR that will appear as a touch  
3032 voltage on the LV network; it relates to the potential grading that will occur within an installation,  
3033 as well as the decay in exported potential along a multiple earthed neutral conductor. The  
3034 resultant touch voltage within the consumer's installation is necessarily subject to a number of  
3035 factors beyond the control of any network operator.

3036 It is recommended that in the UK, a value of  $F = 2$  is used unless:

- 3037 • The LV neutral/earth conductor is earthed at only one point, and:
- 3038 • The LV supplies only a small system that is isolated from the general mass of earth (e.g.  
3039 a metal pillar on a concrete plinth without outgoing circuits).

3040 In such circumstances note (d) of EN 50522 Table 2 applies, which states: "*If the PEN or*  
3041 *neutral conductor of the low voltage system is connected to earth only at the HV earthing*  
3042 *system, the value of F shall be 1.*"

3043 In such circumstances a reduced EPR limit is applicable (e.g. 233 volts for a 1 second fault,  
3044 see Table 1) because it must be assumed that the full EPR could appear as a touch voltage.

3045 In practice, for typical arrangements in the UK where  $F = 2$ , the HV EPR must not exceed 466  
3046 volts if the systems are to be combined. This assumes a 1 second fault clearance time. Lower  
3047 limits will apply for longer fault durations.

### 3048 **9.5.3 Stress Voltage**

3049 The Stress Voltage is the voltage across any two points in a substation or connected circuits.  
3050 The Stress Voltage Limit relates to the insulation withstand requirement of cables and  
3051 equipment.

3052 If HV and LV systems are combined then stress voltage limits are unlikely to be exceeded in  
3053 the substation.

3054 For segregated HV and LV systems, stress voltage includes the difference in potential between  
3055 the HV and LV earths, and may be assumed equal to the EPR of the substation. Typically this  
3056 needs to be considered in the insulation withstand of the LV neutral bushing, LV neutral busbar  
3057 supports, and LV cable screen where these are in close proximity to HV steelwork (a value of  
3058 3 kV or more is often quoted for modern equipment).

3059 Care is needed if bringing (remotely earthed) LV supplies into such sites, particularly if feeding  
3060 into metal equipment cabinets that are earthed to HV steelwork. In such circumstances the  
3061 insulation withstand within the equipment should be verified to ensure that that breakdown  
3062 between LV phase/neutral/earth and HV steelwork cannot occur internally. Isolation  
3063 transformers may be required to ensure that HV and LV systems do not flash across under HV  
3064 fault conditions.

3065 Where these criteria are met, the requirements of BS EN 50522 (Table 2) will be achieved.

#### 3066 **9.6 Combined HV and LV earthing**

3067 HV and LV earthing systems will generally be combined if the EPR on HV steelwork does not  
3068 exceed LV transfer voltage limits described above (Section 9.5).

3069 In general:

- 3070 • combine HV & LV earths if voltage rise due to an HV or EHV earth fault is safe to apply  
3071 to the transformer LV earth;
- 3072 • segregate HV & LV earths if voltage rise on LV transformer earth is unacceptable.

3073 A substation with EPR limited to 466V will usually be suitable for combined earthing if supplying  
3074 a PME network\*. This limit is subject to the caveats described in Section 9.5.2.

#### 3075 **9.7 Segregated HV and LV earthing**

3076 For segregated earth systems, it is necessary to ensure that the LV electrode system is sited  
3077 at sufficient distance from the HV electrode so that the voltage rise on the LV network is  
3078 acceptable.

##### 3079 **9.7.1 Separation Distance**

3080 Table 11 below provide an approximate minimum separation distance based on the EPR and  
3081 acceptable LV transfer limits. The values are not significantly dependent on soil resistivity  
3082 once the EPR is known, although a uniform soil model is assumed.

3083 The tables are calculated for 3x3m substations and 5x5m substations, assuming both have a  
3084 perimeter electrode. These are calculated values as given by **EREC S34 Equation P3**. They  
3085 have been compared with modelled results (for uniform soil) and the most conservative values  
3086 are presented in these tables; this represents the voltage contour furthest from the substation,  
3087 such that any LV electrode beyond this distance from the substation boundary will be at or  
3088 below the stated V<sub>x</sub> figure under HV fault conditions.

3089

---

\* A factor of 2 can be assumed for PME networks compliant with ENA ER G12/4, i.e. the voltage appearing at the customer's earth terminal is expected to be no more than 50% of the substation EPR. This paragraph also assumes that HV faults will clear within 1 second.

3090

**Table 11 - Separation distance (m) from 3x3m substation.**

<b>EPR(V)</b> <b>Vx (V)</b>	<b>1000</b>	<b>2000</b>	<b>3000</b>	<b>5000</b>
233	3.0	7.6	12.2	21.5
324	1.8	5.0	8.3	15.0
376	1.4	4.2	7.0	12.7
466	0.8	3.0	5.3	9.9

3091

3092

**Table 12 – Separation distance (m) from 5x5m substation.**

<b>EPR(V)</b> <b>Vx (V)</b>	<b>1000</b>	<b>2000</b>	<b>3000</b>	<b>5000</b>
233	5.0	12.7	20.4	35.8
324	3.0	8.4	13.9	25.0
376	2.3	6.9	11.7	21.2
466	1.4	5.1	8.9	16.6

3093

3094

NOTE: The following voltage limits are tabulated. For other values refer to Table 1:

3095

233 V = 1 second touch voltage limit (or EPR limit with F=1);

3096

324 V = 162 V x 2, EPR limit applicable to 3 second faults with F=2;

3097

376 V = 188 V x 2, EPR limit applicable to 1.5 second faults with F=2;

3098

466 V = 233 V x 2, EPR limit applicable to 1 second faults with F=1.

3099

3100

These figures relate to the distance of the voltage contour at its furthest point from the substation; in some cases (multiple earthed systems) the first LV neutral/earth electrode may be sited inside the appropriate contour, refer to Section 9.7.4 and to worked examples in ENA **EREC S34**.

3101

3102

3103

3104

**9.7.2 Transfer voltage to third parties**

3105

For substations that are close to third parties, refer to Section 4.3.3. Consideration must be given to railways, pipelines, telecommunications, cable TV, etc. if such utilities pass through an area of high potential. The formulae in **EREC S34** (ref xxx) may be used to provide an indication of the EPR that may be transferred to nearby objects.

3106

3107

3108

3109

**9.7.3 Further Considerations**

3110

The precise separation distance to be maintained between the HV and LV earthing systems is dependent on the EPR, the soil layer structure, and the physical layout of the earth electrodes. If necessary, it should be calculated during the design phase using the methods contained in

3111

3112

3113 **EREC S34** or via detailed simulation and must include the effect of electrodes located away  
3114 from the substation (See Section 9.7.4).

3115 For existing substations or during commissioning of a new installation the transfer potential  
3116 should be determined by measurement where practicable to confirm the calculated value. A  
3117 'Separation Factor' of 0.9 or greater should be achieved (as described in Section 7.10).

#### 3118 **9.7.4 Multiple LV electrodes on segregated systems**

3119 The separation distances above are those relating to the potential contour, such that the LV  
3120 electrode(s) is/are sited beyond this. In practice, if these distances cannot be maintained, one  
3121 or more electrodes on a multiple earthed neutral (e.g. PME system) may be sited within a  
3122 higher voltage contour (but no closer than 3m) provided that the majority of the PME LV  
3123 electrodes are sited beyond this. An above ground separation of 2m or more must be  
3124 maintained to prevent simultaneous (hand-hand) contact between the systems.

3125 This assumes that the remainder of the LV system as a whole will have a resistance lower  
3126 than that of the LV neutral electrode. The LV earthing system will have a 'centre of gravity' that  
3127 lies outside the relevant contour, i.e. the transfer voltage will be the weighted average of that  
3128 appearing at all LV electrodes. Any design based on these assumptions should be backed up  
3129 by a measurement of separation factor for the installed arrangement.

3130 Refer also to **EREC S34** for calculations / worked examples.

3131 This relaxation does not apply to SNE systems or PNB systems where the neutral/earth is  
3132 earthed at only one point.

3133 Where calculations based on the local LV electrode (closest to the substation) indicate  
3134 impractical separation distances or excessive transfer potentials, the design should be  
3135 reviewed and further LV electrodes installed at the end of LV feeder cables, connected via the  
3136 neutral earth conductor. To maximise this beneficial effect, they should be located as far away  
3137 from the HV electrode as possible and have a lower resistance than the LV electrode at the  
3138 substation.

#### 3139 **9.8 Situations where HV/LV systems cannot be segregated**

3140 In some situations it is not possible to segregate HV and LV systems safely without additional  
3141 measures. One example is where an LV system exists within a HV system, or there are other  
3142 similar physical constraints meaning that systems cannot reasonably be kept apart. Refer to  
3143 BS EN 50522.

3144 In such circumstances, consideration should be given to combining the HV and LV systems  
3145 and augmenting the electrode system(s) such that EPR and HV-LV transfer voltage is  
3146 acceptable. If this is not practical, insulated mats/barriers could be considered in relevant  
3147 areas.

3148 If necessary, the building or area could operate with a combined HV/LV system, safely yet with  
3149 a high EPR provided all sources of transfer potential into/out of the 'high EPR area' can be  
3150 excluded, and touch voltages are managed in and around the building. Refer to guidance on  
3151 stress voltage given in Section 9.5.3 above.

#### 3152 **9.9 Practical Considerations**

3153 HV networks are usually capable of being manually, or automatically reconfigured. The  
3154 change in 'running arrangements' will change various parameters including fault level,  
3155 protection clearance time, and sheath return current/percentage.

3156 This complication means that a bespoke design for a distribution substation may not be valid  
3157 if the running arrangement changes, and therefore the value of detailed design calculations on  
3158 a 'dynamic' network is questionable. It is recommended that the design considers all  
3159 foreseeable running arrangements, or (for simplicity) makes worst case assumptions regarding  
3160 fault level, protection clearance time, and ground return current.

3161 A network operator may wish to adopt or provide a target resistance value (tailored to different  
3162 geographic areas and different system earthing/protection scenarios), or other simplification of  
3163 these design rules, for these reasons.

#### 3164 **9.10 LV installations near High EPR sites**

3165 LV electrodes (segregated systems) as described above must be clear of the relevant voltage  
3166 contour. The consideration also applies to any customer's TT electrode. If necessary the  
3167 electrode(s) should be relocated or the shape of the high EPR zone altered by careful  
3168 positioning of HV electrodes. In addition, where possible, LV electrode locations should place  
3169 them clear of any fallen HV or EHV conductors.

3170 The siting of LV earths must consider zones with elevated potential e.g. some properties close  
3171 to high EPR substations or EHV towers may themselves be in an area of high EPR, in which  
3172 case provision of an LV earth derived from outside that zone may introduce a touch voltage  
3173 risk at the installation, due to the LV earth being a remote earth reference. The arrangement  
3174 can also pose a risk to other customers on the LV network if it will permit dangerous voltages  
3175 to be impressed on the LV neutral/earth.

3176 Detailed modelling of HV/LV networks may demonstrate that voltage differences are not  
3177 significant, due to the influence of the network on the shape of the contours; however such  
3178 modelling may not be practicable. If any doubt exists, customers should not be offered an earth  
3179 terminal, and no LV network earths shall be located in the area of high EPR. Cables passing  
3180 through the area should be ducted or otherwise insulated to limit stress voltage to permissible  
3181 limits. Typically a customer will use their own TT earth electrode; however if properties are in  
3182 an area where EPR exceeds 1200 V, it is possible that they will experience L-E or N-E  
3183 insulation failures in HV or EHV fault conditions; isolation transformers (or careful siting of  
3184 HV:LV transformers and electrode systems) may be required; refer to Sections 0, and Section  
3185 11 below .

3186 For PME electrode locations, reference should be made to ENA EREC G12.

#### 3187 **9.11 Supplies to/from High EPR (HPR) sites**

3188 Network supplies into HPR sites invariably need care if the network earth is to remain  
3189 segregated from the HPR site earth. In remaining separate, this can introduce touch voltage  
3190 risk within the site. It is normally necessary to use a careful combination of bonding and  
3191 segregation to ensure that danger does not arise within the site, or on the wider network.  
3192 Sheath breaks (insulated glands) or unearthed overhead line sections are often convenient  
3193 mechanisms to segregate the earthing systems.

3194 Similar considerations are required for LV supplies derived from HPR sites if these are to  
3195 'export' to a wider area. Typically the LV neutral will be earthed outside the contours of highest  
3196 potential and will be kept separate from all HPR steelwork in accordance with normal best  
3197 practice. It may be necessary to apply ducting or additional insulation to prevent insulation  
3198 breakdown and resultant fault current diversion from the HPR site into the wider network.

3199 Refer to [EREC S34](#) for specific examples, and to Section 12 (Case Studies).

3200 **9.11.1 Special Arrangements**

3201 Where a standard substation earthing arrangement is not applicable, alternative options may  
3202 include:

- 3203 • combining HV & LV earths and managing touch and step potentials by installing an earth  
3204 grid to enclose the installation supplied, i.e. effectively producing a large 'equipotential' safe  
3205 zone, irrespective of EPR. (The design must take into account any metallic services such  
3206 as Telecoms entering or leaving the installation, and is most useful in rural areas);
- 3207 • using an isolation transformer with a separate earthing system where an LV supply has to  
3208 be taken outside a HPR substation site with a bonded HV/LV earth system;
- 3209 • use of isolation transformers to provide small capacity LV supplies to HPR ground  
3210 mounted substations. E.g. LV supplies to tele-control equipment located within  
3211 substations with segregated HV/LV earths (as described in 9.5.3). The (alternative) use  
3212 of TT supplies (derived outside the High EPR zone) in such circumstance does not  
3213 protect against insulation failure/flashover between the LV phase/neutral conductors and  
3214 HV steelwork and could lead to the systems becoming inadvertently combined.
- 3215 • For supplies to mobile phone base stations refer to ENA EREC G78.  
3216

**Commented [MD23]:** Put name in references section.

3217 **10 Pole Mounted Substation and Equipment Earthing**

3218 This section describes earthing associated with HV Distribution Overhead Line Networks  
3219 (excluding Tower lines).

3220 **10.1 General Comments & Assumptions**

3221 Extreme care must be taken when replacing pole mounted equipment with ground mounted  
3222 equipment, since any existing earthing system is unlikely to be adequate to limit touch voltages  
3223 to safe levels on the new installation.

3224 **10.2 Pole Mounted Transformers**

3225 Pole mounted transformers (PMTs) typically operate with a segregated HV and LV earthing  
3226 system\* (see section 9.6), and (since the metalwork is out of reach), a high EPR can be  
3227 tolerated on the HV steelwork, provided that the LV electrode system is suitably separated  
3228 from the HV system. The limiting factor for EPR is usually insulation withstand (stress voltage)  
3229 on the LV cables, insulators and bushings at the pole-top; often a design value of 2 kV to 5 kV  
3230 is assumed, depending on equipment specifications. A high EPR (with a small electrode  
3231 system) is often inevitable on systems supplied by unearthed overhead lines as these do not  
3232 enjoy the 'return path' offered by a metallic cable sheath/armour.

3233 The HV electrode must be sited and designed so that it will not present a danger in terms of  
3234 hazardous step potentials (voltage gradient) around it. In this respect it is no different to that  
3235 of ground mounted systems described above, except that PMTs are often in fields, close to  
3236 livestock/animals, and with high ground return currents. Refer to Section 10.3.

3237 **[Include diagram of PMT and earthing arrangements below]**

3238 **10.3 Electrode Configuration for Pole Mounted Equipment**

3239 The following earth electrode designs assume that the overhead network does not have a  
3240 return earth conductor. With this type of system the earth potential rise (EPR) of the local earth  
3241 electrode typically will exceed tolerable touch, step and transfer potentials under earth fault  
3242 conditions.

3243 Due to the possible hazardous touch potentials, earth conductors above ground shall be  
3244 suitably insulated and provided with mechanical protection for a minimum height of 3 m or  
3245 above the height of the anti-climbing device, whichever is greater. In addition the main earth  
3246 conductor shall be suitably insulated for a minimum of 500 mm below ground level. Where the  
3247 separation of electrodes is required guidance will be given in the relevant section.

3248 It is not always reasonably practicable to ensure in all situations that step potentials directly  
3249 above an installed earth electrode system remain below permissible limits under earth fault  
3250 conditions†. It is generally considered that the probability of an earth fault occurring whilst an  
3251 individual happens, by chance, to be walking across the earth electrode at the same time, is  
3252 extremely small. Therefore, in most circumstances no special precautions are required.  
3253 However, at sensitive locations that are often frequented‡ by people, particularly children, and  
3254 concentrations of livestock in stables or pens for example, precautions may be justified to  
3255 eliminate or minimise the risk. This can usually be achieved by careful site selection or at the  
3256 time of installation by installing the earth electrode in a direction away from the area of concern,

\* In some network areas, combined HV/LV systems were employed, so this cannot be assumed.

† This is now less of an issue as step voltage limits have been considerably relaxed compared with previous versions of this specification.

‡ Refer to BS EN 50341-1 clause 6.2.4.2 for definition

3257 burying the electrode as deep as practicable, and/or fencing the electrode off to prevent  
3258 access.

3259 A similar situation also applies to personnel carrying out live operations such as HV drop-out  
3260 fuse replacement, live-line tapping at earthed locations or ABSD switching using hook stick  
3261 (hot-stick or insulated rods) techniques on earthed poles.

#### 3262 **10.4 HV Earth Electrode Value**

3263 The HV electrode is (usually) the only return path for HV fault current (except relatively rare  
3264 instances of cable fed PMTs, or cable terminations), and its resistance must generally be low  
3265 enough to operate HV protection within design limits for the network (typically 1 to 1.5 seconds  
3266 maximum); electrode resistance values between 10 Ohm and 40 Ohm are often quoted for  
3267 design purposes, with lower values providing increased resilience to lightning strikes. (Lower  
3268 resistance values will limit the voltage rise on HV steelwork, and can prevent 'back flashover'  
3269 across LV bushings resulting from lightning surges, which would otherwise destroy the  
3270 transformer winding).

3271 In general the lower the earth electrode resistance the more earth fault current will flow,  
3272 resulting in more reliable operation of the circuit protection. Where surge arresters are used it  
3273 is generally accepted that 10 Ohm is the preferred maximum value of earth electrode  
3274 resistance for satisfactory operation of the arrester. This is in line with the preferred 10 Ohm  
3275 value in BS EN 62305 for high frequency lightning earth electrodes.

#### 3276 **10.5 Electrode Arrangement Selection Method**

3277 A common arrangement of rods used for earth electrodes associated with overhead line  
3278 equipment is a run of parallel rods interconnected with a horizontal conductor.

3279 Resistance values may be calculated using formulae in **EREC S34**. The calculated values are  
3280 considered to be conservative and are based on uniform soil resistivity.

3281 Calculated resistance values for the same rod and soil arrangements, using earthing design  
3282 software are approximately 30% lower. Where the ground conditions are difficult, i.e. of high  
3283 resistivity and/or rocky, the cost of obtaining the required earth electrode resistance value may  
3284 warrant carrying out a site specific design.

3285

3286 **10.6 Earthed Operating Mechanisms Accessible From Ground Level**

3287 This section deals with pole mounted auto-reclosers (PMARs), sectionalisers, and air break  
3288 switch disconnectors, that are all capable of being manually operated via an earthed metallic  
3289 control box or switch mechanism. It is important to note that where a low voltage supply is  
3290 required for control circuits, the supply should be derived from a dedicated transformer whose  
3291 LV neutral is earthed directly to the installation's main HV earth conductor.

3292 There are several methods of minimising the risk from possibly hazardous touch and step  
3293 potentials at such installations. In selecting the most appropriate method due account should  
3294 be taken of the nature of the site, the accessibility of the equipment to third parties and the  
3295 EPR level under fault conditions.

3296 (1) Use of wireless remote control for a unit mounted on the pole out of reach from ground  
3297 level. With this method, an HV earth electrode system may be required where surge  
3298 arresters are fitted or where the manufacturer of the equipment specifies. Where  
3299 equipment is unearthed its mounting height shall comply with the relevant regulations.

3300 (2) Place the control box out of reach from ground level, access being via an insulated  
3301 ladder. Again, with this method an HV earth electrode system may be required where  
3302 surge arresters are fitted or where the manufacturer of the equipment specifies.  
3303 Where equipment is unearthed its mounting height shall comply with the relevant  
3304 regulations.

3305 Install an operator's earth mat and grading conductors to help provide an equipotential  
3306 zone for the operator. Figure 4 and Figure 6 show an example of how this may be  
3307 achieved. Whilst this minimises the hazards for the operator it requires that the  
3308 installation be carried out with great diligence. It is also important that the future  
3309 integrity of the earth electrode is ensured. Misplacement of the earth electrode  
3310 conductors can result in the operator being exposed to hazardous touch and step  
3311 potentials. Consideration needs to be given to the selection of the site prior to  
3312 installation to ensure that the required earth electrode configuration can be installed  
3313 correctly, and maintained adequately into the future. Use of suitable personal  
3314 protective equipment for switching operations may also be considered as an  
3315 additional risk control measure; dielectric (insulated) footwear rated at >7 kV is now  
3316 commonly used to protect operators against step potentials when stepping on/off the  
3317 platform.

3318 (3) Where mechanical damage is likely, for example in farmland, protective measures  
3319 need to be considered to ensure the integrity of the earth electrode and the earth mat.  
3320 An example would be to install and fix the earth mat on or in a raft of concrete or fence  
3321 off the area surrounding the earth mat.

3322 The use of grading conductors to minimise step potentials in the immediate vicinity of the  
3323 operator's earth mat may prove impractical in some circumstances, particularly where there is  
3324 a danger of them being damaged by ploughing. Burying the grading conductors at a greater  
3325 depth will significantly reduce their effectiveness. Keeping step potentials within tolerable limits  
3326 can be extremely difficult and in some case impracticable. In such circumstances alternative  
3327 mitigation should be considered.

3328 Factors such as, soil structure, operating voltage, type of HV system earthing (solid or  
3329 resistance) and system impedance all have an effect on the value of step and touch potentials  
3330 created around the earth electrode, whereas protection clearance times will have a bearing in  
3331 determining the tolerable touch and step potential limits. At some sites it may be prudent to  
3332 restrict access to the control box, for example by use of insulating barriers or fences, so that it


3333 is not possible for third parties to touch the control box and where operators can only touch the  
3334 control box when standing on the earth mat.

3335 It should be noted that burying the operator's earth mat will increase the touch potential  
3336 between the control box and the surface of the ground above the earth mat; the greater the  
3337 depth of the mat, the greater the potential difference between the soil surface above the mat  
3338 and the control box. The hazard this presents can be managed by covering the mat with a  
3339 high resistivity material which will increase the impedance path between the hands and feet.  
3340 Burying the mat will also have the effect of reducing the step potentials for an operator stepping  
3341 off the mat. However, the prime concern is to minimise the touch potentials as these are  
3342 considered to be more hazardous than step potentials. Where the mat is buried the touch  
3343 potential and the hazard it presents will be site specific, being dependent upon the actual EPR  
3344 and the protection clearance times for the given site, therefore a site specific design is  
3345 recommended. The surface mat shown in Figure 4 results in negligible touch potentials for the  
3346 operator standing on the mat, irrespective of the EPR.

3347 In all cases it is an option to use control measures to mitigate risk if a company deems this is  
3348 the most appropriate solution in the circumstances.

3349

3350



NOTE: This arrangement does not exclude the use of a portable earth mat.


Figure 4 — Earthing Arrangement for a PMAR with Ground Level Control Box.

3351

3352

3353

3354



3355 Figure 5 — Alternative Earthing Arrangement for a PMAR with Ground Level Control Box.

3356

3357 **10.7 Air Break Switch Disconnect (ABSD) with an isolated operating mechanism**

3358 There are several methods of controlling hazardous touch and step potentials, at pole mounted  
3359 ABSDs.

3360 Install an insulated rod operated ABSD at high level that does not require an earth electrode.  
3361 Where equipment is unearthed its mounting height shall comply with the relevant regulations.  
3362 This option removes the risk of the operator being exposed to the hazard of touch and step  
3363 potentials that could occur under certain earth fault conditions when adopting method 2 below.

3364 (1) Install an ABSD that is operated manually from ground level with a separate HV earth  
3365 electrode and operator's earth mat. This approach relies on effective separation of  
3366 the HV earth electrode that connects the HV steelwork to earth, and the operator's  
3367 earth mat connected to the operating handle. This arrangement is typical of existing  
3368 earthed ABSD equipment found on rural overhead line distribution networks.

3369 Separation is achieved by placing the HV earth electrode a minimum of 5m away from the  
3370 base of the operator's earth mat using insulated earth conductor from the electrode to the HV  
3371 steel work, and by insulating the operating handle from the switch mechanism using an  
3372 insulating insert in the operating rod. The top of the insert needs to be a minimum of 3m from  
3373 ground level when in its lowest position. The operating handle needs to be connected to an  
3374 earth mat positioned where the operator will stand to operate the handle. If the earth mat is  
3375 installed such that it is visible the operator can verify its existence and its connection to the  
3376 handle prior to operating the handle. The continuing effective segregation of the HV earth  
3377 electrode and the operator's earth mat is the most important aspect of the way in which this  
3378 arrangement seeks to control the touch and step potentials around the operator's earth mat  
3379 position. To minimise the possibility of contact between the buried insulated earth conductor  
3380 and the surrounding soil, should the earth conductor's insulation fail, the conductor could be  
3381 installed in plastic ducting.

3382 Where mechanical damage is possible, for example in farmland, protective measures may  
3383 need to be considered to ensure the integrity of the earth electrode and the earth mat. An  
3384 example would be to install and fix the earth mat on or in a raft of concrete or fence off the  
3385 area surrounding the earth mat using non-conducting fencing.

3386 Under earth fault conditions the HV earth electrode will rise in potential with respect to remote  
3387 earth. A potential gradient will be produced around the electrode; the potentials being highest  
3388 immediately above the electrode and reducing rapidly with distance. The earth mat will be  
3389 located within the potential gradient surrounding the HV earth electrode, but due to the  
3390 separation distance of 5m the potential at that point with respect to remote earth will be  
3391 relatively small. The surface level earth mat for the operating handle and the handle itself will  
3392 rise in potential but there will be effectively no potential difference between the mat and handle.

3393 Under earth fault conditions, assuming the correct separation distance between the HV earth  
3394 electrode and the operating handle earth mat, should the operator have one foot on the mat  
3395 and one off the mat, touch and step potentials surrounding the earth mat should not exceed  
3396 tolerable limits. However, there is a risk of hazardous touch and step potentials arising if the  
3397 HV earth electrode short circuits to the operating handle earth mat. The risk of such a short  
3398 circuit occurring is extremely small provided that the earth installation is correctly installed,  
3399 inspected and maintained.

3400 The actual size and shape of the earth mat shall be such as to ensure that the operator will be  
3401 standing towards its centre whilst operating the handle. Notwithstanding this requirement the  
3402 minimum size of earth mat should be 1 m by 1 m. Due consideration needs to be taken of the  
3403 type of handle, whether it is a two handed or single handed operation and whether the operator  
3404 may be left or right handed. A purpose made mat is recommended in preference to a mat

3405 formed on site out of bare conductor, as this eliminates problems of variation in shape and size  
3406 that can occur with the latter. Where a buried earth mat is used, the maximum depth of the  
3407 mat should be no greater than 300 mm.

3408 Under normal earth fault conditions the touch potential for both buried and surface  
3409 mounted scenarios will be negligible. When deciding between the use of a buried  
3410 earth mat and a surface mounted mat the following issues shall be considered:

- 3411 • A surface mounted mat will allow the operator to visually confirm both the  
3412 position of the earth mat relative to the handle and also the integrity of the  
3413 connection between the earth mat and the handle.
- 3414 • A surface mounted mat will minimise any touch potentials between the soil  
3415 surface on the mat and the handle, both under normal earth fault conditions  
3416 and under second fault conditions where the handle and the earth mat become  
3417 energised although this scenario should be less likely because effective  
3418 segregation can be visually confirmed before operation.
- 3419 • Conversely a surface mounted mat will maximise the step potential around the  
3420 mat although this will only be an issue if the mat and handle become energised  
3421 under a second fault scenario.
- 3422 • A buried earth mat will not allow the operator to visually confirm either its  
3423 position relative to the handle, or the integrity of its physical connection to the  
3424 handle before operation.
- 3425 • Burying the earth mat will increase the value of any touch potential between  
3426 the handle and the soil above the earth mat, this potential will increase with  
3427 depth.
- 3428 • To maintain the same effective soil surface area with a buried earth mat for  
3429 the operator to stand on and minimise any resulting touch potentials requires  
3430 a significantly larger mat than for a surface mounted mat.
- 3431 • Where a second fault occurs that energises the operating handle and earth  
3432 mat, with a buried earth mat the touch potential could exceed tolerable levels.
- 3433 • Conversely burying the mat will have the effect of reducing the step potentials  
3434 under such conditions for an operator stepping off the mat.

3435 The use of suitably rated PPE in these situations would assist in minimising the risk of exposure  
3436 to possibly hazardous potentials.




Figure 6 - Recommended Earthing Arrangement for an ABSD.

3437

3438

3439 **10.8 Surge Arresters**

3440 The preferred value for the surge arrester earth electrode resistance is 10 Ohm or less. Ideally  
 3441 this electrode system should be installed as close to the base of the pole as possible. However,  
 3442 for some locations where it may be necessary for an operator to carry out switching operations  
 3443 on the HV networks at that pole this may create unacceptable step potential hazards. In such  
 3444 cases the HV earth electrode should be installed away from the pole at a location where the  
 3445 step potential is calculated to be safe (typically 5m) for the operator to stand when carrying out  
 3446 any switching operations, see section 15.8. It is preferable to have a small number of deep  
 3447 earth rods rather than many shallow rods or plain horizontal conductor. The earth conductor  
 3448 connecting the base of the surge arresters to the earth electrode system should be as straight  
 3449 as possible, having as few bends in as is practicable. Refer to Section 6.14 for further details.

3450 Where other HV equipment is situated on the same pole and requires an earth electrode, only  
 3451 one HV earth electrode needs to be installed\*. The preference is to install an earth conductor  
 3452 directly from the surge arresters to the buried HV earth electrode, and then connect the earths  
 3453 of the other items of HV equipment to it on the pole. At sites where switching may take place  
 3454 the earth lead should be insulated to the first earth rod which should be a minimum of 5m from  
 3455 the operating mat for an ABSD or 5m from the operating position for equipment that requires  
 3456 the use of hot-sticks or insulated rods. Additional protection may be achieved by placing the  
 3457 earth lead in ducting to that point.

3458 \* Note: This practice differs from that in substations as described in Section 6.14, where separate power frequency  
 3459 and high frequency earths are required.

3460 **10.9 Cable Terminations**

3461 Typically, cable terminations on poles are associated with surge arresters or other HV  
 3462 equipment, in which case the cable sheath or screen is connected directly to the surge arrester

3463 or HV equipment main earth conductor. In the absence of surge arresters or other earthed HV  
3464 equipment the cable will require the installation of an earth electrode.

3465 **10.10 Operations at Earthed Equipment Locations**

3466 At earthed installations fed via overhead line systems, it is essential to have robust operational  
3467 procedures to minimise the risk from the possible hazards associated with the high rise of earth  
3468 potential under earth fault conditions. It should be noted that the risk increases during live fault  
3469 switching operations. It is beyond the scope of this document to detail such procedures but  
3470 consideration should be given to the following points.

3471 Earth systems are usually designed to minimise hazards under main protection operation.  
3472 They are not designed, unless specifically required, to minimise hazards under secondary or  
3473 backup protection conditions. This is an important point to note when developing fault switching  
3474 operational procedures. Temporarily disabling parts of the protection system, reconfiguring the  
3475 network, or raising protection settings to aid in fault location during fault switching can give rise  
3476 to touch, step and transfer potentials of a duration that the associated earth systems have not  
3477 been designed to take account of.

3478 Precautions shall be taken, by virtue of the equipment design and earthing arrangements to  
3479 minimise any touch and step potential hazards. For example, where rod operated (insulated  
3480 hot sticks) equipment is used, the simplest way of minimising hazards from touch and step  
3481 potentials is by, where practicable, placing the earthing electrode, not serving as grading  
3482 conductors, away from the position where the operator will be standing. Where several people  
3483 are present during operations, any person not actively carrying out operations should stand  
3484 well clear of the installed earth electrode.

3485 **10.11 Installation**

3486 The following points should be considered when installing an earth electrode system for  
3487 overhead line equipment:

- 3488 (1) Materials and jointing methods shall comply with the requirements of BS 7430.
- 3489 (2) Installation teams should have a basic understanding of the functions of an earth system,  
3490 and should carry out installations to a detailed specification.
- 3491 (3) Typically, installing a horizontal earth electrode system at a greater depth than 500mm  
3492 will not have any significant effect on reducing the earth electrode's resistance value.  
3493 However, it is recommended that the electrode is buried as deep as is practically possible  
3494 to minimise surface potentials and the possibility of mechanical damage. Where  
3495 ploughing is a concern the electrode should be buried at a minimum depth of 1m.
- 3496 (4) Ensure maximum separation is achieved on the pole between HV earth conductors and  
3497 ABSD handle earth mat conductors.
- 3498 (5) It is recommended that a test point is made available for future connection of an earth  
3499 tester above ground so that the earth electrode resistance can be measured. This test  
3500 point should be installed and constructed so as to prevent unauthorised access, and on  
3501 ABSD's prevent possible flashover to the operator's handle and associated earth mat.
- 3502 (6) Welded, brazed or compression connections are preferable to bolted connections for  
3503 underground joints.
- 3504 (7) Corrosive materials and high resistivity materials such as sand should not be used as a  
3505 backfill immediately around the electrode.
- 3506 (8) The earth resistance of the installed electrode should be measured and recorded.

3507 (9) Where a buried operator's earth mat has been installed, the mat should have two  
3508 connections made to the operating handle.

3509 **10.12 Inspection & Maintenance of Earth Installations**

3510 **10.12.1 Items to Inspect**

3511 During routine line inspections it is recommended that the following items are visually  
3512 inspected and their condition recorded, with any defects being rectified in a timely manner:

- 3513 (1) ABSD earth mat and connection to operating handle.
- 3514 (2) Separation of HV and operator's handle earth on an ABSD.
- 3515 (3) Separation of HV and LV earth conductors on the pole.
- 3516 (4) Check that the anti-climbing device does not compromise the separation between the  
3517 HV earth conductor and the operating handle.
- 3518 (5) Insulation of HV and LV earth conductors.
- 3519 (6) Mechanical protection of HV and LV earth conductors.
- 3520 (7) Bonding of plant and equipment.
- 3521 (8) State of connections, including any test point.
- 3522 (9) Signs of possible mechanical damage to earth electrode and buried earth mats.

3523 **10.12.2 Items to Examine**

3524 Periodically examine a random sample of buried earth electrodes and buried ABSD handle  
3525 earth mats, and rectify any defects found. The examination should check for the following:

- 3526 (1) position of earth mat and electrode locations relative to ABSD handle and operator's  
3527 position;
- 3528 (2) insulating insert in the ABSD operating rod;
- 3529 (3) state of underground connections;
- 3530 (4) state of earth electrode components, particularly galvanised steel rods;
- 3531 (5) state of insulation on underground earth conductors where separation of electrodes is  
3532 required.

3533 NOTE: When carrying out this work protective measures shall be taken to ensure the safety of personnel during  
3534 fault conditions.

3535 The results of the examinations can then be used to assist in developing ongoing inspection  
3536 and maintenance policy, and procedures.

3537 **10.12.3 Items to Test**

- 3538 (1) Periodically test the earth electrode resistance. For the relatively small earth systems  
3539 typically associated with overhead line equipment, a small 3 terminal earth tester is  
3540 adequate. The test should be carried out in accordance with the manufacturer's  
3541 instructions.
- 3542 (2) Regularly test the continuity between operating handle and the operator's earth mat.

3543 (3) Regularly test the continuity of buried earth mats.

3544 (4) Periodically test a random sample of insulating inserts used in ABSD operating  
3545 mechanisms.

3546 Important: When carrying out these measurements the equipment should be made dead or  
3547 where this is not practicable a risk assessment should be carried out and suitable test  
3548 procedures should be adopted which safeguard the operator from any rise of earth potential.  
3549 Such procedures may for example include the use of insulating gloves and boots, mats and /  
3550 or fully insulated test equipment.

3551

3552

3553

3554

3555 **11 Case studies / examples**

3556 [All examples currently removed (Feb 2015) pending group discussion on what to include].

3557

3558 Suggested topics:

3559

3560 1) Risk assessment case studies.

3561 2) Large substation design, fed from tower line (already in S34 so leave out?) [S34 includes 33kV OH  
3562 and U/G substation design and 132kV Neutral current reduction and reduction factors]

3563 3) Small distribution substation with cable connection [Physical layout and practical issues; refer to  
3564 (and include) calculations and results in S34]

3565 4) LV Supply into HOT (HPR) site [ 1 or 2 examples ]

3566

3567

3568

3569

3570

3571

3572

3573

3574

3575

3576

3577

3578

3579

3580

3581

3582

3583

3584

3585

3586

3587

3588

3589

3590

3591

3592

3593

3594

3595

3596 This page deliberately left blank.

3597

