

PRODUCED BY THE OPERATIONS DIRECTORATE OF ENERGY NETWORKS ASSOCIATION

1



Technical Specification 41-24

Issue <1> 2017

Guidelines for the Design, Installation, Testing and
Maintenance of Main Earthing Systems in
Substations

www.energynetworks.org

© <year of publication> **Energy Networks Association**

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of Energy Networks Association. Specific enquiries concerning this document should be addressed to:

**Operations Directorate
Energy Networks Association
6th Floor, Dean Bradley House
52 Horseferry Rd
London
SW1P 2AF**

This document has been prepared for use by members of the Energy Networks Association to take account of the conditions which apply to them. Advice should be taken from an appropriately qualified engineer on the suitability of this document for any other purpose.

<Insert publication history here, e.g. "First published, December, 2011">

Amendments since publication

Issue	Date	Amendment
Issue <1>	<April, 2016>	Draft updated in line with comments from previous meeting. References to S34 highlighted for discussion at April Meeting. Some comments included in body for guidance. Other changes accepted and tracked changes removed [RW].
	June 2016	Minor changes for review at June meeting
	August 2016	Edits following June meeting. All changes accepted. Yellow highlight for S34 references remaining. TO DO: Case studies at end of document. Flow chart.
	Dec 2016 / March 2017	Risk assessment section revised and flow chart updated. General tidy prior to issue.

1	Contents	
2	Foreword	9
3	1 Scope.....	10
4	2 Normative references	10
5	3 Definitions	11
6	4 Fundamental Requirements.....	15
7	4.1 Function of an earthing system.....	15
8	4.2 Typical features of an earthing system.....	15
9	4.3 The effects of substation potential rise on persons.....	16
10	4.3.1 Touch potential	17
11	4.3.2 Step potential	17
12	4.3.3 Transfer potential	17
13	4.3.4 General	17
14	4.3.5 Limits for LV networks	18
15	4.3.6 Limits for Other systems	18
16	4.3.7 Limits for Telecommunications Equipment (HOT/COLD sites).....	18
17	4.4 Safety criteria	18
18	4.4.1 General 'permissible' design limits	18
19	4.4.2 Effect of electricity on animals	22
20	4.4.3 Injury or shock to persons and animals outside the installation	22
21	4.5 Electrical Requirements	22
22	4.5.1 Method of neutral earthing.....	22
23	4.5.2 Fault Current	23
24	4.5.3 Thermal effects - general.....	23
25	5 Design.....	24
26	5.1 Design Considerations	24
27	5.1.1 Limiting values for EPR	24
28	5.1.2 Touch and Step voltages	24
29	5.1.3 Factors to include in calculation of EPR and Safety Voltages	24
30	5.1.4 Transfer Potential.....	24
31	5.2 Preliminary Arrangement and Layout	25
32	5.3 Design Guidelines	25
33	5.3.1 Outdoor Substations	25
34	5.3.2 Indoor Substations	26
35	5.3.3 Shared Sites.....	27
36	5.3.4 Distribution (or 'Secondary') Substations	27
37	5.3.5 Metallic Fences	27
38	5.3.6 Provision of Maintenance/Test facilities	27
39	5.4 Design data	28
40	5.4.1 Soil Resistivity.....	28
41	5.4.2 Fault currents and durations - general	29
42	5.4.3 Fault current growth	30
43	5.4.4 Fault currents for EPR and safety voltage calculations	30

44	5.4.5	Fault currents and clearance times for conductor size (thermal effects)	
45		31
46	5.4.6	Fault currents and times for electrode size calculations (thermal	
47		effects)	32
48	5.5	Conductor and Electrode Ratings	34
49	5.5.1	Earthing Conductors and Electrodes	34
50	5.5.2	Electrode Surface Current Density Ratings	40
51	5.6	Design Assessment	42
52	5.6.1	Design flowchart	42
53	5.6.2	Assessment Procedure	44
54	5.6.3	Methods to improve design (Mitigation measures)	45
55	5.6.3.1	EPR reduction	45
56	5.6.3.2	Touch Voltage reduction	46
57	5.7	Risk Assessment	46
58	5.7.1	Methodology	46
59	5.7.2	Typical applications	47
60	6	Construction of Earthing Systems	48
61	6.1	General Design Philosophy	48
62	6.1.1	Materials	48
63	6.1.2	Avoiding Theft	48
64	6.2	Jointing Conductors and Equipment Connections	49
65	6.2.1	General	49
66	6.2.2	Transition washers	49
67	6.2.3	Copper to Copper Connections	50
68	6.2.4	Copper to Earth Rods	50
69	6.2.5	Electrode Test Points	50
70	6.2.6	Copper to Equipment (Steel, or Galvanised Steel) Connections	50
71	6.2.7	Aluminium to Equipment Connections	50
72	6.2.8	Aluminium to Aluminium Connections	51
73	6.2.9	Aluminium to Copper Connections	51
74	6.2.10	Earthing Connections to Aluminium Structures	52
75	6.2.11	Steel Structures	52
76	6.3	Above Ground Earthing Installations	53
77	6.3.1	Fixing Above Ground Conductor to Supports	53
78	6.3.2	Prevention of Corrosion of Above Ground Conductors	53
79	6.3.3	Metal Trench Covers	53
80	6.3.4	Loops for Portable Earth Connections	53
81	6.4	Below Ground Earthing Installations	54
82	6.4.1	Installation of Buried Electrode within a Substation	54
83	6.4.2	Positioning of Buried Electrode	54
84	6.4.3	Other Earth Electrodes	55
85	6.4.3.1	Earth Rods	55
86	6.4.3.2	Earth Plates	55
87	6.5	Use of Structural Earths including Steel Piles and Rebar	56

88	6.5.1	Sheet Steel Piles.....	56
89	6.5.2	Horizontal Steel Reinforced Foundations.....	56
90	6.5.3	Vertical Steel Reinforced Concrete Columns.....	57
91	6.6	Metallic Fences	57
92	6.6.1	Independently Earthed Fences.....	57
93	6.6.2	Segregation between independently earthed fence and earthing system.....	57
94			
95	6.6.3	Fences Bonded to the Substation Earthing System	59
96	6.6.4	Third Party Metallic Fences.....	60
97	6.6.5	Insulated Fence Sections.	60
98	6.6.6	Chain Link Fencing (Galvanised or Plastic Coated)	61
99	6.6.7	Coated Fence Panels	61
100	6.6.8	Electric Security Fences	61
101	6.6.9	Anti-climbing Precautions	61
102	6.7	Specific Items	61
103	6.7.1	Water Services to Substations	61
104	6.7.2	Non-current carrying metalwork	62
105	6.7.3	Items normally bonded to the main earth grid:.....	62
106	6.7.4	Items NOT normally bonded to the Earth Grid.....	62
107	6.7.5	Non-standard bonding arrangements.....	63
108	6.8	Overhead Line Terminations.....	63
109	6.8.1	Tower Terminations Adjacent to Substation	63
110	6.8.2	Steel Tower Termination with Cable Sealing Ends.....	63
111	6.8.3	Terminal Poles with Stays Adjacent to Substation Fence	63
112	6.8.4	Down drop Anchorage Arrangement with Arcing Horns	64
113	6.8.5	Loss of Aerial Earth Wires	64
114	6.9	HV Cable Metallic Sheath / Armour Earthing	64
115	6.9.1	Insulated (Polymeric) Sheath Cables	64
116	6.9.2	Cables Entering Substations	65
117	6.9.3	Cables Within Substations.....	65
118	6.9.4	Outdoor Cable Sealing-Ends.....	65
119	6.9.5	Use of Disconnected, Non-Insulated Sheath/Armour Cables as an Electrode.....	65
120			
121	6.10	Light-current Equipment Associated with External Cabling	66
122	6.11	Metal Clad and Gas Insulated (GIS) Substations.....	66
123	6.11.1	Metal Clad Substations	66
124	6.11.2	Gas Insulated Switchgear (GIS)	66
125	6.12	Fault Throwing Switches, Earth Switches and Disconnectors	67
126	6.12.1	Background.....	67
127	6.12.2	Fault Throwing Switches (Phase - Earth).....	68
128	6.12.3	Earth Switches	68
129	6.12.4	Isolators.....	68
130	6.13	Operating Handles, Mechanisms and Control Kiosks.....	68
131	6.13.1	Background.....	68

132	6.13.2 Earth Mats (Stance Earths)	68
133	6.13.3 Connection of Handles to the Earth Grid and Stance Earths	69
134	6.14 Surge Arrestors and CVTs.....	69
135	7 Measurements	71
136	7.1 General.....	71
137	7.2 Safety	71
138	7.3 Instrumentation and Equipment.....	71
139	7.4 Soil Resistivity Measurements	72
140	7.4.1 Objective	72
141	7.4.2 Wenner Method	72
142	7.4.3 Interpretation of Results.....	72
143	7.4.4 Sources of Error.....	72
144	7.4.5 Driven Rod Method.....	73
145	7.5 Earth Resistance/Impedance Measurements	73
146	7.5.1 Objective	73
147	7.5.2 Method	74
148	7.5.3 Interpretation of Results.....	74
149	7.5.4 Sources of Error	75
150	7.6 Comparative Method of Measuring Earth Resistance.....	76
151	7.6.1 Objective	76
152	7.6.2 Method	76
153	7.6.3 Interpretation of Results.....	77
154	7.6.4 Sources of Error	77
155	7.7 Earth Connection Resistance Measurements (Equipment Bonding Tests).....	78
156	7.7.1 Objective	78
157	7.7.2 Method	78
158	7.7.3 Interpretation of Results.....	78
159	7.8 Earth Conductor Joint Resistance Measurements	79
160	7.8.1 Objective	79
161	7.8.2 Method	79
162	7.8.3 Interpretation of Results.....	79
163	7.9 Earth Potential Measurements	79
164	7.9.1 Objective	79
165	7.9.2 Method	80
166	7.9.3 Interpretation of Results.....	80
167	7.10 Earth Electrode Separation Test.....	80
168	7.10.1 Objective	80
169	7.10.2 Method	80
170	7.10.3 Interpretation of Results.....	80
171	7.11 Buried Earth Electrode Location	81
172	7.11.1 Objective	81
173	7.11.2 Method	81
174	B MAINTENANCE.....	82
175	8.1 Introduction.....	82

176	8.1.1	Inspection	82
177	8.1.2	Maintenance and Repairs	82
178	8.2	Types of Inspection	83
179	8.2.1	Introduction	83
180	8.2.2	Frequent Visual Inspection	83
181	8.2.3	Infrequent Detailed Visual Inspection	83
182	8.2.4	Detailed Visual Inspection, Testing and Analysis	84
183	8.2.4.1	Testing	84
184	8.2.4.2	Selected Excavation and Examination of Buried Earth	
185		Electrode	85
186	8.2.4.3	Analysis and Recording of Test Results	85
187	8.3	Maintenance and Repair of Earthing Systems	86
188	8.4	Procedure for the Remaking Defective Joints or Repairing Conductor Breaks	
189		87
190	8.4.1	Introduction	87
191	8.4.2	Joint Repair Methods	87
192	8.4.3	Flexible Braids	87
193	9	Ground Mounted Distribution Substation Earthing	88
194	9.1	Introduction	88
195	9.2	Relocation of Pole Mounted Equipment to Ground Level	88
196	9.3	General design requirements	88
197	9.3.1	Design Data Requirements	89
198	9.3.2	Conductor and electrode sizing	89
199	9.3.3	Target resistance	89
200	9.3.4	EPR design limit	90
201	9.3.5	Calculation of EPR	90
202	9.3.5.1	Factors to consider:	90
203	9.3.5.2	Transfer Potential from source	91
204	9.3.6	Step/Touch Potentials at the Substation	91
205	9.3.7	Simplified approach	91
206	9.4	Network and other contributions	92
207	9.4.1	Additional Electrode	92
208	9.4.2	Parallel contributions from interconnected HV and LV networks	92
209	9.4.3	Ascertaining Network Contribution	93
210	9.4.4	Global Earthing Systems	93
211	9.5	Transfer Potential onto LV network	94
212	9.5.1	General	94
213	9.5.2	Touch voltage on LV system as a result of HV faults	94
214	9.5.3	Stress Voltage	94
215	9.6	Combined HV and LV earthing	95
216	9.7	Segregated HV and LV earthing	95
217	9.7.1	Separation Distance	95
218	9.7.2	Transfer voltage to third parties	96
219	9.7.3	Further Considerations	96

220	9.7.4 Multiple LV electrodes on segregated systems.....	97
221	9.8 Situations where HV/LV systems cannot be segregated	97
222	9.9 Practical Considerations	97
223	9.10 LV installations near High EPR sites	98
224	9.11 Supplies to/from High EPR (HPR) sites	98
225	9.11.1 Special Arrangements	99
226	10 Pole Mounted Substation and Equipment Earthing	100
227	10.1 General Comments & Assumptions.....	100
228	10.2 Pole Mounted Transformers	100
229	10.3 Electrode Configuration for Pole Mounted Equipment.....	101
230	10.4 HV Earth Electrode Value	102
231	10.5 Electrode Arrangement Selection Method.....	102
232	10.6 Earthed Operating Mechanisms Accessible From Ground Level	103
233	10.7 Air Break Switch Disconnecter (ABSD) with an isolated operating mechanism	107
234	107
235	10.8 Surge Arresters	109
236	10.9 Cable Terminations	109
237	10.10 Operations at Earthed Equipment Locations.....	110
238	10.11 Installation	110
239	10.12 Inspection & Maintenance of Earth Installations	111
240	10.12.1 Items to Inspect.....	111
241	10.12.2 Items to Examine	111
242	10.12.3 Items to Test	111
243	11 Case studies / examples	113
244	11.1 Risk assessment – house near substation	113
245	11.2 LV Supply into HOT (HPR) site	118
246		
247		
248		

Foreword

This Technical Specification (TS) is published by the Energy Networks Association (ENA) and comes into effect from June, 2017. It has been prepared under the authority of the ENA Engineering Policy and Standards Manager and has been approved for publication by the ENA Electricity Networks and Futures Group (ENFG). The approved abbreviated title of this engineering document is "ENA TS 41-24".

This Specification is to be used in conjunction with Engineering Recommendation S34 (2017). In this document account has been taken of:

- (i) UK Adoption of BS EN 50522:2010 (Earthing of Power Installations Exceeding 1kV a.c.), in particular with reference to acceptable touch/step voltage limits derived from IEC/TS 60479-1:2005 (Effects of current on human beings and livestock);
- (ii) changes to earthing practice as outlined in ESQC (Electrical Safety, Quality, and Continuity) Regulations, 2002, in particular with regard to smaller 'distribution' or 'secondary' substations. These are described in Sections 9 and 10 of this specification;
- (iii) the requirements for Protective Multiple Earthing systems as outlined in Engineering Recommendation G12. (The relevant items concerning substation earthing in EREC G12/4 have now been transferred to this document);
- (iv) the increasing use of plastic sheathed cables;
- (v) the differing requirements of earthing systems at various voltages and for differing types of substation installation.

1 Scope

This Specification applies to fixed earthing systems for all electricity supply systems and equipment earthing within EHV, HV and HV/LV substations.

It also applies to:

- (i) terminal towers adjacent to substations and cable sealing end compounds;
- (ii) pole mounted transformer or air-break switch disconnector installations;
- (iii) pole mounted reclosers with ground level control.

It does not apply to earthing systems for quarries and railway supply substations.

2 Normative references

The following referenced documents, in whole or part, are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

BS 7430:2011+2015 (Code of Practice for Protective Earthing of Electrical Installations)

ESQC (Electrical Safety, Quality, and Continuity) Regulations, 2002 (As amended)

BS EN 50522:2010 (Earthing of Power Installations Exceeding 1kV a.c.)

IEC/TS 60479-1:2005 (Effects of current on human beings and livestock). (Part 1 – General Aspects)

IEC/TR 60479- 3 – (Effects of currents passing through the body of livestock)

ITU-T: Directives concerning the protection of telecommunication lines against harmful effects from electric power and electrified railway lines: Volume VI: Danger, damage and disturbance (2008)

CIGRE Working Group 23.10 Paper 151 (044) (Dec. 1993): Earthing of GIS – An Application Guide

Other references as included in this document: ER 134, S34, BS EN 62305, IEEE 80, IEEE 81, BS EN 62561-2

299 **3 Definitions**

APPROVED EQUIPMENT	Equipment Approved in operational policy document for use in the appropriate circumstances.
AUXILIARY ELECTRODE	See SUPPLEMENTARY ELECTRODE
BACKUP PROTECTION	Protection set to operate following failure or slow operation of primary protection – see NORMAL PROTECTION below. For design purposes the backup protection clearance time may be taken as a fixed (worst case) clearance time appropriate to the network operator's custom and practice.
BONDING CONDUCTOR	A protective conductor providing equipotential bonding.
CROSS COUNTRY FAULT	Two or more phase-to-earth faults at separate locations and on different phases. Effectively this creates a phase-phase fault with current flowing through earth electrode and/or bonding conductors. The result can be an increased 'EARTH FAULT CURRENT' for design purposes at some locations. CROSS COUNTRY FAULTS are usually considered only if a first phase-earth fault does not automatically clear within a short period, or if significant phase voltage displacement (neutral voltage displacement) could occur. If an accurate figure is not available, a value of 85% of the double phase-to-earth fault current may be assumed.
EARTH	The conductive mass of earth whose electric potential at any point is conventionally taken as zero.
EARTH ELECTRODE	A conductor or group of conductors in intimate contact with, and providing an electrical connection to, earth.
EARTH ELECTRODE POTENTIAL	The difference in potential between the 'EARTH ELECTRODE' and a remote 'EARTH'.
EARTH ELECTRODE RESISTANCE	The resistance of an 'EARTH ELECTRODE' with respect to 'EARTH'.
EARTH ELECTRODE RESISTANCE AREA	That area of ground over which the resistance of an 'EARTH ELECTRODE' effectively exists. It is the same area of ground over which the 'EARTH ELECTRODE POTENTIAL' exists.
EARTH FAULT	A fault causing current to flow in one or more earth-return paths. Typically a single phase to earth fault, but this term may also be used to describe two phase and three phase faults involving earth.
EARTH FAULT CURRENT	The worst case steady state (symmetrical) RMS current to earth, i.e. that returning to the system neutral(s) resulting from a single phase to earth fault. This is normally calculated (initially) for the 'zero ohm' fault condition. Depending on the circumstances, the value can be modified by including 'earth resistance'. Not to be confused with 'GROUND RETURN'

current which relates to the proportion of current returning via soil.

In some situations, particularly 'CROSS COUNTRY FAULTS', a different single phase to earth fault at two separate locations can result in 'EARTH FAULT CURRENT' (as seen at the fault-point) that does not return to the system neutrals yet should still be considered at the design stage.

EARTH POTENTIAL RISE (EPR) OR GROUND POTENTIAL	The difference in potential which may exist between a point on the ground and a remote 'EARTH'. Formerly known as RoEP (Rise of Earth Potential). The term 'GPR' (Ground Potential Rise) is an alternative form, not used in this standard.
EARTHING CONDUCTOR OR EARTHING CONNECTION	A protective conductor connecting a main earth terminal of an installation to an 'EARTH ELECTRODE' or to other means of earthing.
EARTH MAT	Definition requested by WPD. Group to decide form of words, e.g.: A buried or surface laid mesh or other electrode, usually installed at the operator position close to switchgear or other plant, intended to control or limit hand-to-feet TOUCH POTENTIAL.
EARTHING SYSTEM	The complete interconnected assembly of 'EARTHING CONDUCTORS' and 'EARTH ELECTRODES' (including cables with uninsulated sheaths).
EHV	Extra High Voltage, typically used in UK to describe a voltage of 33kV or higher.
ELECTRODE CURRENT	The current entering the ground through the substation's electrode system under earth fault conditions. This term is generally used in the context of electrode sizing calculations and is slightly different to Ground Return Current since the ground return current may flow through alternative paths such as auxiliary electrodes etc. For design purposes the electrode current may be taken as the worst case current flowing into a substation's electrode system under foreseeable fault conditions including, where relevant, the loss of metallic return paths and/or cross country faults.
GLOBAL EARTHING SYSTEM	An earthing system of sufficiently dense interconnection such that all items are bonded together and rise in voltage together under fault conditions. No 'true earth' reference exists and therefore safety voltages are limited.
GROUND RETURN CURRENT	<p>The proportion of EARTH FAULT CURRENT returning via soil (as opposed to metallic paths such as cable sheaths or overhead earth wires)</p> <p>If there is a metallic return path for EARTH FAULT CURRENT (e.g. a cable screen or overhead earth wire), this will typically convey a large proportion of the earth fault current. The remainder will return through soil to the system neutral(s).</p>

Reduction factors for neutral current flows (multiple earthed systems) and sheath/earth wire return currents may be applied to calculate the GROUND RETURN CURRENT. The GROUND RETURN CURRENT is used in EPR calculations as it flows through the resistance formed by a substation's overall earth electrode system (and that of the wider network) and thus contributes to voltage rise of that system. Annex I of BS EN 50522 describes some methods for calculating this component. Further guidance is given in ENA **EREC S34**.

GROUND VOLTAGE PROFILE

The radial ground surface potential around an 'EARTH ELECTRODE' referenced with respect to remote 'EARTH'.

HOT / COLD SITE

A HOT site is defined as one which exceeds ITU limits for EPR, typically these thresholds are 650 V (for reliable fault clearance time ≤ 0.2 seconds), or 430 V otherwise. The requirements derive from telecommunication standards relating to voltage withstand on equipment.

Note: These thresholds have formerly been applied as design limits for EPR in some areas. The terms HOT and COLD were often applied as a convenience (on the basis that many COLD sites do achieve safe step/touch limits) but do not relate directly to safe design limits for touch and step voltages in substations. Refer to 'HIGH EPR' below.

HIGH EPR / HPR

High Potential Rise resulting from an earth fault. An EPR greater than twice the permissible touch voltage limit (e.g. 466 V for 1 second faults on soil or outdoor concrete).

HV (High Voltage)

A voltage greater than 1kV and less than 33kV. Typically used to describe 6.6kV, 11kV and 20kV systems in UK.

MES (Main Earthing System)

The interconnected arrangement of earth electrode and bonds to main items of plant in a substation.

NORMAL PROTECTION OPERATION

Clearance of a fault under normal (usual) circumstances. The normal clearance time will include relay operating time and mechanical circuit breaker delays for all foreseeable faults, and may be calculated for design purposes. Alternatively a network operator may work to the 'worst case' protection clearance time applicable to the network in a given area. This time assumes that faults will be cleared by normal upstream protection and does not allow for e.g. stuck circuit breakers or other protection failures/delays. Certain parts of an earthing design should consider slower 'BACKUP PROTECTION' operation (see above) which allows for a failure of normal protection.

NETWORK OPERATOR

Owner or operator of assets. Includes DNO (Distribution Network Operator), IDNO (Independent or 'Inset' DNO) and Transmission Network Operator (TNO) as defined in the Distribution Code (DCode) or System Operator Transmission Code (STC) as appropriate.

SUPPLEMENTARY ELECTRODE	Electrode that improves the performance of an earthing system, and may increase resilience, but is not critical to the safety of the 'as designed' system.
STEP POTENTIAL	See Section 4.3.2 for definition.
STRESS VOLTAGE	Voltage difference between two segregated earthing systems, which may appear across insulators/bushings etc. or cable insulation.
TOUCH POTENTIAL	See Section 4.3.1 for definition.
TRANSFER POTENTIAL	See Section 4.3.3 for definition.
WITHSTAND VOLTAGE	The maximum STRESS VOLTAGE that can be safely permitted between items of plant or across insulation without risk of insulation breakdown or failure.

4 Fundamental Requirements

4.1 Function of an earthing system

Every substation shall be provided with an earthing installation designed so that in both normal and abnormal conditions there is no danger to persons arising from earth potential in any place to which they have legitimate access. The installation shall be able to pass the maximum current from any fault point back to the system neutral whilst maintaining step, touch, and transfer potentials within permissible limits (defined in Section 4.3) based on normal* protection relay and circuit breaker operating times. In exceptional circumstances where the above parameters may not be economically or practically kept below permissible limits a probabilistic risk assessment may be carried out. Where this shows the risk to be below accepted ALARP levels the level of earth potential rise mitigation may be reduced (refer to Section 5.7).

The earthing system shall be designed to avoid damage to equipment due to excessive potential rise, potential differences within the earthing system (stress voltages), and due to excessive currents flowing in auxiliary paths not intended for carrying fault current.

The design shall be such that the passage of fault current does not result in any thermal or mechanical damage [for backup protection clearance times] or damage to insulation of connected apparatus. It shall be such that protective gear, including surge protection, is able to operate correctly.

Any exposed normally un-energised metalwork within a substation, which may be made live by consequence of a system insulation failure can present a safety hazard to personnel. It is a function of the station earthing system to eliminate such hazards by solidly bonding together all such metalwork and to bond this to the substation earth electrode system in contact with the general mass of earth. Dangerous potential differences between points legitimately accessible to personnel shall be eliminated by appropriate design.

The earthing system shall maintain its integrity for the expected installation lifetime with due allowance for corrosion and mechanical constraints.

The earthing system performance shall contribute to ensuring electromagnetic compatibility (EMC) among electrical and electronic apparatus of the high voltage system in accordance with IEC/TS 61000-5-2.

4.2 Typical features of an earthing system

The earthing installation requirements are met principally by providing in each substation an arrangement of electrodes and earthing conductors which act as an earthing busbar. This is called the 'main earth grid' or 'main earth system' (MES) and the following are connected to it:

- (i) all equipment housing or supporting high voltage conductors within the substation such as transformer and circuit breaker tanks, arcing rings and horns and metal bases of insulators;
- (ii) neutral connection of windings of transformers required for high voltage system earthing. For high voltage systems the connections may be via earthing resistors or other current limiting devices, as described in Section 4.4. (The neutral earthing of low-voltage systems is separately considered in Section 9);

* See 'Definitions' in Section 3

- 341 (iii) earth electrodes, additional to the main earth grid which may itself function as an
342 earth electrode;
- 343 (iv) earth connections from overhead line terminal supports and the sheaths / screens
344 of underground cables;
- 345 (v) earth mats, provided as a safety measure, to reduce the potential difference
346 between points on the area of ground adjacent to manually operated plant and the
347 metalwork including handles of that plant (but see also 10.6);
- 348 (vi) 'Grading Electrodes' (intended to reduce touch voltages on equipment), which as a
349 minimum consist of a horizontal ring electrode around all items of earthed plant and
350 the equipment and bonded to it. This often must be supplemented by additional
351 grading electrodes inside the ring;
- 352 (vii) 'High Frequency Electrodes', conductors and electrodes specifically configured to
353 reduce the impedance to lightning, switching and other surges at applicable
354 locations, e.g. surge arresters, CVTs and GIS bus interfaces;
- 355 (viii) all other exposed and normally un-energised metalwork wholly inside the
356 substation perimeter fence, e.g. panels (excluding floating fence panels), kiosks,
357 lighting masts, oil tanks, etc. Conductive parts not liable to introduce a potential
358 need not be bonded (e.g. metal window frames in brick walls). Items such as
359 fences, cables and water pipes which are not wholly inside the substation are
360 separately considered in Sections 6.6 and 6.7.
- 361 (ix) Fences may be bonded to the main earth system in some situations – refer to
362 Section 6.6.

363 Substation surface materials, for example stone chippings which have a high value of
364 resistivity, are chosen to provide a measure of insulation against potential differences occurring
365 in the ground and between ground and adjacent plant. Although effective bonding significantly
366 reduces this problem the surface insulation provides added security under system fault
367 conditions. Permissible 'touch/step' voltages are higher where an insulated surface layer is
368 provided – refer to 'Safety Criteria' below.

369 **4.3 The effects of substation potential rise on persons**

370 During the passage of earth-fault current a substation earth electrode is subjected to a voltage
371 rise (Earth Potential Rise, or 'EPR', sometimes denoted as U_E). Potential gradients develop in
372 the surrounding ground area. These gradients are highest adjacent to the substation earth
373 electrode and the ground potential reduces to zero (or 'true earth potential') at some distance
374 from the substation earth electrode.

375 A person will be at risk if he/she can simultaneously contact parts at different potential; thus in
376 a well designed system the voltage differences between metallic items will be kept to safe
377 levels regardless of the voltage rise (EPR) on the system.

378 Ground potential gradients around the electrode system, if great enough, can present a hazard
379 to persons and thus effective measures to limit them must be incorporated in the design.

380 The three main design parameters relate to 'Touch', 'Step' and 'Transfer' voltages as defined
381 below. These terms are shown as U_{VT} , U_{VS} and 'A' in Figure 1.

382




Figure 1 – Showing Touch, Step, and Transfer Voltages resulting from an earth fault

4.3.1 Touch potential

This term describes the voltage appearing between a person's hands and feet. It arises from the fact that the ground surface potential at a person's feet can be somewhat lower in value than that present on the buried earth electrode (and any connected metalwork). If an earthed metallic structure is accessible, a person standing on the ground 1 metre away and touching the structure will be subject to the 'touch potential'. For a given substation the maximum value of 'touch potential' can be up to two or three times greater than the maximum value of 'step potential'. In addition, the permissible limits for step potential are usually much higher than for touch potential. As a consequence, if a substation is safe against 'touch potentials', it will normally be safe against 'step potentials'.

In some situations, the 'hand-hand' touch potential needs to be considered, for example if 'unbonded' parts are within 2 metres. The permissible limits for this scenario can be calculated as described in IEC/TS 60479-1, using the body impedance not exceeded by 5% of the population. In general, such situations should be designed out, e.g. by increasing separation or introducing barriers if the systems must be electrically separate, or by bonding items together. The siting of fences needs consideration in this regard.

4.3.2 Step potential

As noted above, a potential gradient in the ground is greatest immediately adjacent to the substation earth electrode area. Accordingly the maximum 'step potential' at a time of substation potential rise will be experienced by a person who has one foot on the ground of maximum potential rise and the other foot one step towards true earth. For purposes of assessment the step distance is taken as one metre. This is shown as U_{VS} in Figure 1.

4.3.3 Transfer potential

4.3.4 General

A metallic object having length - a fence, a pipe, a cable sheath or a cable core, for example, may be located so as to bring in ('import') or carry out ('export') a potential to or from the site.

By such means a remote, or 'true earth' (zero) potential can be transferred into an area of high potential rise (HPR) or vice-versa. For example a long wire fence tied to a (bonded) substation fence could export the site EPR to the end of the wire fence, where it may pose an electric shock hazard to somebody standing on soil at 'true earth' potential. Similarly, a metallic water pipe (or telephone cable, or pilot cable, etc.) could 'import' a zero volt reference into a

substation, where local voltage differences could be dangerous. Bonding the cable or pipe to the substation system might reduce local risk but could create a problem elsewhere; isolation units or insulated inserts (for pipework) are typical solutions that may need to be considered.

The limits for permissible transfer voltage relate to shock risk (Touch and Step Voltage), and equipment damage / insulation breakdown (Stress Voltage).

4.3.5 Limits for LV networks

Safety criteria (as defined in Section 4.4.1) apply to the voltage that may be transferred to LV networks. Further information is given in Section 9.5.

4.3.6 Limits for Other systems

Voltages carried to pipelines, fences, and other metallic structures during HV fault conditions must not exceed permissible touch and step voltage limits as defined below (Section 4.4.1). In some circumstances (for example pipelines connected to gas or oil pumping or storage facilities), lower limits may apply as defined in relevant standards.

4.3.7 Limits for Telecommunications Equipment (HOT/COLD sites)

Care must be taken to ensure that telecommunications and other systems are not adversely impacted by substation or structure EPR; in general these systems must be routed so that the insulation withstand is not exceeded by passing through an area of high potential rise. Where the EPR on substations (or structures) exceeds certain levels, the operators of these systems must be notified. Refer to ENA ER S36 for more information.

ITU Directives[†] presently prescribe limits (for induced or impressed voltages derived from HV supply networks) of 430 V rms or, in the case of high security lines, 650 V rms. (High security lines are those with fast acting protection which, in the majority of cases, limits the fault duration to less than 200 milliseconds.) Voltages above and below these limits are termed 'HOT' and 'COLD' respectively, although it should be noted that these terms do not relate directly to safety voltages.

For telecoms connections to 'HOT' sites, consultation with telecommunications provider may be necessary to arrive at a solution, e.g. isolation transformers or optic fibre links to ensure the telecoms system is segregated from the substation earth.

4.4 Safety criteria

4.4.1 General 'permissible' design limits

An effective earthing system is essential to ensure the safety of persons in, and close to substations, and to minimise the risk of danger on connected systems beyond the substation boundaries. The most significant hazard to humans is that sufficient current will flow through the heart to cause ventricular fibrillation.

The basic criteria adopted in this specification for the safety of personnel are those laid down in BS EN 50522, which in turn derive from IEC/TS 60479-1. In addition, ITU-T directives are considered where relevant, and where their limits might be lower than BS EN 50522.

The relevant limits for touch and step voltages are given in Tables 1 and 2 below.

These use the body impedance values not exceeded by 5% of the population, and the 'C2' current curve as described in National Annexe NA of BS EN 50522:2010.

[†] (ITU-T: Directives concerning the protection of telecommunication lines against harmful effects from electric power and electrified railway lines: Volume VI: Danger, damage and disturbance (2008))

457 In selecting the appropriate limits, the designer must consider the type of surface covering,
458 and if footwear will be worn. Within substations, it should be assumed that footwear will be
459 worn. IEC/TS 60479-1 states that these design limits are sufficiently conservative to apply to
460 all humans including children; however it is recommended that further reference be made to
461 that standard, and relevant (lower) limits adopted as necessary if a substation is in close
462 proximity to, or might otherwise impinge on high risk groups.

463

Table 1 – Permissible touch voltages for typical fault clearance times:

Permissible touch voltages V ^(A)		Fault clearance time, seconds																			
		0.1	.15	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	1.1	1.2	1.3	1.4	1.5	2	3	5	≥10 ^(B)
	Bare feet (with contact resistance)	521	462	407	313	231	166	128	106	92	84	80	76	73	71	69	67	63	60	58	57
	Shoes on soil or outdoor concrete	2070	1808	1570	1179	837	578	420	332	281	250	233	219	209	200	193	188	173	162	156	153
	Shoes on 75mm chippings	2341	2043	1773	1331	944	650	471	371	314	279	259	244	232	223	215	209	192	180	173	170
	Shoes on 150mm chippings or dry ^(D) concrete	2728	2379	2064	1548	1095	753	544	428	361	321	298	280	266	255	246	239	220	205	198	194
	Shoes on 100mm Asphalt	13500	11800	10200	7600	5300	3600	2500	2000	1600	1400	1370	1300	1200	1100	1100	1080	990	922	885	866
NOTE: These values are based on fibrillation limits. Immobilisation or falls/muscular contractions could occur at lower voltages. Steady state or standing voltages may require additional consideration.																					
A) Additional resistances apply based on footwear resistance as well as contact patch, as defined in BS EN 50522, i.e. each shoe is 4kΩ and the contact patch offers 3xp, where p is the resistivity of the substrate in Ω·m. Thus for touch voltage, the series resistance offered by both feet is 2150 Ω for shoes on soil/wet concrete (effective p=100 Ω·m). For 75 mm chippings, each contact patch adds 1000 Ω to each foot, giving 2500 Ω (effective p=333 Ω·m). For 150mm chippings (and a conservative estimate for dry concrete), the total resistance is 3000 Ω (effective p = 670 Ω·m). Concrete resistivity typically will vary between 2,000-10,000 Ω·m (dry) and 30-100 Ω·m (saturated). For asphalt, an effective p =10,000 Ω·m gives 34kΩ per shoe. B) The >= 10s column is an asymptotic value which may be applied to longer fault duration. This is a fibrillation limit only; it may be prudent to apply lower limits to longer duration faults or steady state voltages sufficient to limit body current to ‘let-go’ threshold values. C) This assumes no contact resistance but does apply the ‘dry’ body impedance values with large contact areas. For other scenarios (e.g. salt-water wet) refer to IEC/TS 60479-1. D) Dry assumes indoors. Outdoor concrete, or that buried in normally ‘wet’ areas or deep (>0.6m) below ground level should be treated in the same way as soil.																					

Commented [RW1]:
No limits have been specified for continuously held currents

Group considers that C2 curve asymptotic value of 48mA acceptable for 10 seconds or greater.

IEEE 80 suggests that long term voltage should be that where current is below the threshold of let-go, since death by asphyxiation (rather than fibrillation) can occur for long durations if an individual's chest muscles contract to prevent breathing. This lower limit (approx. 10mA) reduces the touch voltage limit to around 35V on soil, or 44V on deep chippings/concrete. There is a limit of 80V in 50522 but this considers only fibrillation.

These factors are alluded to but not spelled out in footnote to tables.

Table 2 – Permissible step voltages for typical fault clearance times:

Permissible step voltages V ^(B)		Fault clearance time, seconds																			
		0.1	.15	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	1.1	1.2	1.3	1.4	1.5	2	3	5	≥10 ^(C)
	Bare feet (with contact resistance)	22753	19763	17077	12715	8905	6044	4290	3320	2770	2434	2249	2098	1992	1897	1823	1771	1616	1503	1442	1412
	Shoes on soil or outdoor concrete	A)	A)	A)	A)	A)	A)	A)	A)	21608	19067	17571	16460	15575	14839	14267	13826	12629	11727	11250	11012
	Shoes on 75mm chippings	A)	A)	A)	A)	A)	A)	A)	A)	24906	21976	20253	18971	17951	17103	16445	15936	14557	13517	12967	12692
	Shoes on 150mm chippings or dry concrete	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	24083	22559	21347	20338	19555	18951	17311	16074	15420	15092
	Shoes on 100mm Asphalt	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)
NOTES:																					
1) As for touch voltage, these limits are calculated according to fibrillation thresholds. Immobilisation or falls / involuntary movements could occur at lower voltages. 2) In general, compliance with touch voltage limits will achieve safe step voltages.																					
A) Limits could not be foreseeably exceeded, i.e. 25kV or greater. B) Additional footwear / contact resistances appear in series (rather than parallel for the hand-feet case), and are therefore 4x those in equivalent touch potential case. C) The >= 10s column is an asymptotic value which may be applied to longer fault duration. This is a fibrillation limit only; it may be prudent to apply lower limits to longer duration faults or steady state voltages sufficient to limit body current to 'let-go' threshold values. D) This assumes no contact resistance but does apply the 'dry' body impedance values. For wet or salt-water wet, scenarios refer to IEC/TS 60479-1.																					

The figures above give acceptable touch and step potentials as a function of fault current duration. Note that touch and step voltages are normally a fraction of the total EPR, and therefore if the EPR (for all foreseeable fault conditions) is below the limits above then it follows that the site will be compliant. (The full design assessment procedure is given in Section 5.)

Permissible limits are a function of normal protection clearance times. Figure B2 of BS EN 50522 shows curves showing intermediate values, if required.

Touch and Step Voltages are sometimes collectively referred to as 'Safety Voltages' since they relate directly to the safety of persons or animals.

Substations shall be designed so that 'Safety Voltages' are below the limits defined in Table 1 and Table 2 above. It will be appreciated that there are particular locations in a substation where a person can be subjected to the maximum 'step' or 'touch' potential. Steep potential gradients in particular can exist around individual rod electrodes or at the corner of a meshed grid.

The presence of a surface layer of very high resistivity material provides insulation from these ground potentials and greatly reduces the associated risks. Thus substations surfaced with stone chippings/concrete or asphalt are inherently safer than those with grass surfacing, and permissible limits are higher. These relate to the 'Additional Resistance' rows in the tables above.

4.4.2 Effect of electricity on animals

The main focus of this document is human safety. However, horses and cattle are known to be particularly susceptible to potential gradients in soil. There are no safety limits prescribed for animals but technical report (IEC/TR 60479-3) provides some limited experimental data. Interpretation of this data suggests that voltage gradients (e.g. around remote electrodes or structures placed in fields) not exceeding 25 V/m will generally not result in animal fatality.

4.4.3 Injury or shock to persons and animals outside the installation

Shock risk outside an installation can be introduced by metallic transfer (fence, pipe, cable) or via the soil. Where a hazardous transferred potential can occur due to metallically conductive means, that eventuality should be removed by the introduction of insulation or other protective measures (examples include insulated sections introduced into external metal fences). Where metal fences are bonded to the substation earthing system, the touch and step potentials external to them must be controlled by the design, such that they are within the acceptable limits. In other words, most risks should be managed by design such that touch and step voltages are below safe 'deterministic' limits defined in Table 2 above. Where HV and LV earthing systems are combined, the EPR is transferred from the installation into domestic, commercial or industrial properties and must be at a level that complies with the requirements of section 9.5.

In many situations, risk to individuals may be beyond the control of the network operator, for example if a building is erected close to an existing substation. In such circumstances, a risk assessment should be carried out to establish the level of risk, and the justifiable spend to mitigate against that risk. Acceptable voltage thresholds will be influenced by activity (e.g. wet/dry), location (e.g. beach-side) and the presence of animals. The risk assessment process is described further in Section 5.7.

4.5 Electrical Requirements

4.5.1 Method of neutral earthing

The method of neutral (or 'star point') earthing strongly influences the fault current level. The earthing system shall be designed appropriate to any normal or 'alternative' neutral earthing

arrangements, in a similar way that it will be necessary to consider alternative running arrangements that may affect fault levels or protection clearance times.

Note, if the system uses a tuned reactor (arc suppression coil (ASC) / Petersen coil) connected between the transformer neutral and earth, the magnitude of the current in the earthing system may be small due to the tuning of the ASC reactance against the capacitance to earth of the unfaulted phases. However, other conditions can occur that require a higher current to be considered. For instance, if the tuned reactor can be shorted out (bypassed), e.g. for maintenance or protection purposes whilst the transformer is still on load, then it is necessary to design for this (refer to sections 5.4.2 and 5.4.5). Furthermore, even if there is no alternative method of system earthing it is still necessary to consider the possibility of a neutral bushing fault on the tuned reactor effectively shorting out the tuned reactor. Such considerations also apply to all impedance earthed systems if there is a foreseeable risk of the impedance 'failing' and remaining out for any significant time.

The likelihood of phase-to-earth insulation failure is increased on ASC systems, particularly if earth faults are not automatically disconnected. This is because a first earth fault will cause phase displacement such that the two healthy phases will become at increased voltage relative to earth (approaching line-line voltage). Consideration should be given to a 'cross-country' fault where two phase-to-earth faults occur simultaneously on different phases. The current can approach phase-to-phase levels if the earth resistance at each fault site is minimal or if there is metallic interconnection between the sites.

4.5.2 Fault Current

The passage of fault current into an electrode system causes voltage rise (EPR, and touch/step/transfer voltages) and heating. Both are related to the magnitude of fault current flow. Section 5.4 describes the fault currents (and durations) applicable to earthing design.

4.5.3 Thermal effects - general

The earthing system shall be sized according to the maximum foreseeable current flow and duration to prevent damage due to excessive temperature rise. For main items of plant in substations (switchgear, transformers, VTs, CTs, surge arrestors, etc.), consideration needs to be given to the possibility of simultaneous phase-earth faults on different items of plant, which could result in phase-phase current flows through the MES. Refer also to Section 5.4.5.

Any current flowing into an electrode will give rise to heating at the electrode and surrounding soil. If the current magnitude or duration is excessive, local soil can dry out leading to an increase in the resistance of the electrode system. Section 5.5.2 defines a 'surface current density' limit (in terms of Amps per m² or cm² of electrode area). In some situations, even if target resistance and design EPR values are achieved, it may be necessary to increase the electrode contact surface area to ensure compliance with this requirement (Section 5.4.6).

5 Design

5.1 Design Considerations

This section describes general arrangements applicable to all substations. Further discussion relating to those items specific to distribution substations is included in Section 9, and pole-mounted systems are further described in Section 10.

5.1.1 Limiting values for EPR

The design shall comply with the safety criteria (touch, step and transfer voltages) and with the earthing conductor and earth electrode conductor current ratings, and will need to allow sufficient current flow for reliable protection operation.

There is no design requirement which directly limits the overall EPR of a substation to a particular value, however, the design will need to consider insulation withstand between different systems, and voltage contours in surrounding soil. The need to comply with these requirements, and safety limits, will naturally tend to restrict the acceptable EPR. In practice, an upper EPR limit may be applied by different network operators based on equipment specifications and/or proximity to third party systems.

5.1.2 Touch and Step voltages

Touch and Step voltages (collectively referred to as 'Safety Voltages') are the most important design criteria. A substation that fails to achieve permissible touch voltage limits will not be safe. Formulae for calculating touch and step voltages are presented in EREC S34.

5.1.3 Factors to include in calculation of EPR and Safety Voltages

For each operating voltage at a substation, two conditions of earth fault should be considered to determine the maximum value of earth electrode current. In one, the earth fault is external to the substation; here the current of concern is that returning to the neutral(s) of the transformer(s) at the substation under consideration. The other is for an earth fault in the substation; here the current of concern is now that value returning to the neutral(s) of the transformer(s) external to the substation under consideration. These currents are components of the system earth fault currents. If these return currents have available to them other conducting paths directly connected to the earthing system of the substation, for example overhead line earth-wires and cable sheaths, then the currents in these paths shall be deducted from the appropriate return current to derive the value of current passing through the earth electrode system of the substation. Evaluation of this 'ground-return' current component is described in EREC S34. See also Section 5.4.2.

5.1.4 Transfer Potential

A further factor that needs to be considered is 'transfer voltage' that may arise from a fault at the source substation(s), if there is a metallic connection (cable sheath or earth wire) between the substation earthing systems. Methods for calculating the transferred potential are described in ENA EREC S34.

A person at a remote location could theoretically receive the full (100%) EPR as a touch potential since he/she will be in contact with 'true earth'. This may be disregarded if the EPR at the source substation is known to meet the safety criteria, i.e. is within acceptable touch voltage limits. However, particular care is needed if there is a possibility of hand-hand contact between a transfer potential source, and other earthed metalwork. The possibility should be excluded by appropriate barriers (e.g. insulated glands, enclosures) or bonding. If this cannot be ensured, then lower voltage limits apply to the hand-hand shock case (refer to IEC/TS 60479-1).

Commented [RW2]: Previous discussion with group decided not to include hand-hand touch potential limits, agreed to keep as such despite SS comments which raised the issue again.

Rob W's spreadsheet has numbers which could be inserted if required.

5.2 Preliminary Arrangement and Layout

In order to determine fully the requirements for and adequacy of an earthing system it is necessary to produce a preliminary design arrangement of that earthing system. From a site layout drawing showing the location of the plant to be earthed, a preliminary design arrangement of the earthing system for the substation should be prepared, incorporating the relevant 'functions' of Section 4.1 and the relevant 'features' of Section 4.2. The particular layout arrangement will be unique to each substation but all will have some dependence on, inter alia, a combination of the factors described in Section 5.4.5, relating to fault level, fault duration, electrode current and soil type.

5.3 Design Guidelines

This Section gives an outline of those features of earthing system arrangements which have proved to be most satisfactory in practice.

5.3.1 Outdoor Substations

Except for pole mounted equipment, it is recommended that the earthing arrangement be based on a bare 'perimeter electrode' (peripheral buried horizontal earthing electrode), generally encompassing the plant items to be earthed such that the perimeter earth electrode is at least 1m out from the plant items to provide touch voltage control at arm's reach. Internal connections shall connect from the perimeter electrode to the items of plant. These internal connections function as earthing conductor if not in contact with soil, or electrode otherwise. Where reasonably practicable, the amount run above the surface shall be minimized to deter theft. In addition, discrete earth electrodes, e.g. rods or plates, may be connected to this perimeter electrode. These may variously be employed to reduce the surface current and/or the electrode resistance of the overall earth electrode system. The overall electrode system is termed the Main Earthing System (MES).

The electrode system may be augmented with inter-connected, buried, bare cross-connections to form a grid. Such cross-connections increase the quantity of earth electrode conductor and mesh density of the grid, reduce touch voltages on plant within the grid, and provide local main conductors to keep equipment connections short; in addition they increase security/resilience of connections by introducing multiple paths for fault current, which is an important consideration.

In all substations it is recommended that duplicate connections are made from the Main Earthing System (MES) to main items of plant, in order to increase resilience (refer to Section 5.4.5 for conductor sizing).

Where regular contact of an operator with an earthed structure is anticipated, e.g. at a switch handle, the earthing system shall be enhanced by providing an earth mat (or, if a mat poses difficulties, appropriate grading electrode) at or just below the surface of the ground and bonded to the metalwork, so arranged that the metalwork can only be touched while standing above the mat (or enhanced area).

Pole-mounted equipment presents a particularly difficult ground potential gradient problem and the special precautions noted in Section 10 shall be observed. It may be necessary to apply these precautions in some ground-mounted substations.

Fault current flowing through an earth electrode system to ground uses the outer extremities of the electrode system to a greater extent than the inner parts of the system. Thus, adding more earth electrode, whether as vertical rods or as horizontal tape, to the inner area of a small loop or well integrated grid electrode system, will have little impact in reducing earth resistance or the current density in the outer electrode conductors of the system (however this can help to control step/touch potentials around specific items of plant).

Such reductions (in overall earth resistance) as may be desirable are best achieved by extending the electrode system to cover a greater area of ground (e.g. by buried 'radial' electrodes), or by driving rods around the periphery of the system or by a combination of both.

The vertical rod electrode is most effective for use in small area substations or when low soil resistivity strata, into which the rod can penetrate, lies beneath a layer of high soil resistivity. Rods are least effective where there is a high resistivity layer beneath one of lower resistivity, e.g. where underlying bedrock is near to the surface. In these locations extended horizontal electrodes in the low resistivity surface layer are more effective.

For large area substations employing a grid electrode system, the addition of vertical rods, even when optimally installed around the periphery of the system, may make only a marginal improvement.

5.3.2 Indoor Substations

The plant of indoor substations will normally be erected on a concrete raft, often containing a steel reinforcing mesh (re-bar). To control touch and step potentials around plant, it is common for re-bar to be bonded to the main earthing system, or for a dedicated 'grading mesh' (usually consisting of prefabricated steel or copper mesh) to be buried in concrete screed in the substation area. These measures are to control potential gradients and are not intended to act as an 'electrode' (they may be employed for example above basement areas); dedicated electrodes will also be required to provide a connection to the mass of earth and achieve the functional requirements. For new substation buildings a buried peripheral horizontal electrode may be conveniently installed around the building foundation and supplemented with vertical rod electrodes as required. Coordination with the civil engineering design can result in a cost-effective installation.

Where reinforcing mesh in concrete is to function as supplementary earth electrode, it must be designed to carry the current without cracking the concrete, be constructed with mesh panels welded together and be welded to the peripheral buried earth electrode at suitable intervals (e.g. 5 m).

The provision of a buried main earth bonding conductor within the confines of an existing building is often impractical and thus a surface mounted main earthing conductor loop, is normally installed with surface run (and duplicate) spur connections to the various items of plant. The earth electrode system employed with this arrangement may differ depending on the magnitude of earth fault current that the electrode system is required to carry. Marshalling earth bars are sometimes used in addition to, or instead of, a surface laid loop, and (if properly labelled) can facilitate measurement/maintenance. The convenience of such an arrangement often brings with it a high reliance on bolted connections and so the 'resilience' aspect needs to be balanced with convenience.

Substations in buildings may require a buried loop/ring electrode outside the building if any extraneous metalwork (e.g. metal cladding, steel joists, handrails, communications antennae etc.) is bonded to the substation earthing system and could otherwise present a touch potential issue to those outside the building. The same considerations apply where a substation is installed in an existing building (for example in the basement of a tower block), even if the building is not recognisable as a 'substation building'; in fact risks associated with members of the public will often be higher in such installations and warrant additional consideration.

Electrode systems (rod nests, etc.) should not be sited close to main access/egress routes without consideration of step and touch voltage in these areas.

Grading electrode (where required) should be positioned 1 m from metal-clad buildings, and bonded to the building's internal HV or EHV earthing system at two or more separate points.

690 If the building is to be provided with a lightning protection system that will be bonded to the
691 main earthing system, the LPS electrodes may contribute to potential grading. Calculations
692 and/or computer modelling will normally be necessary to demonstrate whether such measures
693 can be used in place of dedicated grading electrodes.

694 Sparsely positioned rods (e.g. associated with a lightning protection system to BS EN / IEC
695 62305-1) may serve this function if compliance can be demonstrated at the design stage.

696 A lightning protection electrode system if purposely designed with regard to power system fault
697 currents and with closely spaced rods (or interconnecting electrode ring), could serve the dual
698 purpose of lightning protection and potential grading. Care is needed to ensure that such a
699 system cannot be disconnected from the building, e.g. by removal of test links.

700 Conversely, any earthing system designed for power system fault current may be used for
701 lightning protection system if compliant with BS EN / IEC 62305-1, particularly with regard to
702 high frequency components and down-conductor routing (free of tight bends etc.)

703 5.3.3 Shared Sites

704 Where the customer operates HV (and/or EHV) switchgear, there will be a natural boundary
705 between Network Operator's ownership, and customer ownership. Ideally the Network
706 Operator should not rely on the customer's earthing system to ensure electrical safety around
707 the Network Operator's assets, unless maintenance agreements can be made. In practice, the
708 systems may need to be connected together, but each system should (where reasonably
709 practicable) be designed to be safe (touch voltages) in the absence of any (electrode)
710 contribution from the other system.

711 Neither party should rely on the other's earthing system unless regular maintenance/testing of
712 both systems can be assured.

713 5.3.4 Distribution (or 'Secondary') Substations

714 Distribution (HV:LV) substation earthing is particularly important given that LV system
715 neutral/earth conductors may be connected to, or close to HV earthing systems and
716 consequently could export 'transfer potential' to customer installations. Specific examples for
717 ground mounted substations are given in Section 9, and pole mounted equipment is covered
718 in Section 10.

719 5.3.5 Metallic Fences

720 Substation fences are typically either a) Bonded to the MES, or b) Separately earthed. In
721 general, a bonded design will be required if 2m separation (or barriers/effective insulation)
722 cannot be established to prevent simultaneous contact (hand-hand) between the systems. A
723 separately earthed system is preferable otherwise to minimise the EPR (and resulting touch
724 voltage) that may be accessible externally.

725 In the case of bonded fences, consideration must be given to touch voltages that appear on
726 the fence under fault conditions; an external peripheral electrode may be required 1m around
727 the outside of the fence to achieve acceptable levels. Care must also be taken to ensure that
728 voltage rise is not 'exported' via third party fences etc. that may be in contact with the fence.

729 Refer to Section 6.6 for more details.

730 5.3.6 Provision of Maintenance/Test facilities

731 Facilities for Monitoring Earth System Efficiency (described in Section 6.2.5) should be
732 included at the design stage. Refer to Section 7.5 for information on earth resistance
733 measurements.

734 Test points (e.g. for clamp meter testing) should be shown on earthing drawings.

735 **5.4 Design data**

736 The final design of the earthing system can only be undertaken when sufficient knowledge is
737 available of the proposed physical and electrical arrangements of the substation.

738 As a minimum, the designer must have knowledge of:

- 739 1) value of fault current and supply arrangements (overhead and/or underground cable)
- 740 2) fault duration (or protection settings)
- 741 3) soil resistivity
- 742 4) substation dimensions

743 Any special features about the site, such as subsoil of a corrosive nature and the suitability of
744 the site for driven earth rods or other forms of electrode, must be ascertained. Other relevant
745 features, such as existing earth electrodes, nearby earthed structures, buried pipes or piled
746 foundations are also required to be noted and taken into consideration.

747 In urban areas in particular the substation may be served by an underground cable network
748 which (particularly if incorporating non-insulated sheaths/armours) will make a 'contribution'
749 which may be taken into consideration. Refer to Section 9.4.3 for details on the contribution
750 from typical 11kV networks.

751 **5.4.1 Soil Resistivity**

752 The value of the specific resistivity of the soil may be ascertained by reference to published
753 data or by direct measurement. Table 3 (below) sets out typical values relating to types of soil
754 but these should be used for very preliminary assessments only.

755 [Nationally available soil survey data can also be used for this purpose, e.g.

756 <http://mapapps.bgs.ac.uk/geologyofbritain/home.html>].

Commented [RW3]: Move this link to bibliography. Group to say whether it should be deleted entirely, as websites are subject to move etc?

Table 3 - Typical soil resistivity values

Resistivity in $\Omega \cdot m$

SOIL	RESISTIVITY ($\Omega \cdot m$)
Loams, garden soils, etc	5 – 50
Clays	10 – 100
Chalk	30 – 100
Clay, sand and gravel mixture	40 – 250
Marsh, peat	150 – 300
Sand	250 – 500
Slates and slatey shales	300 – 3,000
Rock	1,000 – 10,000

Multi-layer soil models and computer modelling may offer more effective / optimal designs than typical or 'homogeneous' soil models. Except for some smaller substations, (where the additional expense may not be warranted), direct measurement will normally be necessary prior to detailed design. The recommended method, using the Wenner Array, is described in Section 7.4.

It should be noted that the top layers of soil may be subject to significant seasonal variation due to fluctuating moisture content. Designs should utilise deeper more 'stable' strata wherever possible; the depth of this 'stable' layer is variable depending on soil type and weather/climate.

5.4.2 Fault currents and durations - general

The earthing system must remain intact, and safety voltages must be acceptable for all foreseeable fault conditions. BS EN 50522 describes the need to consider single phase to earth, two phase, and three phase to earth fault current flows, as well as 'cross country' faults in some situations.

The relevant currents for earthing design are summarised in Table 4 below, and described in detail in the following sections.

Commented [RW4]: WPD 33: Single layer or uniform models may be incorrect with regard to touch voltage assessment and Hot Zone contour assessment.

Suggest: Multi-layer soil models and computer modelling may offer more effective / optimal/accurate designs than typical or 'homogeneous' soil models. **Note that safety voltages and voltage contours calculated using 'homogeneous' soil models may be inaccurate.** Except for...
[REJECTED – refer this to S.34]

777 Table 4 – Relevant currents for earthing design purposes

Commented [RW5]: This table now simplified and references included to the relevant sections for more detail

Type of System Earth Supplying Fault	Relevant for EPR and Safety Voltages	Relevant for thermal effects	
		Earth Electrode	Earthing Conductor
Solid Earthing	If known, and if earth-return paths are known to be reliable and rated for duty: Ground return current should be used.	Maximum foreseeable electrode current . This should be taken as the ground return current or value between ground return current and earth fault current , taking into account the loss of any metallic return paths (cable sheath or overhead earth wire) where relevant.	Earth fault currents for all voltage levels at the substation. Three phase (or phase-to-phase) faults should be considered if phase-to-phase fault current can flow through earthing conductors (e.g. separately earthed items of plant, particularly single phase equipment).
Impedance Earthing	Otherwise: Earth fault current should be used. See Section 5.4.3	See sections 5.4.6 and 5.5.2	See section 5.4.5.
Arc Suppression Coil (ASC or Petersen Coil)	ASCs are generally used in addition to solid or impedance earthing. It is therefore usually appropriate to design to the alternative solid or impedance arrangement (as above) which is termed the 'bypass' arrangement. In addition, cross-country faults should be considered if they are likely to be more onerous in terms of magnitude and/or duration. Steady state currents (i.e. the maximum current that can flow in the earthing system without protection operation) may impose additional requirements on the designer.		
	Refer to Section 5.4.3	See section 5.4.6.	See Section 5.4.5
Notes:			
Fault currents associated with all voltages levels in substations must be considered. The appropriate protection clearance times for each voltage level must be applied – refer to Section 5.4.2			

778

779 Refer to Table 1 in BS EN 50522 for further details.

780

781 5.4.3 Fault current growth

782 Consideration should be given to future network alterations and alternative running
783 arrangements. A margin should be added to allow for future changes without detailed
784 assessment (e.g. typical 20% increase, unless more accurate information is available).

785 If fault levels are expected to approach the switchgear rating in the foreseeable future, the
786 **switchgear rating should be used as the design figure**. In any case the rating of the
787 earthing system should be reviewed if plant is to be upgraded such that higher fault levels may
788 be possible.

789 5.4.4 Fault currents for EPR and safety voltage calculations

790 The fault current applicable to EPR calculation (and therefore safety voltage calculations) is
791 the maximum (symmetrical RMS) current to earth (**earth-fault current**) that the installation will
792 see under fault conditions.

793 **Normal operating time** of protection relays and breakers should be used for safety voltage
794 calculations, rather than worst-case (back-up) protection clearance times.

Cable sheath or earth wire return paths should be included if they are reliable and rated for duty, in which case the resultant (smaller) **Ground Return Current** may be used for design purposes, since it is this current (or a fraction of it) that flows into the local electrode system and gives rise to EPR. Designs should consider touch voltage that may result under various failure scenarios and for all voltage levels at a substation.

If specific protection settings are not available, the design should use 'upper bound' (slowest) clearance times associated with normal protection operation, as specified by the network operator.

These considerations apply whether the source substation (i.e. that supplying the fault) is impedance or solidly earthed. EPR should be calculated for all voltage levels at any substation, for faults at the substation and on circuits fed from it. LV faults can usually be shown to be insignificant in this regard.

For substations with Arc Suppression Coils (ASCs), the design should be based on the most onerous (in terms of magnitude and/or duration) earth-fault or cross-country fault. In addition, the design should consider long duration EPR conditions which may give rise to near 'steady state' voltages on equipment or fences etc.

Note: In many cases the 'solid' earth fault level is an appropriate design figure for safety voltage assessment on ASC systems, since this is likely to represent a realistic upper-bound. The need to consider alternative fault scenarios / currents is subject to operational experience / risk assessment.

5.4.5 Fault currents and clearance times for conductor size (thermal effects)

Conductor sizing calculations should be based on **backup** protection clearance time, i.e. the design shall allow for failure of primary protection without damage to the earthing system. In the absence of network specific data, the following operating times should be assumed:

Up to and including 132 kV: 3 seconds (excluding LV)

275 kV and higher voltages: 1 second

For earthing conductors and electrodes in substations it is recommended that the design fault-current should be the maximum symmetrical three-phase fault current value, or other worst case foreseeable value if greater.

NOTE: The decision of whether to include the 'missing return path' scenario is largely dependent on operational experience and risk assessment. For example, the likelihood of complete failure of the metallic return path will be higher for a single overhead earth wire than it would be for a triplex (3 x bunched single cores) cable network arranged in a ring.

The maximum fault current applies wherever this may be borne by one spur connection, in which case that spur shall be sized accordingly. In grid (mesh) earthing designs there will often be parallel paths to share the current; if the current is to flow in two or more paths (e.g. around a ring) then each individual path shall be sized to no less than 60% of the fault current.

Installations connected to, or part of the one where the highest fault current occurs, may only be required to carry a portion of that current and the earth conductors may be sized accordingly. For example, in lower voltage areas peripheral to a higher voltage one, their earth conductors must be sized to meet the lower voltage fault current and calculations may show that they are also adequate for their proportion of the HV or EHV fault current.

Conductor ratings are given in Section 5.5.1.

5.4.6 Fault currents and times for electrode size calculations (thermal effects)

The discrete earth electrode shall at all times retain its functional properties, i.e. both its current carrying capability and its value of resistance to earth. For these reasons the temperature rise of the electrode conductor and the density of current dissipation from electrode to soil, during the passage of fault current through it, shall be limited.

Electrodes are thus subject to thermal requirements of the electrode material due to passage of fault current, and current limits imposed by the electrode-to-soil interface as described below:

- a) 'Conductor Thermal requirements' are satisfied by appropriate choice of material and cross sectional area for each electrode and its connection to the main earthing system (Section 5.5.1).
- b) 'Surface Current Density' requirements are satisfied by ensuring sufficient electrode surface area. In some cases it will be necessary to install additional electrode(s) to satisfy this requirement, particularly if the electrode resistance requirements can be met with a relatively small electrode system.

Further detail – surface current density

The soil surrounding earth electrodes is of a much higher sensitivity than the electrode conductor material and thus the passage of current through the soil will develop, relatively, a much higher temperature rise. The effect of high temperature in the soil causes drying of the surrounding soil, thus further increasing its resistivity, or even the production of steam which can force a separation between the electrode conductor and its interfacing soil.

For this reason the current rating of an earth electrode is specified in terms of its surface current density (A/mm^2), and is dependent on soil resistivity. As a consequence the current rating of buried electrodes in practical installations is very much less than equivalent sized above-ground earthing conductors (Section 5.5.2 gives typical ratings).

Where a multi-mesh buried main earth grid is installed, the density of fault current in the earth electrode should rapidly reduce as the distance from the point of fault increases. Provided, therefore, that a sufficient quantity of grid conductor is buried and is well distributed, the surface current density will generally be satisfactory and high surface temperature restricted to a small area close to the fault point and thus have negligible effect on the value of total earth electrode resistance or on the efficacy of the earthing system as a whole.

Design fault currents and clearance times for electrode ratings

The surface area of the main electrode through which the fault current flows to ground shall, as a minimum, be sufficient to disperse the maximum foreseeable **electrode current** (i.e. the total current flowing into the electrode system).

The **ground return current** (or **earth fault current**) should be used in calculations if the electrode current(s) are not known. Higher values may be appropriate for ASC systems, as described below.

NOTE 1: The maximum current flow into individual electrode groups (where there is more than one) should be assumed to be 60% of the ultimate overall figure used above.

NOTE 2: Reduction factors for neutral current flows (multiple earthed systems) and sheath/earth wire return currents may be applied in the normal way to calculate ground return current or electrode current.

NOTE 3: Faults at all voltage levels in each substation shall be considered.

The possibility of sheath failure or aerial earth wire failure can give rise to higher than normal ground return current (and consequent electrode current) and should be considered where necessary, as described in the previous section.

For ASC systems*, the **electrode current** calculation must consider **cross-country** faults since these are more likely on ASC systems. The electrode current in such circumstances can sometimes exceed the normal calculated **ground return current**. **Solid earth-fault** level or **phase-to-phase** fault levels should be used if there is any doubt, even if the 'bypass' is via resistor or reactor. The value to be used is subject to risk assessment and operational experience.

* NOTE: This is particularly relevant where earth faults are not automatically disconnected within 3 seconds.

The relevant clearance times are for **backup** protection operation as described in the previous section, since it is imperative that the earthing system remains intact if faults are slow to clear.

Long term (steady state) current flows can cause drying of soil, and must be considered in addition to normal faults (see below).

Relatively rare faults (e.g. bushing failures or internal faults) which may cause an ASC or impedance to be shorted out should be considered if necessary, based on operational experience.

Long term current flows

If significant ground-return current can flow for prolonged duration (i.e. without protection operation), the effect of this current should be considered separately; it can lead to drying at the electrode-soil interface and impose a steady state (or 'standing voltage') on plant which can require additional measures to ensure safety. This is relevant for ASC systems where earth faults are not automatically disconnected, or where moderate current can return via earth to the system neutral in normal circumstances due to un-balanced network capacitance or leakage. The magnitude of this current should be taken as the ASC coil rating or earth-fault protection relay current settings.

NOTE: A maximum surface current density of 40 A/m² is appropriate for long term current flows. This is unlikely to cause drying at the electrode-soil interface.

Surface area and current density requirements

In many cases the electrode surface area requirement is satisfied by normal design practice based on achieving a satisfactorily low earth resistance value; care is needed for systems where a small electrode system is otherwise thought to be sufficient.

The appropriate fault current, as described above, should be divided by the surface area of the electrode system (as described in EREC S34 section XXX) to demonstrate that the current density at the electrode-soil interface is within limits given in Section 5.5.2.

It is permitted to use the surface area of all connected electrodes (main and auxiliary) in this calculation. However, it is good design practice, wherever possible, to ensure that sufficient main electrode meets this requirement.

NOTE: In situations such as substations in urban areas where the overall Ground Return Current is significantly increased by interconnection to a larger network or other auxiliary electrode system, dividing this **overall ground return current** (returning via a wide area electrode system, shown as I_E in EREC S34 Figure 3.2) into the **local** electrode surface area will provide a safety margin. It is permissible, for design economy, to calculate the local electrode current (i.e. by evaluation of the ground return current 'split' between the local electrode system and other paths, shown as I_{ES} in S34 Fig 3.2), and dividing this resultant electrode current into the local electrode area. This approach should be used with caution, or combined with the risk assessment approach outlined in Section 5.7 as

failure of auxiliary electrode connections etc. could result in overheating/failure of the local electrode system under fault conditions.

Limiting values of surface current rating, calculated for some typical electrodes are given in Table 8 below (section 5.5.2).

5.5 Conductor and Electrode Ratings

The earthing system must remain intact following a protection failure as described in section 5.4.5.

5.5.1 Earthing Conductors and Electrodes

Earthing conductors should normally be selected from standard copper or aluminium sections; this does not exclude the use of other materials if longevity and resilience (especially to corrosion) can be demonstrated. For alkaline or acidic soils (i.e. those where the pH is greater than 10 or less than 4), or in other situations where corrosion is likely, it may be necessary to oversize electrodes, or to apply other measures to give a reasonable lifetime. Refer to BS 7430 for further details.

Based on maximum fault clearance times, the conductor temperature should not exceed 405°C for copper and 325°C for aluminium based on an initial temperature of 30°C. A lower limit of 250°C (absolute) is relevant for bolted connections, since extreme thermal cycling can lead to loosening over time.

Table 5 and Table 6 below give declared current ratings for a range of standard conductor sizes for both 1 second and 3 second fault duration times. The short time rating of other conductors can be calculated from formulae given in EREC S34.

Table 5 - CONDUCTOR RATINGS (COPPER)

(a) 405°C maximum temperature (Copper)

These copper sizes are based on a temperature rise of 375°C occurring in 3 seconds and 1 second above an ambient temperature of 30°C (i.e. achieving a maximum temperature of 405°C) with the currents in columns (a) and (b) respectively applied to the conductors. For each substation it will be necessary to specify whether column (a) or (b) should apply.					
Fault Current (kA) Not Exceeding		Copper Strip (mm)		Stranded Copper Conductor	
(a)	(b)				
(3 secs)	(1 sec)	Single (spur) Connections	Duplicate or Loop Connections	Single (spur) Connections	Duplicate or Loop Connections
4		25 x 4	25 x 4	70mm ²	70mm ²
8		25 x 4	25 x 4	70mm ²	70mm ²
12		25 x 4	25 x 4	95mm ²	70mm ²
13.2		31.5 x 4	25 x 4	120mm ²	70mm ²
18.5		40 x 4	25 x 4	150mm ²	95mm ²
22		50 x 4	31.5 x 4		120mm ²
26.8		40 x 6.3	40 x 4		150mm ²
40		-	50 x 4		
	40	50 x 4	31.5 x 4		
	60	50 x 6.3	50 x 4		
	63				
<p>NOTE:</p> <p>Equivalent sizes for stranded conductor include, but are not limited to the following, quoted as number of strands/strand diameter:</p> <p>70mm²=19/2.14mm or 7/3.55mm(e.g. HDC); 95mm²= 37/1.78mm; 120mm² =37/2.03mm; 150mm² =37/2.25mm.</p> <p>Consideration of corrosion risk may lead to the decision to specify minimum strand diameters (e.g. 1.7mm or larger as per BS EN 50164-2). A minimum strand diameter of 3mm is preferred by some DNOs for longevity of the electrode system particularly if corrosive soils exist.</p>					

Commented [RW6]: Meeting notes suggest BS7884 or BS13602 provide an alternative spec.

956

(b) 250°C maximum temperature (Copper) – bolted connections

These copper sizes are based on a temperature rise not exceeding 250°C , from an ambient temperature of 30°C with the currents in columns (a) and (b) respectively applied to the conductors. For each substation it will be necessary to specify whether column (a) or (b) should apply. These figures are generally applicable to bolted connections between tapes or lugs etc. which offer a relatively small thermal mass.					
Fault Current (kA) Not Exceeding		Copper Strip (mm)		Stranded Copper Conductor	
(a)	(b)				
(3 secs)	(1 sec)	Single (spur) Connections	Duplicate or Loop Connections	Single (spur) Connections	Duplicate or Loop Connections
4		25 x 4		70mm ²	70mm ²
8		25 x 4		95mm ²	70mm ²
12		25 x 6		120mm ²	95mm ²
13.2		25 x 6		150mm ²	95mm ²
18.5		38 x 5		185mm ²	120mm ²
22		40 x 6			150mm ²
26.8		50 x 6			185mm ²
40		-	40 x 6		
	40	40 x 6	50 x 3		
	60	-	50 x 6		
	63	-	50 x 6		
<p>NOTE:</p> <p>Equivalent sizes for stranded conductor include, but are not limited to the following, quoted as number of strands/strand diameter: 70mm²=19/2.14mm or 7/3.55mm(e.g. HDC); 95mm²= 37/1.78mm; 120mm² =37/2.03mm; 150mm² =37/2.25mm.</p> <p>Consideration of corrosion risk may lead to the decision to specify minimum strand diameters (e.g. 1.7mm or larger as per BS EN 50164-2). A minimum strand diameter of 3mm is preferred by some DNOs for longevity of the electrode system particularly if corrosive soils exist.</p>					

957

958

959

Table 6 - CONDUCTOR RATINGS (ALUMINIUM)

(a) 325°C maximum temperature (Aluminium)

These aluminium sizes are based on a temperature rise of 295°C occurring in 3 seconds and 1 second above an ambient temperature of 30°C with the currents in columns 1(a) and 1(b) respectively applied to the conductors. For each substation it will be necessary to specify whether column 1(a) and 1(b) should apply.					
Fault Current (kA) Not Exceeding		Aluminium Strip (mm)		Stranded Aluminium Conductor (mm)	
(a)	(b)				
(3 secs)	(1 sec)	Single (spur) Connections	* Duplicate or Loop Connections	Single (spur) Connections	Duplicate or Loop Connections
4		20 x 4	20 x 2.5	70mm ²	70mm ²
7.5		25 x 4	20 x 4	120mm ²	70mm ²
12		40 x 4	25 x 4		120mm ²
13.2		50 x 4	25 x 4		120mm ²
18.5		40 x 6	40 x 4		150mm ²
22		50 x 6	50 x 4		
26.8		60 x 6	40 x 6		
40		60 x 6	50 x 6		
	40	50 x 6	50 x 4		
	60	80 x 6	50 x 6		
<p>NOTE:</p> <p>Equivalent sizes for stranded conductor include, but are not limited to the following, quoted as number of strands/strand diameter:</p> <p>70mm²=19/2.14mm or 7/3.55mm; 95mm²= 37/1.78mm; 120mm²=37/2.03mm; 150mm²=37/2.25mm.</p>					

966

967

(b) 250°C maximum temperature (Aluminium) – bolted connections

These aluminium sizes are based on a temperature rise not exceeding 250°C in 3 seconds and 1 second from an ambient (initial) temperature of 30°C with the currents in columns 1(a) and 1(b) respectively applied to the conductors. For each substation it will be necessary to specify whether column 1(a) and 1(b) should apply. These figures are generally applicable to bolted connections between tapes or lugs etc. which offer a relatively small thermal mass.					
Fault Current (kA) Not Exceeding		Aluminium Strip (mm)		Stranded Aluminium Conductor (mm)	
(a)	(b)				
(3 secs)	(1 sec)	Single (spur) Connections	* Duplicate or Loop Connections	Single (spur) Connections	Duplicate or Loop Connections
4		20 x 4	20 x 2.5	70mm ²	70mm ²
7.5		25 x 5	25 x 3	120mm ²	70mm ²
12		50 x 4	25 x 5	185mm ²	120mm ²
13.2		50 x 4	25 x 5		120mm ²
18.5		50 x 6	50 x 4		185mm ²
22		60 x 6	50 x 4		
26.8		-	40 x 6		
40		-	60 x 6		
	40	60 x 6	40 x 6		
	60	-	60 x 6		
<p>NOTE:</p> <p>Equivalent sizes for stranded conductor include, but are not limited to the following, quoted as number of strands/strand diameter:</p> <p>70mm²=19/2.14mm or 7/3.55mm; 95mm²= 37/1.78mm; 120mm²=37/2.03mm; 150mm²=37/2.25mm.</p> <p>Duplicate or loop connections have been rated to carry 60 per cent of the full fault current.</p>					

968

969

Table 7 - Cross sectional areas for steel structures carrying fault current

These sizes are based on the maximum temperature achieved after the passage of fault current for 3 seconds and 1 second from an ambient (initial) temperature of 30°C. For each substation it will be necessary to specify whether column 1(a) or 1(b) should apply.			
Fault Current (kA) Not Exceeding		250°C (applicable to bolted structures)	400°C (applicable to welded/continuous structures which are galvanised)
(a)	(b)		
(3 secs)	(1 sec)	mm²	mm²
4		109	91
7.5		204	171
12		327	273
13.2		359	301
18.5		503	421
22		599	501
26.8		729	610
40		1087	910
	40	628	525
	60	942	789

5.5.2 Electrode Surface Current Density Ratings

Table 8 below shows the current rating of typical electrodes. The limiting factor tends to be heating at the electrode-soil interface, consequently the ratings are dependent on soil resistivity.

Table 8 - MAXIMUM CURRENT RATING OF TYPICAL ROD, TAPE AND PLATE ELECTRODES

Soil Resistivity $\Omega \cdot m$	3 – Second Current Rating				1 - Second Current Rating			
	Rod 16mm Dia. A (per metre length)	Plate 915 x 915mm A	Plate 1220 x 1220mm A	25 x 4 mm tape	Rod 16mm Dia. A (per metre length)	Plate 915 x 915mm A	Plate 1220 x 1220mm A	25 x 4 mm tape
10	69.7	2322	3135	80.3	120.7	4022	6979	138.9
30	40.2	1340	2217	46.4	69.7	2322	4128	80.3
40	34.9	1161	1568	40.1	60.4	2011	3575	69.3
50	31.2	1038	1402	35.9	54	1799	3197	61.7
60	28.4	948	1280	32.7	49.3	1642	2919	56.8
70	26.3	878	1185	30.3	45.6	1520	2702	52.6
80	24.6	821	1108	28.3	42.7	1422	2528	49.2
100	22	734	991	25.4	38.2	1272	2261	44
150	18	600	810	20.7	31.2	1038	1846	35.9
200	15.6	519	701	17.9	27	899	1599	31.2
250	13.9	464	627	16	24.1	804	1430	27.8
300	12.7	424	572	14.6	22	734	1305	25.4

In most practical installations the actual values of surface current density will be considerably less than the above limiting values, due to the quantity of bare buried conductor (electrode) employed in the installation to provide effective bonding and in some installations where extra electrodes have been added, to comply with the touch potential limits. Further detail is given in EREC S34 – Equation to go in S34 and to be referenced from here; note that this current density limit is independent on electrode material, and therefore the limits can be applied to rebar/piling/other 'fortuitous' or auxiliary electrodes, providing that temperature rise in these structures under fault conditions will not cause issues such as cracking/distortion etc.

989 Where an electrode is encased in a material such as concrete, or material/agent other than
990 surrounding soil, the surface area calculation should be carried out at the electrode-material
991 interface, using the surface area of the metallic electrode itself and the properties of the 'agent'.
992 In some cases it will also be necessary to carry out a similar calculation at the interface of the
993 'agent' with surrounding soil, noting that the larger surface area offered by the agent will apply.

994 A well designed earthing system should provide sufficient surface area to satisfy this
995 requirement without reliance on rebar or other fortuitous / auxiliary electrodes.

996 **5.6 Design Assessment**

997 The assessment procedure outlined in 5.6.1 begins with an approximation which, if furnishing
998 satisfactory results, avoids the need for a more detailed assessment. If the results of this
999 approximate assessment indicate that the safety criteria could be exceeded or the rise of earth
1000 potential is considered to be excessive, then the more refined assessment should be
1001 employed.

1002 When an entirely theoretical approach is used for assessing the design of an earthing system,
1003 doubts on the reliability of the result may arise due to uncertainties as to the correct value of
1004 soil resistivity to be used or of the effects that other buried structures may have. In these
1005 circumstances recourse may have to be had to direct measurement to obtain a more reliable
1006 result.


1007 Recommended methods of measurement are given in Section 7.5. On the basis that the earth
1008 electrode system will not yet be installed, measurement may be made on representative test
1009 electrodes and the results extrapolated to the intended final design. Measurement may be
1010 delayed until a sufficiently representative part of the intended system is installed to obtain a
1011 better prediction of any improvements necessary. In any event a final check measurement of
1012 the completed installation is recommended prior to energisation.

1013 **5.6.1 Design flowchart**

1014 The general approach is summarised in the flowchart below:

1015

1016



5.6.2 Assessment Procedure

An approximate assessment considers both the internal and external earth fault conditions as explained above but disregards any contribution that external electrodes, e.g. overhead line earth-wires or cable sheaths, may have. An approximate assessment may be all that is required in many cases providing compliance with the safety criteria is demonstrated.

By reference to the flowchart above (Section 5.6.1):

- 1) Establish the soil resistivity (by measurement or enquiry)
- 2) Estimate the resistance of the site electrode system (using computer modelling or calculations as detailed in EREC S34).
- 3) Obtain the worst-case fault current flowing through the electrode system, disregarding the effect of 'fortuitous' electrode systems or cable sheath/earthwire return paths.
- 4) Estimate the EPR, which is the product of resistance (point 2 above) and current (point 3).
- 5) If the value derived in (4) above does not exceed 2x the permissible 'touch' potential then no further assessment needs to be done. The finalised design of the earthing system may be prepared taking into account the earthing and electrode conductor ratings.

If the value derived under (4) above exceeds the appropriate safety voltages by a factor of 2 or more, then a more refined assessment shall be made as detailed below.

- 6) Determine the soil resistivity by measurement.
- 7) Estimate the value of the substation earth electrode system resistance, including the contributions made by any overhead earthwires and/or earthed cable sheaths radiating from the site using the preliminary design assessment layout and the data provided in EREC S34.
- 8) Obtain the appropriate total values of system earth fault current for both an internal and external earth fault and deduce the greater value of the two following quantities of earth fault current passing through the earth electrode system. Refer to EREC S34 for guidance on this evaluation.
- 9) For an internal fault, establish the total fault current less that returning to any local transformer neutrals and that returning as induced current in any earthwire or cable sheath/armour.
- 10) For an external fault, that returning to local transformers less that returning as induced current in any earthwire or cable sheath/armour.
- 11) Estimate the rise of earth potential (EPR) based on the product of items (7) and (9) or (10) above, whichever is the greater.
- 12) If the EPR value derived under (11) above exceeds 2x the appropriate touch or step voltages, an assessment covering touch, step, and transfer potentials shall be made. The design should consider LV, telecoms, and remote systems where relevant (ref: EREC S34 Section XXX)

13) If the earthing system is safe against 'touch' potential it will almost always be safe against 'step' potential*, although special consideration may be needed in certain situations such as wet areas, livestock, etc.

Reference should be made to **EREC S34** for equations giving ground surface potential contours; the touch potential is the difference between EPR and ground surface potential up to 1m from plant / bonded items. Computer modelling may be necessary for complex systems.

Depending on the results of the evaluation, further improvements in the design of the earth electrode system may be necessary until the appropriate safety criteria for touch, step and transfer potentials are met and any necessary isolation or additional insulation is provided to avoid contact with transferred potentials which exceed the appropriate safety limit.

5.6.3 Methods to improve design (Mitigation measures)

Following assessment, if the safety criteria are not met, the designer shall consider ways to either a) reduce overall EPR, or b) reduce the step/touch voltages.

5.6.3.1 EPR reduction

As described in 4.4.1, there is no specified limit to the rise of earth potential of the substation and the ultimate design limit is dependent on a number of factors. However, improvements may sometimes be justified to lower this value by reducing the value of the earth electrode resistance. If, for example, the surface potential outside the substation exceeds that which is acceptable to third parties in that area (e.g. telecoms or pipeline operators), then lowering the earth electrode resistance (and consequent EPR) may be considered.

Reduction of earth resistance by extending electrode area may increase transfer potential onto third party metallic services and this must be considered in the design. Note that it may be cheaper and more practical instead to protect the other authorities' plant by isolation or additional insulation.

EPR (arising from local faults) can generally be reduced by one or more of: a) earth resistance reduction, b) fault level reduction, or c) reducing the ground return component.

a) Is probably more practical to achieve by installation of additional electrode.

b) Can be achieved by impedance earthing (section 4.5.1), or changes to running arrangements, or possibly more accurate calculation of earth fault level including earth resistance values (which may be of benefit in marginal situations).

c) Can be achieved by lower impedance metallic return paths (e.g. enhanced cable sheaths or earth-wires, or undergrounding a section of overhead line to make a complete cable circuit).

An excessive EPR arising from transfer voltage, e.g. carried along the cable sheath from the source substation, can be reduced by lowering earth resistance as a) above, or by introducing a sheath break into the cable (e.g. by using an insulated gland or un-earthed overhead line section); special care is required in such circumstances to ensure that an individual cannot contact two earthing systems simultaneously. There may be other considerations which make a sheath break unacceptable or ineffective in some circumstances. Alternatively, measures

* As stated in BS EN 50522: As a general rule meeting the touch voltage requirements satisfies the step voltage requirements, because the tolerable step voltage limits are much higher than touch voltage limits due to the different current path through the body.

1096 could be employed to lower the EPR at the source substation. In any case, the design must
1097 be re-assessed to consider these revised arrangements.

1098 5.6.3.2 Touch Voltage reduction

1099 If reduction of EPR is not practicable or economic, touch voltage can be reduced by adopting
1100 measures to equalise potential between an operator's hands and feet; generally these
1101 measures involve additional bonded grading electrode or mesh under the operator's position,
1102 or insulated platforms.

1103 Equations are provided in **EREC S34** which give simple touch voltage calculations.

1104 The touch and step voltages must be re-calculated or re-modelled following any changes to
1105 the electrode layout. The touch voltages appearing on external parts of a substation
1106 (fences/doors/substations) must also be considered as these could cause issues for members
1107 of public.

1108 In some circumstances, asphalt (tarmac) or similar ground coverings may be used to justify an
1109 increase in the permissible limits so that the touch voltages are acceptable (see Section 4.4.1).
1110 Protection enhancement (faster fault clearance) may be also explored in similar
1111 circumstances, since permissible limits for touch/step voltage are higher if faster fault
1112 clearance times can be achieved. These two measures should not be considered an
1113 alternative to a properly designed earthing system and should be used only as a last resort, or
1114 in conjunction with the risk assessment approach outlined below.

1115 5.7 Risk Assessment

1116 In some situations it may not be reasonable to achieve compliance with permissible safety
1117 voltages at all locations in and around a substation. Nevertheless, in some locations (e.g.
1118 unmanned sites with restricted access), it may be deemed to be an acceptably low risk. It is
1119 recognised in new standards that some risk must be accepted in order to provide electrical
1120 infrastructure to society.

1121 As set out in BS EN 50522, risk assessment is one of the acceptable tools for analysis of
1122 situations where the cost of removing an identified risk appears to be disproportionately high.
1123 A risk-based approach needs to consider the statistical probability of injury occurring, and to
1124 weigh this against the cost needed to mitigate against that risk.

1125 Risk Assessment should only be used in circumstances where strict compliance with
1126 permissible safety voltage limits cannot be achieved, and where there are valid and well
1127 documented reasons for this. It should be used only as a last resort, as described in the
1128 flowchart in Section 5.6.1. In practice it is most appropriate outside an installation as it should
1129 almost always be possible to achieve safe (deterministic) step and touch voltages within site
1130 boundaries.

1131 A worked example is provided in Section 11.

1132 5.7.1 Methodology

1133 The use of risk assessment needs to be justified, e.g. when achieving safe (deterministic)
1134 touch and step potentials is not practicable and economical.

1135 The individual risk of fatality per year (IR) for a hypothetical person is calculated from the mean
1136 number of significant EPR events (f_n) per annum, the probability of exposure (P_E) and the
1137 probability of fibrillation (P_{FB}). A simplified formula applicable to power system applications is:

1138

Commented [RW7]: From new S34:

$$IR \cong f_n * P_E * P_{FB}$$

This simplified formula is in line with that presented in Annex NB of IEC 50522.

NOTE: A hypothetical person describes an individual who is in some fixed relation to the hazard, e.g. the person most exposed to it, or a person living at some fixed point or with some assumed pattern of life [R2P2]. To ensure that all significant risks for a particular hazard are adequately covered, there will usually have to be a number of hypothetical persons considered.

P_E and P_{FB} are dimensionless quantities; P_E relates to the proportion of time that an individual is in contact with the system. P_{FB} can be derived from body current calculations and fault clearance times, with reference to Figure 20 of IEC 60479-1 [xx]. The assessment should in the first instance use the higher P_{FB} for the band (e.g. 5% for the 0-5% band AC-4.1 between lines C1 and C2). An interpolated rather than upper-bound P_{FB} may be justifiable in some circumstances.

It is recommended that the large area dry contact impedance model 'not exceeded for 5% of the population' is used (Table 1 of IEC 60479-1:2005) unless specific circumstances apply.

The calculated individual risk is then compared to a broadly acceptable risk of death per person per year as defined in the HSE Document "Reducing Risk Protecting People" (R2P2) [ref xx]. If the risk is greater than 1 in 1 million (deaths per person per year), but less than 1 in 10,000, this falls into the tolerable region and the cost of reducing risk should then be evaluated using ALARP principles (as low as reasonably practicable) taking into account the expected lifetime of the installation and the HSE's present value for the prevention of a fatality (VPF) to determine the justifiable spend for mitigation.

Where the justifiable spend is significantly less than the cost of mitigation, risk assessment may justify the decision whether or not to take mitigating action. Mitigation may include (and is not limited to) new or relocated barriers/fences, insulating paint, earthing redesign, substation relocation, restricted access / signage, protection enhancements, reliability improvements, EPR reduction, insulated ground coverings or fault level modification.

5.7.2 Typical applications

Typical applications for risk assessment may be those outside an installation, on the basis that it is almost always possible to control step and touch potentials within the confines of a substation by using appropriate buried electrode and/or ground coverings. Risk assessment is, in any case, not appropriate for situations where the presence of an individual increases the likelihood of an earth fault, e.g. switching operations or work in substations or HV installations.

Case Study 1 in Section 11 describes a typical example of a fence that has been built close to a substation with high EPR. Under substation fault conditions, touch voltages exceeding permissible design limits can appear around the fence, due to voltage differences between the elevated soil potential and the fence. The risk assessment approach allows the need for mitigation measures to be evaluated.

Commented [RW8]: This bit added in response to recent customer enquiries in solar farm.

6 Construction of Earthing Systems

6.1 General Design Philosophy

Above ground connections may use copper or aluminium conductors. Metal structures may be used to provide connections between equipment and the earth grid where appropriate.

Below ground earth grids will normally be installed using copper conductor.

When designing and installing both above and below ground earthing installations the risk of theft and corrosion must be considered and mitigation measures put in place where necessary.

6.1.1 Materials

- The use of copper earthing conductor is preferable due to its electrical and material properties.
- Copper tape and (hard drawn) stranded copper conductor (min strand diameter 2mm) may be used as buried electrode.
- Bare aluminium or copper rope (fine braided) conductors must not be used underground in any circumstances due to risk of accelerated corrosion.
- Aluminium (which is less prone to theft) may be used at least 150mm above ground.
- Galvanised steel may be used as supplementary electrode where it is already installed for other reasons. Consideration should be given to the risk of corrosion over the lifetime of the installation. [Galvanised steel has an electropotential different to that of copper and can erode quickly if connected to a system which has copper electrodes]
- In very hostile environments it may occasionally be necessary to use more resilient materials such as stainless steel.

6.1.2 Avoiding Theft

At the design stage all exposed copper electrode should be reduced to a minimum. On new installations above ground exposed copper and aluminium sections should be fixed using anti-theft fixing techniques. See Section 6.3.1 for conductor fixing detail.

At new and existing high risk sites the use of additional anti-theft precautions must be considered.

Precautions above ground may include:

- application of anti-climb paint on above ground sections and / or above ground copper may be painted to look like aluminium or galvanised steel;
- fitting galvanised steel anti-theft capping over the conductor to a height of at least 3 m or the equipment position;
- fitting steel banding around structures and pinning the fixings;
- stamping copper tape electrode with the owner's name;
- earth connections to such items as metal cladding, metal structures, metal door frames or any other metallic panels should be made inside buildings;
- additional site security precautions such as the application of alarms, electric perimeter fences, CCTV etc.;
- use of forensic traceable liquids;
- avoiding yellow/green insulated coverings (use e.g. grey instead).

Precautions below ground may include:

- placing concrete or concrete anchor blocks over buried electrode;
- attaching earth rods every few metres to prevent removal of electrode;

Commented [RW9]: Chosen as consistent with 50522, group to consider also 'Installation' or 'Practical applications' etc

- 1224 • pinning electrode at least every 300 mm where it is installed in concrete trench work or
- 1225 over concrete plinths;
- 1226 • laying electrode in conductive concrete or similar materials.

1227 Earthing conductors located in pre-formed concrete trenches (or similar) containing power
1228 and/or multicore cables should be fixed to the walls near the top (e.g. 100mm from the top).
1229 Where possible they should be concealed or otherwise protected against theft.

1230 **6.2 Jointing Conductors and Equipment Connections**

1231 **6.2.1 General**

1232 Exothermic welded, brazed and compression type joints are acceptable above and below
1233 ground.

1234 Bolted joints are only permissible above ground. For replacement work following theft this may
1235 not be initially practical but any temporary bolted underground joints must be replaced to make
1236 the repairs permanent.

1237 For connections made to equipment welded joints may be possible, but in the majority of cases,
1238 bolted joints will be necessary. The provision of bolted earth connections on equipment needs
1239 special consideration to achieve a low resistance arrangement which can withstand the
1240 maximum earth fault current without deterioration. Purpose designed connections should
1241 preferably be provided by the equipment manufacturer.

1242 Bolted connections should preferably be of the double bolt / double hole lug fixing type,
1243 however this generally requires drillings to be provided at the equipment procurement stage.
1244 Where single bolt / single hole lug fixings are provided the application of a washer and second
1245 (lock) nut provides extra security.

1246 With aluminium conductors in particular surface preparation is critical to achieving connections
1247 with ongoing low resistance.

1248 Nuts, bolts and washers are to be of high tensile stainless steel or galvanised steel, except for
1249 transition washers used for joining dissimilar metals.

1250 **6.2.2 Transition washers**

1251 A transition washer may be used to minimise corrosion when joining dissimilar metals with a
1252 bolted connection. Transition washers designed for copper-aluminium joints shall be surface
1253 penetrating, grease protected washers manufactured from corrosion resistant copper alloy to
1254 BS2874 (grade CZ121). They are designed to provide a stable corrosion resistant interface
1255 between aluminium and copper or tinned copper, and are usually provided as a pack including
1256 appropriate matched nuts, bolts and washers.

1257 Different transition washers may be required for connections from copper to galvanised metal.

1258 Transition washers tend not to be widely used for connections between aluminium and zinc
1259 coated (galvanised) steel, because zinc and aluminium are very close in the galvanic series.
1260 Such connections are likely to corrode however once the zinc coating has been lost, and
1261 therefore precautions should be taken to exclude moisture by use of an appropriate grease or
1262 paint applied after the joint is made.

1263 All bolted joints should be painted with two coats of bitumen paint, where practicable, as an
1264 aid to preventing corrosion.

6.2.3 Copper to Copper Connections

Tape to tape connections must be brazed or exothermically welded.

Stranded to stranded connections must be exothermically welded or joined using compression joints.

Stranded to tape connections must be exothermically welded or a lug must be compressed onto the stranded conductor, which for underground use is bolted and then brazed or welded onto the copper tape. For above ground purposes, the lug may be bolted to the tape but should preferably have a double bolt fitting.

Soft soldered joints (e.g. lead-tin or lead free solder) shall not be used.

6.2.4 Copper to Earth Rods

Connections must be brazed or exothermically welded. Bolting and U-bolts are not acceptable. [Except for smaller distribution substations where hot works may not be practicable].

6.2.5 Electrode Test Points

Electrode test points may be required either at the rod top for long single rods or inline between a rod group and the main earthing system. To allow individual rod resistance values to be tested with a clip-on meter and facilitate electrode tracing all test points should be suitably constructed to allow the test clamp to fit and to avoid corrosion.

Test links are not recommended, but where installed special procedures must be adopted to avoid inadvertent disconnection and to permit safe management/testing techniques.

A test point associated with pile cap connections is useful but only if the design of the rebar is electrically separated from the rest of the site. At most sites the rebar will be connected together and while this provides an excellent earth, testing the individual pile cap earths is impossible. In these cases separate earth pins should have been provided in the design perhaps for high frequency and/or lightning protection which will allow testing between individual earth rods and the main earth grid.

6.2.6 Copper to Equipment (Steel, or Galvanised Steel) Connections

Connections should, wherever possible, be in the vertical plane. Remove paint from the metal at joint position on the equipment earth, sand metal smooth and apply neutral jointing compound. Drill the copper tape to accommodate the bolts (normal diameter is 10 mm) and then tin the complete contact area. The bolt holes must be less than one-third the width of the tape. Failing this a copper flag must be jointed to the copper tape and the holes drilled into this. A two bolt fixing is preferred, unless a suitably rated fixing is provided by the manufacturer. Copper joint surfaces, once drilled should be cleaned using aluminium oxide cloth (grade 80). Copper is tinned at all bolted connections; the tinning needs to be thin, and should not exceed an average of 0.5 mm, otherwise it will 'flow' from bolted sections under pressure. Neutral jointing compound is then to be applied to the joint faces.

The same procedure should be used when joining to galvanised steel, in which case the zinc coating shall be removed from the joint faces.

6.2.7 Aluminium to Equipment Connections

Aluminium conductor connections to equipment should, where possible be in the vertical plane. In all cases joints must be made in accordance with Section 6.2.6 above. However, the aluminium tape should not be tinned, and appropriate transition washers should be used at the aluminium to steel interface.

6.2.8 Aluminium to Aluminium Connections

The preferred method is either inert-gas tungsten-arc (TIG) or inert-gas metal arc (MIG) welding provided that the area of the welded material at least matches that of the tape cross section. Bolted joints are acceptable since aluminium is only used above ground.

For bolted joints the following applies:

- All joints require a two bolt fixing.
- Bolts must be high tensile galvanised steel, fitted with large diameter galvanised steel washers, or (optionally), transition washers designed to penetrate the aluminium oxide coating.
- The surface aluminium must be cleaned using grade 80 aluminium oxide cloth or equivalent and coated with neutral compound grease. This may not be necessary if a transition washer is used, in which case manufacturer's guidance should be followed.
- Bolts must be tightened using a torque wrench, to avoid over stressing in accordance with Table 9 below. It is important not to compress aluminium connectors by excessive tightening, as loss of 'elasticity' by plastic deformation can result in loosening of the connection when subject to thermal cycling.
- All excess grease must be wiped off the finished joint.
- The joint must be sealed with two coats of bitumastic paint or equivalent.

Commented [C10]: Grade 80 aluminium cloth or equivalent specified from previous electricity industry tests as it creates the optimum surface conditions for forming aluminium connections. Use has been carried forward into NG instructions.

Table 9 – Bolt sizes and torques for use on aluminium

Dimensions in millimetres

Bar Width	Bar Overlap	Bolt Diameter	Hole Size	Recommended Torque (Nm)	Washer Size	Washer Thickness
40	80	10	12	35	OD 25 ID 11	2.5
60	100	12	14	50	OD 28 ID 12.5	3.0

6.2.9 Aluminium to Copper Connections

Connections are to be in the vertical plane, at least 150mm above the ground or concrete plinth. They must be located in positions where water cannot gather and the aluminium will be above the copper. Bimetallic joints must not be made on buried sections of electrode.

All connections involving dissimilar metals must be cleaned with abrasive cloth and coated with neutral compound grease, before making a bolted connection. Copper must be pre-tinned. The finished joint should be sealed using bitumastic paint, compound, water proof tape or a heat shrink tube filled with neutral grease. A transition washer [section 6.2.2] may be used to minimise corrosion at bolted joints.

Where joints have been made closer to ground level than 150 mm (usually following theft), a corrosion risk assessment is necessary. If the ground is well drained and there is little chance of water being retained around the joint then the above arrangement is acceptable. If not then the copper must be extended upwards to reduce risk of corrosion.

6.2.10 Earthing Connections to Aluminium Structures

The following procedures are necessary to ensure that aluminium structures used to support substation equipment do not corrode:

- (i) The bottom surface of the structure base and the top surface where galvanised steel or other equipment is to be fitted, must be painted with two coats of bitumastic paint, prior to bolting into position on the concrete plinth. (Note - this reduces the possibility of bimetallic action which would corrode the aluminium). A conducting strap is required between any steel of the top level equipment support and the aluminium structure.
- (ii) Provision should be made for connecting below ground conductor to the structure via a suitable drilling and bi metallic connection (ref. 6.2.9).
- (iii) Except for fault throwers and high frequency earths (capacitor voltage transformers and surge arresters) the aluminium structure leg(s) may be used to provide earth continuity down to the connection to the main earth grid. The following is also necessary:

Any bolted sections of the structure that may be subject to bimetallic corrosion, and/or may be of insufficient cross section, should be bridged using aluminium earth tape. The bridged joint must be made as any other aluminium to aluminium earth connection. Totally tinned copper straps can be used if necessary on connections to insulator supports from the aluminium. The copper and completed connection must be painted to prevent moisture ingress and corrosion.

The aluminium structure must be connected to the main substation earth grid, using copper tape that is tinned at the joint position.

Where the legs of the support structure are greater than two metres apart or the structure forms a bolted TT (or goalpost type) formation, an earth connection must be made on two legs of the structure.

6.2.11 Steel Structures

Steel structure legs should be used wherever practicable to provide the connection between the earth grid and equipment at the top, except for fault throwers and earth switches. For equipment requiring high frequency earths (e.g. capacitor voltage transformers and surge arresters), refer to section 6.14.

Ideally the structure should be of the welded type or have one or more legs formed with a continuous section from ground to equipment level.

If a steel structure is used to convey fault current, it must be reliable, and of sufficient current carrying capacity to avoid excessive temperature rise. If there is reliance on a single joint or leg, bolted shunts shall be considered. Where bolted shunts are used, the temperature rise of bolted connections shall be limited to 250 °C. Refer to Section 0.

Joints should be reliable. Galvanising (zinc coating) of the steel forms an oxide which increases in thickness with age and could create a high resistance at steel - steel joint surfaces.

Where aluminium tape is connected to a galvanised steel structure a transition washer is not required, however adequate preparation of the joint surfaces, and protection from water ingress is required in accordance with normal best practice. Refer to Section 6.2 for more detail of jointing practices.

6.3 Above Ground Earthing Installations

6.3.1 Fixing Above Ground Conductor to Supports

Previous standards required that above ground copper or aluminium tape was fixed to structures at 1m intervals using cleats. This is acceptable from a technical prospective; unfortunately the cleats used provide a convenient way for the above ground conductor to be stolen.

To prevent theft, the following methods of fixing shall be used:

Pinning at least every 300 mm for higher security using stainless steel pins. (The pins should have plastic spacers to separate the pin from the conductor and in the case of aluminium, plastic spacers to separate the aluminium from galvanised steelwork).

Drilling and screwing with tamper proof screw heads. This method is more appropriate if the concrete support may be damaged by use of percussion driven pins. Again a plastic spacer is required to separate the screw from the metal. The screws should be stainless steel.

It is important that the pins or screws are fitted such that water cannot gather and cause corrosion. Aluminium should preferably not be in direct contact with concrete, so if practicable, the back of the conductor should be coated with a high temperature aluminium grease or other heat-proof coating to prevent this.

Consideration must be given to the reduction of conductor cross sectional area and current carrying capability due to drilling. Any holes introduced into the earth conductor should not exceed 10mm in diameter and one third of the width.

Note that the design final temperature of a bolted connection is 250 °C, compared to that of 405°C (copper) and 325°C (aluminium). Consequently earthing conductors with bolted connections have a rating that is between 80% and 90% of their normal value.

6.3.2 Prevention of Corrosion of Above Ground Conductors

Copper strip conductor supported from or in contact with galvanised steel should either be tinned or coated in a high temperature grease to prevent electrolytic action.

Unless it is protected, aluminium earthing conductor should not be laid within 150 mm of ground level.

6.3.3 Metal Trench Covers

Within substation buildings, trench covers need to be indirectly earthed. This is best achieved by installing a copper strip (25mm x 3mm) along one edge of the trench top edge. The covers will be in contact with this when in position. The copper strip should be bonded to the switchgear earth bar or internal earthing system.

[Feedback awaited re: Computer flooring / suspended flooring]

6.3.4 Loops for Portable Earth Connections

Earth loops of aluminium or copper strip conductor connected to the structure earth connection, must be provided at appropriate locations where portable earth leads need to be applied. The loops, if not provided as part of the structure shall preferably be formed separately and jointed to the aluminium or copper tape. Recommended size should be not less than 230 mm long and 75 mm high.

Loops must not be installed in the run of high frequency earths associated with CVTs and surge arrestors since these will introduce a high impedance to high frequency/steep fronted surges. A loop for portable earths may be added in parallel to the straight earthing conductor

Commented [RW11]: Don't think this is correct? Al electropotential similar to that of Zn, but Cu and Zn should be separated?

rather than as a loop formed in the earthing conductor itself. 'D' loops should only be installed on fully rated conductors.

6.4 Below Ground Earthing Installations

6.4.1 Installation of Buried Electrode within a Substation

The electrode must be installed at least 600 mm deep. This gives physical protection to the electrode and connections. It also tends to place the electrode in moist soil below the frost line so helping ensure its resistance is stable. The resistivity of ice is in the region 10,000 to 100,000 Ohm.m (e.g. compared with 10-1000 Ohm.m for most soils), therefore an earthing system's resistance will increase significantly if it is not clear of frost.

Buried earth electrode should be surrounded by 150 mm of fine texture non-corrosive soil, firmly consolidated. The use of pulverised fuel ash (PFA) or coke breeze as backfill is not recommended as it may induce rapid corrosion of buried electrode and metallic cable sheaths. Where there is a risk of corrosion, the electrode size may need to be increased.

If the indigenous soil is hostile to copper, i.e. acidic with a pH value of less than 6 or alkaline with a pH value of more than 10, suitable surrounding soil should be imported. However, if groundwater is present (which may serve to remove the imported soil) then other methods may be necessary to protect the electrode. More regular testing or inspection may be required.

When laying stranded conductor, care should be taken to avoid distorting and opening the individual strands, because this increases the probability of accelerated corrosion.

6.4.2 Positioning of Buried Electrode

The laying of earth electrode close and parallel to hessian served power cables, multicore cables, or bare metal pipes, is to be avoided. This is to reduce the risk of them being punctured due to high currents or voltage transients on the electrode.

Electrode must be at least 300 mm away from hessian served power cables and bare metal pipes and 150 mm away from plastic sheathed cables. Where a crossing is necessary, PVC tape or a split plastic duct must be applied around the cable or pipe for 0.5 m either side of a position where the cable or pipe crosses an earth electrode, or for the distance over which the 0.3 m separation cannot be maintained.

Where copper tape within the site is to be buried under proposed cable routes care must be taken to ensure it is buried deep enough or otherwise protected in a duct so that it is not damaged during cable installation.

Where electrode connected to the earthing system is laid under metal fencing, and the fencing is independently earthed, the electrode should be insulated for at least 2 m each side of the fence.

Earthing conductors laid near drainage pits or other civil works should maintain a separation of at least 500 mm to avoid mechanical damage during subsequent works.

Where bare electrode has to cross permanent trench routes:

- short lengths of electrode may be laid under the trench for later connection to the grid;
- a short duct may be laid under the trench to accommodate the electrode.

Subsidiary connections to equipment may be laid at shallower depth. Due to variation of soil resistivity near the surface, their contribution to the overall earth resistance should be ignored

Commented [RW12]:

in the design. Their contribution towards reducing touch and step potentials should be included.

In cases where a concrete plinth covers the whole substation site, (e.g. 11 kV/LV unit type or urban 33kV substations) earth electrodes should be installed prior to construction of the plinth. Provision should be made to bring multiple connections out through the concrete. The extent of the electrode mesh required will be influenced by whether steel reinforcing is used and bonded, within the foundation.

When routing bare electrode off site, either to reduce the overall earth resistance or to provide a connection to external equipment such as terminal poles, routes that may be frequented by people with bare feet or animals are to be avoided.

If this is not possible, calculations or computer modelling should be used to confirm that the step potentials in these areas are acceptable (a design figure of 25 V/m may be used for livestock areas as described in Section 4.4.2). Where electrode crosses land that is ploughed it should be installed a minimum of 1m deep.

When rebar is installed in building and equipment foundations duplicate connections may be made from the rebar to the grid for touch voltage control. (See section 6.5).

Burying copper in concrete below ground level, and at a depth such that the moisture content remains reasonably stable, does not reduce the effectiveness of the earthing [except where damp-proof membranes are installed].

6.4.3 Other Earth Electrodes

6.4.3.1 Earth Rods

These are generally convenient to install where the subsoil is free from boulders and rock. Rod electrodes and their connections should be in accordance with ENA TS 43-94. The earth resistance of a rod or group of rod electrodes may be calculated from formulae given in **EREC S34**.

A number of rods may be connected in parallel but they should be installed with sufficient spacing apart such that each is essentially outside the resistance area of any other. For worthwhile results the mutual separation should be not less than the depth of the rod.

The rods may be connected to the earth grid via a test chamber which is capable of accepting a clip on resistance meter.

Deep earth electrodes should, as far as possible, be driven into the earth vertically. If rods are installed in drilled holes they may be backfilled with a proprietary low resistance backfill material.

Rods may be particularly advantageous if the earth resistivity falls with depth. If several deep earth electrodes are necessary in order to achieve a required parallel resistance, then, where space is available, the mutual minimum separation could usefully be double that of the effective length of an individual earth electrode.

Substations in large urban developments are often located below ground level in tanked structures. In such situations special facilities for installing earth electrodes are required.

6.4.3.2 Earth Plates

Earth plates tended to be used in older earthing system designs when they were often situated in groups or "nests" near the main transformers. Modern designs make little use of plates, except where the soil is such that it is difficult to drive in earth rods or at the corners of the

1517 earth grid perimeter electrode. In this case a plate will be installed in the vertical plane and
1518 acts as a replacement for a rod.

1519 In older sites, should an earth plate require replacement, it is likely that the earthing system
1520 itself will require redesign and this may render the plate obsolete. Where there is any doubt,
1521 the plate can be replaced on a like for like basis, or by several 2.4m rods in parallel, close
1522 together. Plates are typically 1220 mm or 915 mm square in size, of ribbed cast iron and
1523 approximately 12 mm thick.

1524 **6.5 Use of Structural Earths including Steel Piles and Rebar**

1525 Structural metalwork (piles and foundations) can make a valuable contribution to an earthing
1526 system, specifically providing parallel paths for earth fault current, reducing overall earth
1527 resistance and increasing resilience. Such contributions should be viewed as additional, rather
1528 than instead of, a dedicated earthing system.

1529 Horizontal (meshed) rebar installed in concrete or in a screed below plant can provide good
1530 control of touch voltages. In this sense it should be viewed in terms of touch voltage control,
1531 rather than as an electrode system.

1532 **6.5.1 Sheet Steel Piles**

1533 Sheets that are more than 3m long and 2m wide are to be bonded to the earthing system, as
1534 specified by the Design Engineer. Stainless steel studs are to be exothermically welded to
1535 each second sheet at a suitable height (normally 600mm below finished ground level) and a
1536 strip of 40mm x 4mm copper tape will be bolted to these. The strip will in turn be connected to
1537 the main substation earthing system. If the piles form a separate electrode connected to the
1538 earthing system at one point, then the connection should be via a test chamber such that the
1539 contribution of the piles may be monitored. Bolted connections should be avoided where
1540 possible.

1541 **6.5.2 Horizontal Steel Reinforced Foundations**

1542 For transformer and switch rooms, the most significant benefit of shallow rebar mesh is in
1543 potential grading (touch voltage control). Where this is necessary to ensure operator safety
1544 (i.e. in situations where the EPR exceeds safe touch voltage limits), it is important to ensure
1545 the integrity of any connections.

1546 For touch voltage control, rebar will be installed normally at shallow depth (i.e. with the rebar
1547 strips bound with soft steel wire, or as a prefabricated mesh), but with two or more rebar
1548 connections left protruding from the concrete for approximately 150mm sufficient to allow
1549 connection to copper or aluminium conductors. Alternatively connections may be provided
1550 before concrete is poured using a rebar clamp with flexible earth conductor. In either case any
1551 inaccessible rebar extension used for the final connections must be welded to the main rebar
1552 assembly.

1553 Ideally the rebar should be arranged with welded connections along at least two orthogonal
1554 edges such that welded joints connect each bar.

1555 If the rebar in concrete is to function as an auxiliary earth electrode (e.g. it is installed at
1556 sufficient depth to make a contribution), then current rating considerations may mean that
1557 exothermic welding is necessary for connections to the rebar and between rebar meshes.

1558 NOTE: Protruding rebar may not be acceptable in some circumstances due to concerns with water ingress etc.

6.5.3 Vertical Steel Reinforced Concrete Columns

Where these columns have steel reinforcing that extends further into the ground than it is possible to bury a conventional earthing system, then the design may require these to be bonded to the earthing system. The easiest method is to leave a section of bonded rebar 150mm out of the concrete for a connection to be made later by the earth installers. This steel reinforcing bar must have its electrical continuity maintained at joint positions by welding the connection. Some designs require electrical connections between the piles made with rebar. In this case supervision of the civil works will be required before concrete is poured.

NOTE: Protruding rebar may not be acceptable in some circumstances due to concerns with water ingress etc.

6.6 Metallic Fences

Two alternative earthing arrangements may be applied to metallic substation fences. These are:

- an independently earthed (or segregated) fence arrangement where the fence is kept electrically isolated from the substation main earth system (Figure 2) or:
- a bonded fence arrangement where the fence is bonded to the substation main earth system (Figure 3).

Occasionally it may be appropriate to employ both methods on different fence sections at the same site. In this case insulated sections are used to physically link the fences with different earthing arrangements.

Where the fence panels are supported by steel posts that are at least 1m deep in the ground, the posts can be considered as earth electrodes.

Where it is important (mainly overhead lines crossing or in parallel with the fence or proximity to magnetic fields) to provide electrical continuity between adjacent panels, this can be provided by attention to the bolt/fixing connections or by providing a separate continuity conductor (buried or supported on the fence).

6.6.1 Independently Earthed Fences

Where the substation earthing system is effectively within the substation perimeter fence, the fence should be separately earthed with rods approximately 2.4 m long located at:

- all fence corners;
- one metre either side of each point where HV overhead conductors cross the fence;
- additional locations such that the interval between rods sites shall not exceed 50m.

Gate posts should be bonded together with below ground connections to ensure that difference potentials do not arise when the two parts are bridged by a person opening the gates. Flexible copper bonds (minimum 16mm² cu or equivalent) should also be used to bond the gates to the posts as an additional safety measure.

6.6.2 Segregation between independently earthed fence and earthing system

A segregation distance above ground of at least 2 metres should be maintained between the substation fence and the substation earthing system including all items connected to it. (This is based on personnel avoiding simultaneous contact with the independently earthed fence and equipment connected to the earthing system.) A similar distance shall be maintained below ground, where practicable, taking into account the location of substation perimeter electrodes etc.

1602 The 2m segregation between the independently earthed fence and the earthing system shall
1603 be maintained on an ongoing basis. This must not be compromised by alterations such as the
1604 addition of lighting or security installations, where e.g. cable armours can compromise the
1605 segregation of the systems.

1606 Where the required segregation cannot be achieved then mitigation measures should be
1607 considered (e.g. insulating paint or barriers (that do not compromise security)). Alternatively,
1608 the risk assessment approach outlined in section 5.7 may be applied.


1609 Methods to calculate the transfer potential onto fences are described in **EREC S34.**

1610

1611

1612

Figure 2 – Arrangement of separately earthed fence



6.6.3 Fences Bonded to the Substation Earthing System

This arrangement is used where substation plant and equipment is located with 2m of a metallic fence and where internal fences which are located within the area encompassed by the substation earthing system. The fences should be connected to the earth grid using discrete but visible connections located at:


- all fence corners;
- one metre either side of each point where HV overhead conductors cross the fence;
- additional locations such that the interval between connections does not exceed 50m.

Where the fence which is connected to the substation earthing system is the perimeter fence, and where the touch potential external to the fence could exceed the safety limits set out in Table 1, then the following requirements apply.

- A bare electrode conductor shall be buried in the ground external to the perimeter fence at approximately a distance of 1 metre away and at a depth of 0.5 metres. In agricultural locations risk of disturbance due to ploughing should be addressed;
- The conductor should be connected to the fence and to the earthing system at intervals of 50 metres or less such that it becomes an integral part of the substation earthing system. One method to achieve this is to 'expand' the substation grid such that the fence is located within the area of this grid. (Figure 3 below);
- Chippings or asphalt around the substation perimeter will provide additional protection to animals/persons outside the substation.

At locations where fencing connected to the substation earth grid abuts with independently earthed fencing and this presents a touch hazard, there should be electrical isolation between the two fence systems. See para. 6.6.5 for methods of achieving electrical isolation between fences using insulated fence sections.

Figure 3 – Arrangement of bonded fence



6.6.4 Third Party Metallic Fences

Third parties shall not directly connect their metal fences to a metallic substation fence, as this may introduce a transfer potential risk. Where such third party fences are present or are likely to be present within 2 m of the substation, one of the options listed below should be implemented to maintain electrical isolation between the two fence systems.

Note: Security considerations may preclude this if the third-party fence could act as a climbing aid.

6.6.5 Insulated Fence Sections.

Insulated fence sections to segregate lengths of fencing which are bonded to the main earth grid from those which are independently earthed or connected to third party fences may be used. The insulated sections may be formed by:

- Installing a 2 m (or longer) insulated fence panel made wholly of insulating material.
- Installing a 2 m (or longer) metal fence panel mounted on insulated supports / standoff insulators. (The insulators need a voltage withstand capability in excess of the highest EPR at the perimeter of the site whilst at least maintaining the equivalent physical strength of the fence).

1661 Coated fences (section 6.6.7) must not be treated as insulated sections unless specifically
1662 designed and tested for such purposes.

1663 **6.6.6 Chain Link Fencing (Galvanised or Plastic Coated)**

1664 Such fencing should be earthed by bonding the support posts, fence and straining wires and
1665 any anti-climbing devices to the independent or bonded fence earth electrode system as
1666 appropriate. This may conveniently be achieved by the addition of an electrode run with the
1667 fence to aid bonding/earthing. The fence shall be treated as if it were bare metal, i.e. no
1668 insulation withstand should normally be assumed.

1669 If a touch potential issue exists with a plastic coated chain link fence it should be addressed
1670 by installing a grading electrode rather than by relying on the integrity of the plastic fence
1671 coating which may not be comprehensive and is also likely to deteriorate.

1672 **6.6.7 Coated Fence Panels**

1673 These typically consist of galvanised steel support posts and galvanised steel mesh panels,
1674 all of which are coated. When used for enclosing electrical apparatus or a substation, they
1675 shall be earthed and precautions are necessary to cater against damage or erosion of the
1676 coating. The support posts shall be earthed via a bolted connection and ideally the metal of
1677 each panel should in turn be similarly connected to the post. Ideally these should be via
1678 manufacturer provided facilities. The overall fence is connected to earth in a similar manner to
1679 a separately earthed or bonded metal palisade fence.

1680 Such fences should not be treated as insulating, unless the covering is specifically designed
1681 for this purpose and its longevity can be assured.

1682 If a touch potential issue exists with a coated fence it should be addressed by installing a
1683 grading electrode.

1684 **6.6.8 Electric Security Fences**

1685 When electric security fencing is installed on independently earthed fence installations, the
1686 isolation of segregated fence sections from the main substation earthing system must be
1687 maintained. This may require independent electric fence zones and special consideration of
1688 electric fence earth connections.

1689 **6.6.9 Anti-climbing Precautions**

1690 Where barbed wire or other metal anti-climbing devices are erected along the top of brick walls
1691 or other non-metallic barriers they may be connected to earth using the same procedure as
1692 with fencing. Note that metallic parts not liable to introduce a potential need not be bonded
1693 (e.g. short lengths of barbed wire or spikes etc.).

1694 Care should be taken to ensure that anti climbing guards do not bridge fencing sections that
1695 are designed to be separately earthed or isolated. This includes e.g. the metal centre rods of
1696 plastic 'vane' guards etc.

1697 **6.7 Specific Items**

1698 **6.7.1 Water Services to Substations**

1699 Water supplies to substations shall be run in non-metallic pipes. This avoids the substation
1700 potential rise being transferred outside so endangering other users of the water supply system.
1701 This is now largely a legacy issue at older sites as insulated pipes are used for new
1702 construction. When such an existing site is being refurbished or upgraded at least a section of
1703 insulated plastic pipe should be inserted in the incoming metallic water service.

1704 Any metallic pipe used within the substation site should be bonded to the substation earthing
1705 system and adequately segregated from separately earthed fence sections.

1706 **6.7.2 Non-current carrying metalwork**

1707 Most non-current carrying metalwork of all kinds within the perimeter fence shall be securely
1708 bonded to the main earthing system to ensure that all such items are held to the same potential
1709 and, if called upon to do so, will carry fault currents without damage. Exceptions apply to
1710 conductive parts not liable to introduce a potential, and these need not be bonded.

1711 The cross section of any bonding conductors shall be as described in Table 5 and Table 6. If
1712 there is no likelihood of current flow or corrosion/erosion, equipotential bonding conductors
1713 should be no smaller than 16mm² copper or equivalent.

1714 NOTE: Small metallic items (extraneous metalwork) that are unlikely to introduce or carry a significant potential,
1715 need not be bonded to the main earthing system (ref: 4.2). Such items may include, but are not limited to, window
1716 frames, signposts, wall brackets, small access steps/handrails etc.; However if there is any foreseeable likelihood
1717 of them adopting a potential in service (sufficient to cause a touch voltage hazard), such items should be bonded
1718 to the main earthing system.

1719 Larger items, even if some distance from current carrying metalwork, may adopt a stray voltage due to induction or
1720 capacitive coupling and should always be bonded.

1721 **6.7.3 Items normally bonded to the main earth grid:**

1722 These include:

- 1723 • overhead line termination structures including towers, gantries and earthed wood pole
1724 structures within or adjacent to the substation;
- 1725 • power cable sheaths and armours (at one or more points);
- 1726 • transformer and reactor tanks, coolers and radiators, tap changers, earthing resistors,
1727 earthing reactors, high voltage transformer neutral connections;
- 1728 • metal clad switchgear assemblies and cases, isolators and earth switch bases;
- 1729 • metal gantries and structures and metalwork mounted on wood structures;
- 1730 • metallic building structures including steel frames (bonded at each corner), rebar and
1731 piles. Miscellaneous metalwork associated with oil and air tanks, screens, steel structures
1732 of all kinds;
- 1733 • all panels, cubicles, kiosks, LV AC equipment, lighting and security masts.

1734 Critical items such as transformer tanks and terminal towers shall have duplicate connections
1735 to the main earth grid.

1736 **6.7.4 Items NOT normally bonded to the Earth Grid**

1737 The following list is not exhaustive, and includes some typical items that a designer may specify
1738 to remain un-bonded.

- 1739 • The perimeter fence is only bonded to the main earth system if all or part if it cannot be
1740 kept at least 2 m clear of earthed structures and the main earthing system. (Section 6.6)
- 1741 • Screens of telephone cables where they are taken into HOT sites. (Refer to 4.3.7);
- 1742 • Extraneous non-current carrying metalwork as described in Section 6.7.2
- 1743 • Parts intended to be isolated from earth (e.g. floating fence panels, some stay wires, etc.)
- 1744 • Some protection equipment, or equipment connected to (e.g.) frame leakage protection,
1745 which must be connected to earth in a specific manner.
- 1746 • LV neutrals/earths in some circumstances.

6.7.5 Non-standard bonding arrangements

Sometimes it may be necessary to isolate cable sheaths and screens from the main substation earth grid to avoid transfer potential issues. Such arrangements must be the subject of a bespoke design and precautions taken at the earth isolation point to avoid touch potential issues.

NOTE: There may be other considerations which make a sheath break unacceptable or ineffective in some circumstances. ENA EREC C55 provides further related information.

6.8 Overhead Line Terminations

6.8.1 Tower Terminations Adjacent to Substation

Where the aerial earth wire of an incoming overhead line terminates on a steel tower / terminal support adjacent to a substation, continuity shall be provided for current in the earth wire to flow into the main earthing system. Continuity is to be provided by:

- bonding the aerial earth wire to the top of the line gantry, or;
- bonding the aerial earth wire to the top of the tower, and bonding the base of the tower to the main substation earthing system.

The rating of the bonds must at least be equal to that of the aerial earth wire.

If not bonded via aerial earth wire, the tower must be bonded to the main earth grid via two continuous conductors which run from different tower legs via separate routes and connect to two different points on the main earth grid. Each below ground conductor must be fully rated. The bonds should be buried and be installed so as to minimise risk of theft. If the bonds run under an independently earthed fence they must be insulated for a 2 metre distance on either side of the fence.

If the tower legs are located within 2 m of an independently earthed metal fence then the section of fence adjacent to the tower should be bonded to the tower and electrically isolated from the rest of the fence. Alternatively the relevant metal fence panels may be replaced by insulated panels, or suitable insulating coating applied (ref: 4.4.3 and 6.6). If this is not practicable a risk assessment should be carried out (section 5.7).

6.8.2 Steel Tower Termination with Cable Sealing Ends

Where an aerial earth wire terminates on a tower with a sealing end platform or an associated cable sealing-end compound that is well outside the substation, continuity between the base of the tower and the main earthing system will be provided by either the sheaths of the power cables or by an earth continuity conductor laid and installed in accordance with ENA EREC C55.

6.8.3 Terminal Poles with Stays Adjacent to Substation Fence

Stay wires that are external to the site and more than 2 m from the fence or earthed metalwork may be left un-earthed, if this is in accordance with normal practice. They should be earthed within the substation compound where possible to minimise risk from current leakage across the stay insulator.

Earthed stay wires can present a touch potential risk if the stay is in very close proximity to an independently earthed fence, and may form an inadvertent connection between the independently earthed fence and the main earth grid. To address this, in addition to installing the normal upper stay insulator a second stay insulator should be installed as close to ground level as possible leaving the centre section of the stay unearthed. 2 m segregation must be achieved between the lower earthed section of the stay including the rod and the fence.

1791 Unless the earthed stay rod is inside the earth grid, a loop of buried electrode should be laid
1792 around the rod at a 1m radius, and bonded to the rod/main earthing system to control touch
1793 potential.

1794 **6.8.4 Down drop Anchorage Arrangement with Arcing Horns**

1795 Where it is necessary to have an assembly of ferrous fittings such as turn buckles, links,
1796 shackles etc. between the insulators and an earthed structure or ground anchor point,
1797 precautions may be required if the earth fault current is very large.

1798 The earthed end arc-ring (or horn) anchorage arrangement may be attached to the main earth
1799 connection by means of a flexible copper shunt, in order to limit earth fault current flowing
1800 through the discontinuous ferrous fittings. This prevents mechanical damage due to arcing.

1801 **6.8.5 Loss of Aerial Earth Wires**

1802 If alterations are carried out to overhead lines which break an otherwise continuous aerial earth
1803 wire between substation sites, consideration must be given to the increase in ground return
1804 current and consequent increase in EPR which arises.

1805 There may also be a further increase in EPR due to reduction of the chain impedance
1806 contribution. It may be necessary to consider the installation of an overhead or buried earth
1807 conductor to provide continuity of the aerial earth wire.

1808 **6.9 HV Cable Metallic Sheath / Armour Earthing**

1809 This section covers all HV power cables contained within or entering HV substations but
1810 excludes those HV cables which feed HV/LV transformers located in the substation where the
1811 LV supply is exclusively for use in the substation. The requirements for these latter cables are
1812 dealt with under Section 9.

1813 **6.9.1 Insulated (Polymeric) Sheath Cables**

1814 The metallic sheath/armour of cables can, due to their inductive coupling properties, provide a
1815 very low impedance return path for earth fault current flowing in the cable phase conductors.
1816 This can greatly reduce the current that returns to source though the ground and subject to the
1817 sheath being continuous significantly reduce the EPR at associated terminal substations.

1818 To achieve this, the sheath/armour must be earthed at least at both ends. This arrangement
1819 of earthing is generally satisfactory for three-core and TRIPLEX type high voltage cables
1820 forming part of general distribution system circuits.

1821 Simply bonding sheaths/armours at both ends of single-core cables or very heavily loaded
1822 circuits such as transformer interplant cables can cause de-rating as large steady-state
1823 currents may flow in the sheath/armours, causing additional heating and risking damage.

1824 Consequently two methods of installation have been developed for single-core cables where
1825 the length is sufficient to cause this problem.

1826 a) Single Point Bonding – where the sheaths are connected to earth at one point. A parallel
1827 Earth Continuity Conductor may be laid with the cables to provide continuity between items
1828 of plant.

1829 b) Cross bonding – where the sheaths are connected to earth at each end, and periodically
1830 transposed to cancel circulating currents flowing in the sheaths.

1831 Single-point bonding preserves the rating of the cables, but permits a voltage to develop
1832 between the sheaths/armours and earth at the unearthed ends of the cables which could, on
1833 long cable runs, require shrouding or other measures to ensure safety.

Commented [RW13]: To distinguish from earlier reference to sheath breaks which also relates to pilot cables and comms

1834 Cross-bonding provides a return path for earth fault current in the sheaths without permitting
1835 significant steady-state de-rating current to flow or exceeding the sheath voltage rise limit. Care
1836 is needed at link boxes/transposition points.

1837 Both methods, together with their merits and disadvantages are described in detail in ENA
1838 EREC C55 "Insulated Sheath Power Cable Systems", together with solutions to the problems
1839 described above. A bespoke cable and earthing / bonding design is usually required for very
1840 heavily loaded circuits (e.g. interplant cables) or circuits operating above 33 kV.

1841 Methods for calculating the sheath return current and resulting ground return current (for
1842 systems with sheaths earthed at both ends) are given in [ENA EREC S34](#).

1843 **6.9.2 Cables Entering Substations**

1844 The sheath/armour at the substation end of the cable should be earthed to the substation
1845 earthing system.

1846 TRIPLEX, three-core, and fully cross-bonded cables will, in addition, be earthed at their remote
1847 ends. This provides both a conductive and inductive path for fault current. With cross-bonded
1848 single-core cables, it is the usual practice to install further additional sheath earths along the
1849 route of the cable. The additional sheath earths will normally produce an insignificant benefit,
1850 and can be ignored in the assessment of the substation earth resistance.

1851 **6.9.3 Cables Within Substations**

1852 Three-core cables will have their sheath/armour earthed at both ends.

1853 Single-core cables will usually be short enough to allow single-point sheath/armour earthing,
1854 without causing serious sheath voltage rise problems. The single sheath/armour bond to earth
1855 should be located where personnel are most frequently present, for example at switchgear.
1856 Screens should be shrouded at the unearthed end. An earth continuity conductor may be
1857 required. Refer to ENA EREC C55 for further details.

1858 For the higher voltage systems, sheath voltage limiting devices (SVLs) may be installed
1859 between the sheath and earth at the unearthed end of the cable to protect the integrity of the
1860 sheath and its terminating point insulation against transient voltage surges on the sheath.

1861 **6.9.4 Outdoor Cable Sealing-Ends**

1862 Where cables terminate at outdoor sealing-ends, pedestal-type insulators are fitted to insulate
1863 the sealing-end base and gland from its support structure. If sheath earthing is made at this
1864 location special earthing bonds are required in accordance with ENA TS 09-15 or EREC C55
1865 as appropriate.

1866 When the standing sheath-voltage at a termination can exceed 10 volts to earth, the base
1867 metalwork of the sealing-end shall be screened against accidental contact by means of an
1868 insulating shroud of the type illustrated in EREC C55.

1869 Sealing-end support insulators should be used only for short single-core cable tails with an
1870 earth bond made at the trifurcating point of any three-core cable.

1871 **6.9.5 Use of Disconnected, Non-Insulated Sheath/Armour Cables as an Electrode**

1872 Metallic sheathed/armoured hessian served cables are often decommissioned or replaced with
1873 insulated sheath cables. Where these are laid direct in soil, they can provide a valuable
1874 electrode contribution. Where practicable (particularly if the buried length exceeds 200 m)
1875 these redundant cables should be retained as earth electrodes to maintain their contribution
1876 towards lowering overall substation earth resistance and EPR.

1877 If such sections are retained, the phase conductors and sheaths/armours of these cables, once
1878 disconnected should be joined together to maintain their contribution to the electrode system.
1879 The start ends should ideally be connected to the earth grid via test chambers to permit
1880 continuity or resistance measurements. The remote ends should, if practicable, be connected
1881 to the electrode system at a joint or distribution substation. Cable and earthing records should
1882 be annotated to show such cables are being used as substation earth electrode.

1883 Constant-force springs (CFS) or plumbed joints may be appropriate for connecting stranded
1884 copper conductor to lead sheathed cables; other types of connection may loosen in service as
1885 the lead continues to flow or 'creep' under contact pressure. In any case moisture should be
1886 excluded from such joints using heat shrink boots or similar. Manufacturer's guidance should
1887 be sought if connecting to sheaths of other cable types.

1888 **6.10 Light-current Equipment Associated with External Cabling**

1889 All exposed conductive parts of light current equipment shall be earthed to the main earthing
1890 system as required. Where pilot or communication cables operate between two remote points
1891 and the rise of earth potential at each end of the circuit does not exceed the appropriate ITU-
1892 T limit, any required circuit earth may be made at either end. If the rise of earth potential at
1893 either end exceeds the appropriate ITU-T limit, then protective measures shall be applied to
1894 those circuits. Refer to ENA EREC S36, and sections 4.3.7 and 6.9.3.

1895 **6.11 Metal Clad and Gas Insulated (GIS) Substations**

1896 **6.11.1 Metal Clad Substations**

1897 Metal clad substations will normally be erected on a concrete raft. The provisions for an earth
1898 electrode system in these circumstances will be similar to those described under item 9.3.1.
1899 Where touch potential is an issue consideration should be given to using an enclosure made
1900 of insulating material and to using surface-laid earth mat/grating.

1901 **6.11.2 Gas Insulated Switchgear (GIS)**

1902 Gas Insulated Switchgear (GIS) employing single-phase busbar enclosures require additional
1903 earthing precautions incorporated into the design of the substation earthing system.

1904 Due to close coupling with individual phase conductors busbar enclosures can experience high
1905 levels of induction. Steelwork used to support the enclosures and adjoining items of plant may
1906 form closed paths in which induced inter-phase and earth currents flow under both steady-
1907 state and fault conditions. These currents can be undesirably high and may approach the
1908 phase conductor current. The flow of circulating current renders secondary wiring more
1909 vulnerable to inductive interference.

1910 A further issue with GIS is the creation of surge voltages on the enclosures and associated
1911 steelwork during switching or other transient/high frequency system disturbances.

1912 To help minimise the above effects it is recommended that an earth grid, well integrated and
1913 with locally enhanced electrode (e.g. increased mesh density and vertical rods) in the regions
1914 close to the plant, be laid over the raft from which short spur connections can then be taken to
1915 the specific earthing points on the equipment. Typical arrangements are described in CIGRE
1916 Paper 044/151 - "Earthing of GIS – An Application Guide", issued by Working Group 23.10
1917 (December 1993).

1918 To retain current in the busbar enclosures, short circuit bonds, together with a connection to
1919 the earthing system, should be made between the phase enclosures at all line, cable and
1920 transformer terminations, at busbar terminations and, for long busbar runs, at approximately
1921 20 metre intervals. Switchboards > 20 m long will require intermediate connections. Except
1922 where adjacent enclosures are insulated from each other the interface flanges of the

1923 enclosures should have bonds across them and the integrity of bolted joints of all bonds should
1924 be checked.

1925 As a guide the resistance of the bonded flanges should not exceed 5 micro-ohm. At insulated
1926 flanges consideration should be given to the installation of non-linear resistive devices to
1927 prevent transient flash-over.

1928 **6.12 Fault Throwing Switches, Earth Switches and Disconnectors**

1929 **6.12.1 Background**

1930 Fault throwing switches, earth switches and disconnectors are normally mounted on steel,
1931 aluminium, steel reinforced concrete or wood pole structures.

1932 Metallic structures may be of electrically continuous all welded construction or assembled
1933 using several large pre welded sections or individual bolted members. In some cases though
1934 the structure is of bolted construction there may be a continuous metallic section from ground
1935 to equipment level. Where there is more than one metallic section in series in a fault current
1936 path continuity between sections needs to be considered.

1937 Where steel or aluminium support structures are used to support isolators and / or earth
1938 switches it is desirable to use the structure itself to carry earth fault current in order to reduce
1939 the need for above ground earth conductors with consequent risk of theft. This arrangement is
1940 only acceptable where the metallic structure can provide a reliable earth connection with
1941 adequate current carrying capacity.

1942 NOTE: Some Network Operators may not use support structures in lieu a dedicated earthing conductor. See also
1943 6.2.6

1944 When installing earth connections to earth switches and isolators the design will take into
1945 account the magnitude and duration of the prospective earth fault currents involved. **Fault**
1946 **throwing switches shall have a dedicated earth connection, see 6.12.2.**

1947 The main earth connection to these devices carries earth fault current under the following
1948 conditions:

1949 **Table 10 – Conditions for the passage of earth fault current**

Device	Condition For Passage of Earth Fault Current
Fault Throwing Switch	By design when protection operates
Earth Switch	When there is an equipment failure or switching error. May also carry lightning induced current when closed.
Isolator	When the isolator or its connections fault, or when the isolator is used in a sacrificial mode if main protection fails.

1950

1951 The main options for connecting earth switches and isolators are to use either:

- 1952 • a fully rated earth conductor, fixed to the structure. This method is most applicable to higher
1953 fault current applications (e.g. systems operating at 90kV and above) or where the support
1954 structure cannot provide an adequate earth fault current path. See Table 5 and Table 6 for
1955 conductor ratings;
- 1956 • alternatively a metallic structure may be used to conduct earth fault current from the top of
1957 the structure equipment to the grid. This is subject to the structure having sufficient current

1958 carrying capability and being electrically continuous. The method is more applicable to
1959 lower fault current applications (e.g. 33 kV systems) which use welded or continuous
1960 metallic structures.

1961 The following earthing arrangements apply to fault throwing switches, earth switches and
1962 isolators located within secured substation sites fitted with earth grids.

1963 Different arrangements (e.g. insulated down-leads) may be required for equipment located
1964 outside substations in areas accessible to the public.

1965 **6.12.2 Fault Throwing Switches (Phase - Earth)**

1966 A direct earth connection shall be made from the switch earth contact to the main earth grid
1967 using a conductor fixed to the structure.

1968 **6.12.3 Earth Switches**

1969 Connections from earth switches to the main earth grid may be made by either:

- 1970 a) An earth conductor, fixed to the structure or:
1971 b) By using the metallic support structure as a conductor subject to the aluminium or steel
1972 structure having sufficient current carrying capability and being electrically continuous.

1973 **6.12.4 Isolators**

1974 Connections from isolator support metalwork to the main earth grid may be made by either:

- 1975 a) A fully rated earth conductor, fixed to the structure or:
1976 b) By using the metallic support structure as a conductor subject to the aluminium or steel
1977 structure having sufficient current carrying capability and being electrically continuous.

1978 **6.13 Operating Handles, Mechanisms and Control Kiosks**

1979 **6.13.1 Background**

1980 Earthing arrangements for operating handles of isolators, circuit breakers, earth and fault
1981 throwing switches must provide touch and step potential control for the operator.

1982 These are critical locations which require careful consideration and sound construction.

1983 A full earth grid may not always be present at some older sites and additional precautions may
1984 be required when operational work and/or minor alterations are being carried out to ensure
1985 safe touch and step potentials. Generally, with exceptions outlined below, stance earths shall
1986 be provided at all locations where operators may stand to operate high voltage equipment
1987 handles, mechanisms and control equipment.

1988 **6.13.2 Earth Mats (Stance Earths)**

1989 New installations will have touch and step potential control provided by a purpose designed
1990 earth grid. If it can be demonstrated that such measures are adequate to ensure operator
1991 safety, and if a network operator's operational policy allows, an additional stance earth may
1992 not be required. In making this assessment, the likelihood of deterioration due to theft or
1993 corrosion should be considered. Portable or visible (surface laid) stance earths may be
1994 required in addition to any buried grading electrode as a risk reduction measure.

1995 NOTE: Surface-laid earth mats are preferred over buried earth mats; they give much better touch control and their
1996 presence can readily be checked. The size and position of the mat must match the operator stance position(s) for
1997 the given equipment. Galvanised steel grating earth mats can be readily extended to cover the operator path
1998 followed with horizontal operation handles. Buried earth mats may be a suitable alternative to surface-laid earth
1999 mats where the resulting touch voltage is sufficiently low.

6.13.3 Connection of Handles to the Earth Grid and Stance Earths

The earth connection from the handle to the grid shall always be separate to that for the switch metalwork and be as short as possible.

The earth connection shall use standard copper conductor connected direct to the main substation earth.

In some cases an insulated insert may be fitted between the operating handle and the switch metalwork to help prevent any fault current flowing down the handle and mechanism into the earth grid.

Refer also to Section 10.6 (Earthed Operating Mechanisms Accessible From Ground Level).

6.14 Surge Arrestors and CVTs

Plant including surge arresters and CVTs (Capacitor Voltage Transformers), which are connected between line and earth, present relatively low impedance to steep-fronted surges and permit high-frequency currents to flow through them to earth.

Unless a low impedance earth connection is provided, the effectiveness of the arrester could be impaired and high transient potentials appear on the earthing connections local to the equipment. The following installation earthing arrangements are recommended:

Two connections to earth are required for both surge arresters and capacitive voltage transformers (CVTs):

- The first connection (for power frequency earthing) will use the structure to the main substation earth grid.
- The second (high frequency) connection should be direct to an earth rod, installed vertically in the ground as near to the surge arrester base as possible, with a tee connection to the support structure if metal. High frequency earth rods shall be driven vertically into the ground to a depth of approximately 4.8m. Where this is not achievable, a high density earth mesh arrangement or four (or more) long horizontally buried conductors (nominally 10m in length, minimum depth 600mm) dispersed at 90° (or less, equally spaced across the full 360°) may be used in place of the rod. Calculations must be provided to demonstrate that any proposal is equivalent to the 4.8m long earth rods. The high frequency connection shall be made to the centre of the alternative HF earthing designs. Dedicated earth mats or similar may be considered in difficult circumstances.

Refer to BS EN 62305 (Lightning Protection Standard) and BS EN 62561-2 (Lightning Protection System Components – requirements for conductors and earth electrodes), or ENA ER 134 for more information.

The benefit of surge arresters over arc gaps is greatest when the resistance to earth is less than 20 Ohms. When a surge arrester is provided at a cable termination, the earth side of the arrester should be connected to the cable crucifix and thereby to the cable sheath. Surge arresters should be sited as close as practical to the terminals of the plant, (e.g. transformer bushings or cable sealing ends) which they are protecting.

The support structure and plinth will be designed to allow the high frequency earth connection to either pass through its centre, or through an angled slot to ensure that the connection is as short and straight as possible. This will aid performance and deter theft. It is particularly important to avoid sharp bends. This connection must not be enclosed within a steel support tube or box.

Commented [RW14]: Section 6.6 Surge Arresters "Surge Arresters should always be connected as close as practicable to the apparatus and the earth side fixed to or connected to the frame of the apparatus. Surge arresters should be positioned directly across the cable/sheath or transformer HV winding and tank.

Commented [RW15]: This para is from ER 134 and could be omitted?

2043 Fully rated conductors must be used for both high frequency and power frequency
2044 connections. High frequency downleads should be insulated from the support structure
2045 (except where bonded to the structure at low level) to accommodate surge counters, and also
2046 to facilitate testing of the electrode with a clamp meter (Section 7.6.2(b)).

7 Measurements

7.1 General

This section describes some of the most common measurements which may be required during the design, commissioning or maintenance of an earthing system at an electrical installation. An overview of the important measurement and interpretation methods is provided together with some guidance on avoiding sources of error. More detailed guidance and method statements would be expected to be available in company manuals and operational documentation.

7.2 Safety

The earthing related measurements described in this section are potentially hazardous. They must be carried out by competent staff using safe procedures following a thorough assessment of the risks. The risk assessment should include, but not be limited to, consideration of the following aspects and the necessary control measures implemented, e.g. personal protective equipment, special procedures or other operational controls.

- a) Potential differences that may occur during earth fault conditions between the substation earthing system and test leads connected to remote test probes. The likelihood of an earth fault occurring should be part of this assessment, e.g. not allowing testing to proceed during lightning conditions or planned switching operations.
- b) Potential differences that may occur between different earthing systems or different parts of the same earthing system. In particular, approved safe methods must be used when disconnecting earth electrodes for testing and making or breaking any connections to earth conductors which have not been proven to be effectively connected to earth*.
- c) Potential differences occurring as a result of induced voltage across test leads which are in parallel with a high-voltage overhead line or underground cable.
- d) Environmental hazards of working in a live substation or a construction site as governed by the electricity company safety rules or the CDM regulations as applicable.
- e) Injury when running out test leads for large distances in surrounding land.

* NOTE: Disconnection from earth can cause voltage differences to arise in the case of the path from tower line-earthing system due to induction; as it is related to current in the tower line, and therefore present continuously, it represents a particularly serious hazard.

7.3 Instrumentation and Equipment

It is imperative that measurements are taken using the most suitable instrumentation for the required task which is in good working order and has a valid calibration certificate. The instrumentation will be used for field measurements in all weather conditions. It must therefore be robust, have a sufficient level of water resistance and be suitably protected from electrical transients (e.g. by fuses) and shielded for use in high-voltage installations. Further advice on this may be sought from a reputable instrument manufacturer.

Instruments shall be calibrated regularly (e.g. annually) to a traceable national standard. Heavily used instruments should be checked more frequently, e.g. against other calibrated instruments or standard resistors, between formal calibration periods. Instruments must be

2092 periodically serviced/safety tested and any identified damage or faults must be rectified before
2093 re-use.

2094 Many of the measurements require ancillary equipment such as test leads, earth rods,
2095 connection clamps, etc. and it is equally important that these are also fit-for-purpose and well-
2096 maintained.

2097 **7.4 Soil Resistivity Measurements**

2098 **7.4.1 Objective**

2099 Site specific measurements are required to determine the resistivity of the materials (soil, rock,
2100 etc.) that make up the ground where an earth electrode is installed. The results obtained can
2101 be interpreted to provide a uniform equivalent resistivity for use in standard design equations
2102 (EREC S34) or a multi-layer soil model, which can be used in commercially available computer
2103 simulation tools. Important design parameters such as the earth resistance and EPR are
2104 strongly dependent on the soil resistivity so it is essential for the accuracy of the design that
2105 proper attention is given to these measurements and their interpretation as early as possible
2106 in the design process.

2107 **7.4.2 Wenner Method**

2108 A four-terminal earth tester is used for these measurements. There are a number of available
2109 measurement techniques which involve passing current through an array of small probes
2110 inserted into the surface of the soil and measuring the resulting potentials at specified points.
2111 Using Ohm's law a resistance can be calculated which may be related to the apparent
2112 resistivity at a particular depth using suitable formulae. Varying the positions of the probes,
2113 and hence forcing the current to flow along different paths, allows the apparent resistivity at
2114 different depths to be measured. The most commonly used arrangement for earthing purposes
2115 is the Wenner Array (Dr Frank Wenner, US Bureau of Standards – now NIST) and this is
2116 described in more detail in BS EN 50522 UK National Annex C.

Commented [RW16]: Checked, corrected to US from UK

2117 NOTE: There are variations on the Wenner Array method using uneven electrode spacings that can be used and
2118 these include the Schlumberger Array method and the General Array method.

2119 For large substations it is important to take measurements at a number of different locations
2120 around the site so that an average may be used. In urban areas meaningful measurements
2121 may only be obtained from the nearest parks or open ground and so results from several
2122 locations around the substation are essential.

2123 **7.4.3 Interpretation of Results**

2124 It is difficult to interpret measurement results by inspection other than for a uniform or two-layer
2125 soil model. Formulae for interpretation of data for soils with three or more layers are
2126 cumbersome and practically requires the use of software. There are a number of suitable
2127 software tools available commercially. Because most of these are based on a curve-fitting
2128 approach, geo-technical information such as borehole records are useful to reduce uncertainty
2129 in the soil resistivity model by indicating layer boundary depths, materials, water table height,
2130 bedrock depth, etc. and should be used where available.

2131 Knowledge of the soil resistivity at different depths is important when designing the most
2132 effective electrode to reduce the substation earth resistance. For example, vertical rods are
2133 better suited to a soil with a high resistivity surface layer and low resistivity material beneath.
2134 Conversely, where there is low resistivity material at the surface with underlying rock then
2135 extended horizontal electrodes will be more effective.

2136 **7.4.4 Sources of Error**

2137 There are a number of sources of measurement error which must be considered when planning
2138 and carrying out these measurements. These include, but are not limited to:

- 2139 (a) influence of buried metallic structures such as bare cable armouring/sheaths, earth
2140 electrodes, pipes, etc. Measurements taken above or near buried metallic services will
2141 indicate lower resistivity values than actually exists. This can lead to under-designed
2142 earthing systems which may be costly to rectify at the commissioning stage.
2143 Measurement locations must be carefully planned to avoid interference from metallic
2144 structures by consulting service records and, where there remains uncertainty, the use
2145 of scanning methods on site. It is also important that measurements are taken at a
2146 number of different locations (minimum of two) around the site of interest so that any
2147 influenced results become apparent in comparison to unaffected results. Two
2148 orthogonal sets of measurements can also help to indicate an error;
- 2149 (b) interference from stray voltages in the soil or induction from nearby electrical systems
2150 may adversely affect measurement results, normally evident as an unstable reading on
2151 the instrument or unexpectedly high readings. This may be reduced by avoiding test
2152 leads running in parallel with high voltage power lines/cables or near other potential
2153 sources of interference, e.g. electric traction systems.
- 2154 (c) the wenner spacings used must be appropriate for the size of the earthing system and
2155 recommended spacings are provided in BS EN 50522 National Annex C. Spacings that
2156 are too short may not identify the lower layer resistivities which can introduce large
2157 positive or negative error into design calculations;
- 2158 (d) low resistivity soils, especially at long wenner spacings, require relatively small
2159 resistances to be measured at the surface. Instrumentation with an inadequate lower
2160 range may reach its limit and incorrectly indicate higher resistivity values than exist;
- 2161 (e) care must be taken in interpreting the measurement data. If using computer software
2162 tools, it should be remembered that the result is a 'model' of the soil conditions which
2163 is largely determined by automatic curve-fitting routines or user judgement. To increase
2164 confidence it is good practice to 'test' the model by comparing it to other geological
2165 data available for the site and the expected range of resistivity values for the materials
2166 known to be present. Measured resistances of vertical rods installed at the site can also
2167 be compared to calculated values obtained using the soil model to increase confidence.
2168 It should be recognised that the soil resistivity model may need to be refined throughout
2169 the project as more supporting information becomes available.

2170 7.4.5 Driven Rod Method

2171 The driven rod method is an alternative to the Wenner Method which is particularly useful in
2172 built-up urban areas where there is inadequate open land to run out test leads. This method
2173 should be used with caution and measures must be taken to avoid the possibility of damage
2174 to buried services, in particular HV cables. Where the absence of buried services cannot be
2175 established, rods must not be driven. An earth rod is driven vertically into the ground and its
2176 earth resistance measured as each section is installed using either of the methods from
2177 Sections 12.5 and 12.6. Using a simple equation (for uniform soil equivalence – refer to ENA
2178 EREC S34) or computer simulation (for multi-layer analysis) the soil resistivity may be deduced
2179 from the measured rod resistance and its length in contact with the soil. This method can be
2180 cost-effective as the rods can be used as part of the earthing installation. Where possible the
2181 results from driven rods at a number of locations around the site should be used together with
2182 any available Wenner Method data to improve confidence in the derived soil resistivity model.

2183 7.5 Earth Resistance/Impedance Measurements

2184 7.5.1 Objective

2185 The substation earth resistance or impedance is normally measured where practicable on
2186 commissioning of a new substation and subsequently at maintenance intervals. The

2187 measurement will include all earthing components connected at the time of the test and the
2188 result represents the value which is normally multiplied by the ground return current to
2189 determine the EPR. This method may also be used to measure the earth resistance or
2190 impedance of individual electrodes, tower footings or tower line chain impedances. (Refer to
2191 ENA EREC S34 for details of chain impedance and relevant calculations).

2192 7.5.2 Method

2193 The most commonly used method of measuring substation earth resistance or impedance is
2194 the fall-of-potential method and this is described in BS EN 50522 UK National Annex C. It
2195 requires temporary electrodes to be installed in the ground some distance from the substation
2196 and connected back via trailing leads. A standard four-pole earth tester should be used (as
2197 opposed to a three-pole tester – refer to 7.5.4(e) to inject a small test current into the earth
2198 electrode and returned via a remote probe. A voltage gradient is set up around the electrode
2199 and a second probe is used to measure this with respect to the electrode voltage rise. The
2200 resistance is calculated and results are normally presented as a curve of resistance versus
2201 distance from the substation along a particular route. Voltage measurements may be taken
2202 along any route but traverses which are parallel or orthogonal to the current lead are most
2203 commonly used and are more readily interpreted using standard methods.

2204 Most commercially available earth testers use a switched DC square wave signal. Where it is
2205 possible to select a very low switching frequency (below 5 Hz) the measured values will
2206 approach the DC resistance which will be accurate for small earth electrode systems in
2207 medium to high soil resistivity. When higher switching frequencies are used (128 Hz is
2208 common) inductive effects may be evident in the results. Where an appreciable inductive
2209 component is expected and long parallel test leads are used it is advisable to use an AC
2210 waveform, so that mutual coupling between the test lead may be subtracted and a true AC
2211 impedance obtained. Because of the appreciable standing voltage commonly found on live
2212 substation earth electrodes, AC test signals are normally selected to avoid the fundamental
2213 and harmonic frequencies. For the most accurate results, measurements should be taken
2214 using frequencies either side of the power frequency to allow interpolation. Additional guidance
2215 may be found in IEEE 81 (add ref).

2216 It may not be possible to use the fall-of-potential method where no suitable routes exist for the
2217 test lead / probe set up, e.g. in urban or industrial areas. Alternative methods must be used in
2218 these locations as described in Section 7.6.

2219 The substation earth resistance or impedance can also be measured by injecting a current
2220 from a generator connected to a remote substation earthing system via a de-energised power
2221 line. The rise in electrode potential is then measured with respect to another remote earth
2222 electrode such as a telecommunication circuit earth. This method is more costly in terms of
2223 equipment resources and circuit outages; it is rarely used in the UK. Experience has shown
2224 that care must be taken to ensure that there are no unwanted metallic paths between the
2225 substation electrode and either of the reference electrodes as this will divert current and
2226 introduce errors, unless the diverted current can be measured and a correction applied. This
2227 is especially difficult to achieve in urban environments, otherwise this technique would be a
2228 good option where no suitable area for a fall-of-potential measurement exist.

2229 7.5.3 Interpretation of Results

2230 Earth resistance or impedance measurement results are normally in the form of a series of
2231 points on a curve which must be interpreted using a mathematical rule or procedure. Care
2232 must be taken in selecting a suitable method and their limitations must be understood. More
2233 detail on the methods available is given in BS EN 50522 UK National Annex C.

7.5.4 Sources of Error

There are a number of sources of measurement error which must be considered when planning and carrying out these measurements. These include, but are not limited to:

- (a) influence of buried metallic structures such as bare cable armouring/sheaths, earth electrodes, pipes, etc. Measurements taken above or near buried metallic services will generally underestimate the substation resistance. Measurement locations must be carefully planned to avoid interference from metallic structures by consulting service records and, where there remains uncertainty, the use of scanning methods on site. Measurement results that have been influenced by a parallel buried metallic structure will typically be lower than expected and the resistance curve will be flat. A metallic structure crossing the measurement traverse at right-angles will result in a depression in the resistance curve. If interference is suspected the measurement should be repeated along a different route or an alternative method used;
- (b) the distance between the substation and the remote current probe is important to the accuracy of the measurement. The theoretical recommended distance is between five and ten times the maximum dimension of the earth electrode with the larger separations required where there is underlying rock. In practice, where there is insufficient land to achieve this, the current probe should be located as far away from the substation as possible. Measurements taken using relatively short distances between the substation and return electrode may not be accurately interpreted using standard methods and require analysis using more advanced methods. Typical distances used range from 400 m for standard 33/11 kV Primary Substations up to 1000 m or greater for large transmission substations or for large combined systems;
- (c) interference caused by standing voltage ('noise') on a substation earthing system may result in standard earth testers failing to produce satisfactory results. This is normally evident as fluctuating readings, reduced resolution or via a warning/error message. Typical environments where this may be experienced include transmission substations (275 kV and 400 kV), railway supply substations or substations supplying large industrial processes such as arc furnaces or smelters;
- (d) results must be interpreted using an appropriate method and compared to calculations. Where there is significant difference further investigation is required. Interpretation using the 61.8% Rule or Slope Method may not be appropriate in all circumstances as they are based on simple assumptions; Detailed analysis using computer software may give greater accuracy where:
 - the soil resistivity is non-uniform, i.e. multi layered soils;
 - where the current return electrode is relatively near to the electrode under test, e.g. less than five times the size of the earth electrode being tested;
 - for a large and irregular shaped electrode where the test is taken far away from the centre of the electrode
 - where there are known nearby buried metallic objects that may have influenced the measurements.
- (e) use of a three-pole earth tester is acceptable where the resistance of the single lead connecting the instrument to the electrode is insignificant compared to the electrode resistance. These instruments are generally suitable only for measuring small electrode components such as rods or a small group of rods in medium to high resistivity soils. For larger substations or low resistance electrodes a four-pole instrument is essential to eliminate the connecting lead resistances which would otherwise introduce a significant error.

7.6 Comparative Method of Measuring Earth Resistance

7.6.1 Objective

To measure the earth resistance of small individual electrode components within a large interconnected earthing system. This method is most effective where a relatively high resistance electrode is measured in comparison to a 'reference earthing system' which has a much lower resistance.

7.6.2 Method

Two different approaches may be used as follows:

- The first method, illustrated in Figure 12.1, requires that the electrode being tested is disconnected from the remainder of the substation earthing system, e.g. immediately after installation prior to the connection being made or via opening of a test link at existing sites. A standard four-pole earth tester may be used with terminals C1 and P1 connected to the electrode component being tested. Terminals C2 and P2 are connected to the 'reference earth'. Current is circulated around the earth loop containing the electrode and the reference earth resistances and the voltage developed across them is measured. Using Ohm's Law the series 'loop resistance' is calculated and if the reference earth resistance is sufficiently low relative to the electrode resistance the measured value will approach the electrode resistance.
- The second method, illustrated in Figure 12.2 uses a similar principle but does not require disconnection of the electrode. A clamp type meter is placed around the connection to the electrode which generates and measures current and voltage in the electrode loop and displays the 'loop resistance'. The advantage of this method is that the earth electrodes may be tested without disconnection hence avoiding the associated safety risks and the need to apply earth disconnection procedures. This is the preferred method for safety and facilities should be included in the design to allow access to rods for testing with a clamp meter.




Figure 12.1 — Illustration of Earth Resistance Measurement using the Comparative Method and a Four-Pole Earth Tester (Test Electrode Disconnected).

Commented [PR17]: Rob- I think the figure heading should be in Caption but 10pt instead of 9 (it's the same a figure headings but 1 pt. down and not centrally aligned) I think the title should be above with the figure reference below?




Figure 12.2 Illustration of Earth Resistance Measurement using the Comparative Method and a Clamp Type Resistance Meter (Test Electrode Connected)

7.6.3 Interpretation of Results

In order to accurately measure an electrode resistance via this method it is necessary to have a very low reference earthing system resistance compared to the electrode resistance (10% or lower is recommended). It is also necessary to have a reasonable physical separation between the electrode and reference earth to reduce mutual coupling through the soil.

If the reference earth resistance is too high the measured result will be significantly higher than the Electrode resistance (if it is known it can be subtracted). If the electrode and reference earths are too close together then a value lower than the electrode resistance may be measured. These errors may be acceptable if the purpose of the measurement is a maintenance check where it is only necessary to compare periodic readings with historical results to identify unexpected increases, e.g. due to corrosion or theft.

If several different electrodes can be tested with respect to the same reference earth more detailed interpretation methods may be developed to increase confidence in the individual electrode resistances and in some circumstances allow the reference earth resistance to be deduced.

7.6.4 Sources of Error

- (a) If the reference earth resistance is too high relative to the electrode resistance the measured value may be significantly higher than the electrode resistance. An approximate assessment of this may be made by comparing the physical area covered by the respective earthing systems, e.g. a rod electrode measured with respect to a large substation earth grid would be expected to provide a reasonable accurate resistance for the rod electrode.
- (b) Where the test electrode and reference earth are in close proximity to each other there will be significant mutual coupling via the soil which may result in an apparently lower reading than the true electrode resistance.
- (c) The electrode under test may be inadvertently in contact with the reference electrode below ground level, or otherwise connected to it. The test current is then circulated around a loop and does not represent the intended earth electrode resistance.
- (d) This method cannot be directly used to measure the overall substation earth resistance which requires the use of the fall-of-potential method described in Section 12.6.

7.7 Earth Connection Resistance Measurements (Equipment Bonding Tests)

7.7.1 Objective

To measure the resistance between a plant item and the main substation earth electrode to check bonding adequacy. This is essential during commissioning of a new substation to confirm that each item of plant is effectively connected to the earth electrode system. It is also useful as an on-going maintenance check and for operational procedures, e.g. post-theft surveys.

7.7.2 Method

The procedure is based upon the principle of measuring the resistance between a set point (or points) on the main electrode system and individual items of earthed equipment. A micro-ohmmeter is used and the connection arrangement is illustrated in Figure 12.3. Measurements can be taken from one central point (such as the switchgear earth bar) or, to avoid the use of unduly long leads, once a point is confirmed as being adequately connected, it can be used as a reference point for the next test and so on.




Figure 12.3 Connections for Earth Bonding Conductor Resistance Measurements

To establish that a satisfactory connection exists between the grid and any exposed metalwork it is necessary to measure in the micro-ohms or milli-ohms range. An injection current of at least 100 mA is recommended.

The probable path of the injected current must be considered and where the substation uses a bus-zone protection scheme care must be taken to ensure that any test current does not produce enough current to operate protection systems.

Special procedures must be adopted when checking bonding between a substation earthing electrode and a terminal transmission tower. If the bond is ineffective or missing a potential difference may exist which may pose a shock hazard or damage to a test instrument. Normally these methods will include checking current flow in the terminal tower legs prior to testing as a higher proportion of current will flow in a leg with an effective connection to the substation. This would be supplemented by voltage measurements using suitably insulated probes and meters and buried electrode location techniques.

7.7.3 Interpretation of Results

The measured resistance between the two connection points will depend on the length, cross-sectional area, material and number of earth conductors between them. Based on a maximum distance of 50 m between connection points, a threshold value of 20 mΩ will provide a good indication of when further investigation is required.

7.8 Earth Conductor Joint Resistance Measurements

7.8.1 Objective

To measure the resistance across an earth conductor joint to check its electrical integrity. This is normally performed for every joint created at a new substation prior to backfilling. It is also carried out during periodic maintenance assessments.

7.8.2 Method

The method described uses a micro-ohmmeter to measure electrical resistance and is suitable for bolted, compression, brazed and welded joints. It does not check the mechanical integrity of welds or for voids inside a joint.

Most micro-ohmmeters are supplied with standard leads with two sharp pins that can penetrate through paint or surface corrosion to reach the metal underneath. The first set of leads is connected to one side of the joint and the second set to the other as illustrated in Figure 12.4. Ideally, the connectors should be no more than 25 mm either side of the joint. A suitable scale must be selected on the instrument (normally a minimum current of 10 A is required to measure in the micro-Ohm range) and an average value recorded after the test polarity has been reversed.




Figure 12.4 Connections for Earth Conductor Joint Resistance Measurements

Joints must also be mechanically robust and survive a firm tap with a steel hammer.

7.8.3 Interpretation of Results

The measured resistance should not significantly exceed that of an equivalent length of conductor without a joint. Joints which exceed this by more than 50% must be remade. Where different sized tapes are involved, the threshold value used should be that of the smaller tape.

At new installations it is recommended that a few sample joints are made under controlled conditions (e.g. in a workshop), their resistance measured and the median of these values used as the benchmark for all other similar joints made at the installation.

7.9 Earth Potential Measurements

7.9.1 Objective

To measure Touch, Step and Transfer Voltages (e.g. 'Hot Zones') for comparison with calculated values. These measurements may be required to confirm that the installed design complies with the main safety limits (see Section 4.4). Advanced techniques and equipment are required to perform these measurements at live substations and guidance on the different methods available can be found in IEEE 81 (add ref).

7.9.2 Method

Earth potential measurements may be measured by injecting a current into the substation electrode and returning through a remote electrode via a connecting conductor. The return electrode may be another substation electrode connected via a de-energised power line or a temporary test lead and set of probes. Providing the return electrode is located at a large distance from the substation (relative to the size of the substation electrode) a potential profile will be set up around the substation proportional to that which would exist during fault conditions. The voltage between the substation electrode and different points on the surface can then be measured and related to Touch Voltage. Step Voltage can also be determined from measurements of the potential difference between points on the surface which are 1 m apart. In both cases the actual touch voltage can be found by scaling in the ratio of the test current and fault current.

In a similar way, the potential gradients may be measured around the substation, for example emanating out from each corner, and equipotential contours derived to provide Hot Zone information. Measurements may also be carried out to determine the voltage transferred from a substation electrode to a nearby metallic structure, e.g. a steel pipe or the earthing system associated with a different electrical system.

7.9.3 Interpretation of Results

The measurement results must be interpreted by competent engineers and compared to calculated values. It is recommended that a series of measurements are taken at a number of locations around the substation where high touch or step voltages are expected (normally at the corners or in areas where the electrode mesh is less dense). This will enable the trends in the voltage gradients to be assessed to identify spurious data points. Where the return electrode is not located sufficiently far away from the test electrode large errors may be introduced. These errors may be corrected using a detailed computer model or by averaging the measurements obtained using different current return electrode locations.

7.10 Earth Electrode Separation Test

7.10.1 Objective

To assess the electrical separation of two electrodes in the soil by measurement, e.g. segregated HV and LV electrodes at an 11 kV distribution substation or a substation earth electrode and a separately earthed fence.

7.10.2 Method

This method requires that the earth resistances of the two electrodes (R_1 and R_2) have been measured separately using the fall-of-potential method described in Section 12.5.

Similar connections are then made as the bonding integrity checks (figure 12.3) and the 'earth loop' resistance (R_3) of the two electrodes via the ground is measured.

7.10.3 Interpretation of Results

If the two electrodes are separated by a large distance then the R_3 will approach the series resistance of $R_1 + R_2$. Lower measured values of R_3 indicate a degree of conductive coupling through the soil. Generally, for the purposes of checking satisfactory segregation of earth electrodes the following test is used: $R_3 > 0.9(R_1 + R_2)$. Values lower than $0.9(R_1 + R_2)$ may indicate inadequate separation and further investigation is required (refer to Section 9.7.3).

7.11 Buried Earth Electrode Location

7.11.1 Objective

At older substation sites, whilst an earthing system is in place, a record of its design may not exist or may be out of date. An earthing record is desirable to ensure that the design is satisfactory and to assist in the planning of new construction work. The record should include the position of the electrode, its burial depth, material, size and installation method (e.g. above ground, in ducts, or buried directly).

Where existing electrode needs to be located within live substations, surface detection methods are usually the lowest cost option.

7.11.2 Method

The most effective surface detection techniques, found by experience are documented below. This includes commercially available low to medium frequency systems and Ground Penetrating Radar (high frequency) systems. It should be noted that these methods are subject to interference from other buried services and often need to be supplemented by trial excavations.

A low to medium frequency system comprises a transmitter and receiver, working at frequencies from 50 Hz (detection of live mains cables) to nearly 100 kHz. The transmitter injects a signal into the earthing system which is to be traced (the "target line"). As this signal passes through the earth electrodes, it radiates an electric and magnetic field, one or both of which can be detected and interpreted by coils in the receiver. Basic receivers simply emit an audio tone as they are passed over the target line. More advanced receivers give information, such as burial depth and test current magnitude. This feature can sometimes enable one to distinguish between the target line and others which have erroneously picked up the transmitter's signal through coupling.

A ground penetrating radar system, used in conjunction with appropriate analysis software, can also be used to produce a reasonable graphical image of structures below the surface. Radar systems detect the dielectric contrast between a target and its surroundings and so are well suited for detecting conductive, metallic electrodes against soil which is relatively resistive. They are well suited to drained, high soil resistivity locations. The radar system is usually guided over the trace area in a grid pattern, with detection results being stored for later analysis by the computer.

Where neither of the above methods are conclusive, e.g. in areas with a high density of buried services, selected trial holes may be required.

8 MAINTENANCE

8.1 Introduction

Earthing systems shall be inspected, maintained and repaired so as to ensure they will operate in the manner required on an ongoing basis.

8.1.1 Inspection

This falls into two main categories:

- (a) Visual Inspection
- (b) Detailed Physical Examination and Testing

When setting inspection, testing and maintenance regimes for a substation consideration shall be given to identifying and where necessary rectifying issues arising from:

- physical deterioration and damage/theft;
- inappropriate installation alterations or third party actions which prejudice the principal of operation of the earthing system;
- inappropriate installation / design;
- changes to system operating regimes or construction which alter the magnitude, flow and / or duration of earth fault current to values outside the original earthing system design parameters;
- magnitude of EPR and how close touch and step potentials are to safety limits.

The frequency of inspection and testing should be set according to EPR, risk of theft, damage, and deterioration. It may be revised from time to time if circumstances change.

If an extraordinary event occurs (e.g. delayed fault clearance) then additional ad hoc inspection and testing may be required

8.1.2 Maintenance and Repairs

When undertaking repairs or minor alterations to damaged earth conductor and buried electrode the procedures adopted must take into account:

- Broken conductors may operate at elevated voltages even when the rest of the associated network is operating normally.
- The possibility of transient or sustained system earths fault occurring while repairs are being undertaken.

Inspection, testing and maintenance work must be undertaken in accordance with company operational and safety procedures. Where required risk assessments and method statements will be prepared. Inspectors must wear company specified personal protective equipment and only approach plant and equipment when it is safe to do so. See Sections 8.3 and 8.4 for further issues.

8.2 Types of Inspection

8.2.1 Introduction

The main types of inspection may be summarised as:

- a frequent basic visual inspection to check there is no visible damage, theft or obvious impairment of the earthing system;
- a less frequent and more detailed visual inspection to review the standard of construction and condition as well as checking for damage, theft and impairment;
- an infrequent more thorough visual inspection combined with testing, measurement and analysis.

For an open busbar substation typical areas to be inspected include earth connections associated with:

- aluminium, steel, concrete and wood structures;
- towers, earthed poles and above ground cable connections within or adjacent to the substation site.
- isolator mechanisms, fault-throwing switches, earth switches and control kiosks including associated surface and buried earth mats;
- transformers, reactors, VTs, CVTs, CTs, surge-arresters and arcing horns;
- transformer neutral links and switches and associated connections to earth either direct or via earthing resistors, reactors or earthing transformers;
- metallic Fencing and gates;
- indoor switchgear (if present) including connections to plant, cables, structural steel work and earth bars.

8.2.2 Frequent Visual Inspection

This can form part of a normal routine substation inspection procedure or be a part of the procedures operation staff conduct when entering a substation. The objective is to frequently and quickly check for visible damage, theft or obvious impairment of the earthing system.

During routine visual inspections accessible earth connections associated with key items of electrical plant in the substation should be checked. Procedures such as lifting trench covers will normally be avoided unless the initial inspection gives cause for concern.

8.2.3 Infrequent Detailed Visual Inspection

Before commencing a detailed examination, the substation earthing records should be checked to confirm they correspond to the actual layout. The inspector should be aware of the fence earthing arrangement and whether it is independently earthed or bonded to the earth grid or a mixture of both.

The key items covered in the Frequent Inspection plus all other accessible connections to plant, circuits and civil infrastructure should be inspected thoroughly. As well as condition, the standard of construction should be reviewed against present practices and any inadequacies reported. Checks for damage, theft and impairment of the earthing system should also be carried out. Visual checks should be carried out on less accessible earthing conductors not covered in the Frequent Inspection such as those located under trench covers or located in basements.

2571 The results of all inspections must be documented in accordance with company procedures.

2572 A pre-prepared check list for each site will assist consistent reporting and record keeping.

2573 8.2.4 Detailed Visual Inspection, Testing and Analysis

2574 This consists of four related parts:

- 2575 • A thorough detailed visual inspection and review of the earth connections to all electrical
- 2576 plant, circuits and civil infrastructure as per 8.2.3
- 2577 • Carrying out specific testing and measurement of the earthing installation as per 8.2.4.1
- 2578 • Selecting portions of the buried electrode system for examination via trial holes as per
- 2579 8.2.4.2
- 2580 • Analysis and recording of results including review of EPR related issues as per 8.2.4.3

2581

2582 8.2.4.1 Testing

2583 See Section 7 for specific measurement and analysis techniques.

2584 Testing may include:

- 2585 (i) Measurement of the overall substation earth resistance/impedance value;
- 2586 (ii) Measuring resistance of:
 - 2587 • Individual earth electrodes
 - 2588 • Rod and plate groups
 - 2589 • Fence earth rods
 - 2590 • Test electrodes (where fitted).
 - 2591 • Surge arrester, CVT and GIS high frequency earths;
- 2592 (iii) Measurement of soil resistivity;
- 2593 (iv) Resistance tests across a representative sample of important joints using a micro-
- 2594 ohmmeter. The value should be recorded and compared with the values
- 2595 recommended by the manufacturer, or taken for similar joints elsewhere. Any joint
- 2596 where the resistance value is excessive will require to be broken down, cleaned
- 2597 and remade, or replaced;
- 2598 (v) Confirmation of continuity between key items such as transformers, switchgear,
- 2599 terminal tower(s) etc. and the main substation earth grid using a micro-ohmmeter.
- 2600 This is especially important for items where corrosion, theft or damage is
- 2601 considered to have prejudiced the integrity of the connection;
- 2602 (vi) Confirmation of continuity between adjacent site earthing systems;
- 2603 (vii) Confirmation of whether metallic fences are isolated from or bonded to the main
- 2604 substation earth grid by carrying out a separation test;
- 2605 (viii) For substations fitted with frame leakage earth fault protection checking the integrity
- 2606 of the segregation between earth zones by testing and/or visual inspection and also
- 2607 testing across cable terminations where island glands are fitted;
- 2608 (ix) Measurement of Soil pH value;

Commented [PR18]: G0 - Sub divisions of lists should be in Roman numerals, consider changing main list to a, b, c and sub to i, ii etc.

- 2609 (x) Tracing of buried electrode if required to update the substation earthing drawing;
- 2610 (xi) Segregation tests and review of segregation between distribution substation HV
2611 and LV earths. (Refer to Sections 7.10 and 9.7);
- 2612 8.2.4.2 Selected Excavation and Examination of Buried Earth Electrode
- 2613 Since the earth electrode system is largely buried, it is impracticable to carry out a detailed
2614 examination of the whole installation. However, it cannot be assumed that the buried electrode
2615 system, once installed will remain in good condition.
- 2616 Particularly where a substation site is associated with former industrial use such as a coal
2617 power station or foundry which may have produced corrosive material used as landfill there is
2618 enhanced risk of corrosion of buried copper conductor. A similar risk may also arise if material
2619 from such sites is imported to construct a substation. It is recommended that representative
2620 locations be chosen to excavate and expose the buried electrode, in order to check its
2621 condition.
- 2622 These should include some below ground connections, e.g. an earth rod connection position,
2623 or other locations where the electrode is jointed. Several connections from above ground plant
2624 should be uncovered back to the connection to the buried earth tape/grid, to check their
2625 condition through the layers of chippings and soil. Conductor size should be compared with
2626 records.
- 2627 Whilst carrying out excavation, the soil pH value should be checked. This should lie between
2628 6.0 and 10.0. For pH values outside these limits, it is probable that corrosion of the copper
2629 conductors/connectors will be evident. In the past, power station ash has been used as
2630 bedding for earth electrodes. This is known to be acidic, and is likely to cause corrosion of the
2631 conductors.
- 2632 Where tests show the pH value of the soil to be outside the limits, if the copper electrode is
2633 corroded, then repairs or a new electrode system and either some imported soil or an inert
2634 backfill (such as bentonite) is required. If the electrode has limited corrosion, then a soil /
2635 corrosion investigation is necessary to assess the risk of future corrosion and any precautions
2636 necessary. Normally the corrosion rate will be uneven, with severe corrosion in some areas
2637 and none in others. Severely corroded electrodes will need to be replaced, whilst that
2638 elsewhere will need to be monitored and measures taken to limit corrosion in all important
2639 areas.
- 2640 Should examination of the exposed conductors or connections give cause for concern, then
2641 additional excavations elsewhere on site may be necessary to assess the extent of the
2642 problem.
- 2643 8.2.4.3 Analysis and Recording of Test Results
- 2644 Resistance values for the substation, individual electrode groups and for joints should be
2645 recorded and where previous values are available compared to indicate any trend.
- 2646 The earthing drawing should be updated if required with revised electrode sizes and positions.
- 2647 Once a new substation earth resistance is obtained it should be used to recalculate the
2648 substation EPR using up to date earth fault current data and earth fault current return paths
2649 (earth wires/cable sheaths etc). Safety voltages and conductor current ratings should be
2650 recalculated and any deficiencies identified.
- 2651 The presence (or otherwise), values and configuration of any resistances / impedances placed
2652 in high voltage transformer neutrals should be recorded and aligned with those contained in
2653 the company power system model.

2654 Defects should be listed and prioritised for remedial action.

2655 **8.3 Maintenance and Repair of Earthing Systems**

2656 In some cases, earthing related maintenance and repair work will be reactive, following theft
2657 or damage revealed by an inspection.

2658 Before undertaking earthing system repair or measurement work, the responsible person in
2659 charge of the work must familiarise themselves with the site specific risks and consequences
2660 of:

- 2661 • Working on or touching unsound earthing systems;
- 2662 • Open circuiting (even for a short time) earth conductor circuits;
- 2663 • Extending (even temporally) earthing systems from sites where touch and step potentials
2664 are controlled;
- 2665 • Working on broken earthing conductors;
- 2666 • An earth fault occurring on the system being worked on. For primary substations
2667 supplying extended high voltage rural overhead line networks this can be a relatively
2668 frequent occurrence (e.g. at least once a week). Supervisors should avoid work or testing
2669 being carried out in high risk periods such as during storms or fault switching.

2670 There is risk of serious or fatal electric shock when working on intact and depleted/damaged
2671 earthing systems. The responsible person in charge of any remedial work should be suitably
2672 qualified to undertake this area of work. Network Operators should develop their own
2673 policies/procedures for dealing with depleted earthing systems.

2674 Specialised equipment including insulated rods, shorting leads and conductor clamps are
2675 required to make repairs. PPE including insulated footwear and gloves must be available if
2676 required.

2677 High voltages can appear on earth system conductors even under normal running conditions.
2678 Items requiring particular caution include connections associated with CVTs, transformer
2679 neutrals, underground cable bonding arrangements and connections between main earth grids
2680 and overhead line towers.

2681 Examples of situations requiring remedial work include:

- 2682 • broken or damaged below ground earthing conductors which have been exposed in the
2683 course of excavation work;
- 2684 • broken or damaged bonding conductors on underground cable systems (such as cross-
2685 bonding connections that can be expected to carry significant current under normal
2686 operating conditions);
- 2687 • repairs to/replacement of high resistance earth connections (Para 8.4);
- 2688 • minor alterations to/diversions of earthing systems for construction work;
- 2689 • repairs after theft of earthing conductors (Remedial work on depleted earthing systems is
2690 normally the subject of a bespoke company instruction and is outside the scope of this
2691 document).

2692

8.4 Procedure for the Remaking Defective Joints or Repairing Conductor Breaks

8.4.1 Introduction

It may be necessary to remake a joint or repair a break on the earth electrode system at a substation for a number of reasons:

- (a) The joint is obviously damaged.
- (b) The joint has failed a micro-ohmmeter test.
- (c) An earth electrode has been severed.
- (d) A minor diversion of the electrode system or other repair work may be proposed.

Should a fault occur during the period when a repair is being carried out, to prevent danger from a high voltage, which could appear across the joint, precautions must be taken.

The design of the earth grid (if present) may or may not be adequate to eliminate danger to personnel when touching a bare broken conductor even after a temporary earth continuity conductor has been applied.

Before carrying out any repairs, the joint or break to be repaired must be short-circuited by connecting a fully-rated conductor to positions either side of the break or defective joint. This short must be applied using an approved procedure involving insulated rods.

If company policy so states or any doubt exists the operator shall wear insulating footwear and gloves designed for electrical application when handling earth conductor to make a permanent repair.

Whilst carrying out work, the operator should stand within the boundaries of the earth grid, or immediately above a bare buried earth conductor.

For example, if a terminal tower earth connection is broken, a significant potential difference may be present between the tower and earth grid. Arcing and current flow will occur when trying to remake the connection. Insulated rods and approved connectors are required to apply the initial short-circuit. The repairs, as detailed in the next paragraph, can then be carried out.

Similarly high voltages may appear across open circuited cross bonding conductors on high voltage underground cable circuits.

8.4.2 Joint Repair Methods

- (i) Compression Joint – Cannot be repaired, must be replaced.
- (ii) Mechanical Connector - Disconnect, clean all contact surfaces, apply a company approved contact lubricant, reconnect and re-tighten.
- (iii) Cold-weld/Exothermic weld Joint - If defective this type of joint must be replaced.

On completion of repair of any joint, having first connected the instrument across the joint, the temporary earth continuity conductor* should be removed; a micro-ohmmeter resistance test must then be carried out across the joint.

* Shorting strap

8.4.3 Flexible Braids

Flexible bonding braids or laminations should be inspected for signs of fracture and corrosion and changed as required. A protective compound may be applied to flexible braids where corrosive conditions exist.

9 Ground Mounted Distribution Substation Earthing

9.1 Introduction

Whilst the general principles of earthing can be applied to all voltage levels, small (distribution) substations providing supply to LV networks can present their own additional challenges. The key earthing related differences between distribution (or 'secondary') substations, and larger ('primary', or 'grid' substations) include:

- high voltage distribution apparatus is often located in densely populated areas in close proximity to the public;
- earth fault clearance times on distribution systems are usually longer;
- many older 'legacy' installations do not have the benefit of a comprehensive earth grid environment, as they rely on metallic sheath cable systems to control touch and step potentials;
- low-voltage earth connections may be combined with HV earthing systems, or in close proximity to them;
- connections from the low voltage distribution system are taken into almost every property;
- for new connections distribution network operators have a legal obligation to provide a low voltage earth terminal to their customers as long as it is safe to do so;
- the low voltage system must be earthed such that earth potential rise due to high voltage earth faults does not cause shock or injury (to installation users, public or staff) or damage to internal electrical installations, distribution equipment or telecommunication systems.

The design issues, therefore, can be summarised as: a) achieving safety in and around the HV:LV substation, and b) ensuring that danger does not arise on the LV system as a consequence of HV faults.

The design approach outlined in Section 5.6.1 applies equally to distribution substations, and special considerations are described below.

9.2 Relocation of Pole Mounted Equipment to Ground Level

Due to the high EPR that can appear on pole mounted equipment, metallic items must not be re-located at ground level (e.g. replacing a pole transformer with a small padmount substation) without appropriate modifications to the earthing system.

Ground mounted substations will introduce a touch potential risk that is absent from pole mounted installations, and consequently require an electrode system that not only limits EPR, but controls touch and step voltages to safe limits.

Similarly, care should be exercised if other earthed equipment on the pole (e.g. auto-reclose relay cabinet) is within reach of those on the ground.

Section 10 describes pole mounted installations in detail. In either case, the decision to operate with combined HV and LV, or otherwise, must consider the voltage that will be impressed on the LV system under HV fault conditions (Section 9.5).

9.3 General design requirements

In common with any earthing system, the design of any new build substation must satisfy requirements for EPR, touch/step voltages, transfer voltages, and stress voltages. If major

changes are to be made to an existing substation, the effects of these proposed changes on the existing earthing system need to be considered. A significant consideration in all cases is the transfer potential that will be impressed on the LV network under HV fault conditions. See 9.5

9.3.1 Design Data Requirements

The data required is similar to that described in Section 5.4, as necessary to determine the current flow into the electrode system, and the fault duration. These include:

- 1) fault level at the new substation, or at the source (primary);
- 2) resistance of the earthing system at the primary substation (R_a), and at the new distribution substation (R_b);
- 3) circuit length and cable type(s);
- 4) whether there is any overhead line in the circuit.

For worst case studies, if there is any overhead line, the ground return current (I_{gr}) can be assumed equal to the earth fault current at the distribution substation (i.e. $I_{gr}\% = 100\%$).

9.3.2 Conductor and electrode sizing

Earth conductors at distribution substations will usually connect key items of plant such as transformer(s), ring main unit / switchgear, and low voltage cabinets. In many 'unit substations' these items may be supplied with bonding connections in place. These bonds must be sized as described in 5.5.1; in general they must be sized for the maximum foreseeable earth fault level. For ASC systems the limited ASC current must not be used (see Section 5.4.5). DNOs may wish to use the earth fault level at the primary substation, or higher value allowing for growth and uncertainty, up to the 3-phase fault current.

Electrodes must have sufficient surface area to meet the requirements of Sections 5.4.6 and 5.5.2. The worst case foreseeable 'electrode current' should be used for design purposes, this may be taken as the maximum earth-fault current at the substation or its source, or the larger of cross-country fault current or bypass fault current on ASC systems.

Note: If detailed modelling of current distribution is carried out, it will be seen that the 'ground return current', if calculated using a contribution from a wide area network, will be significantly higher than the local 'electrode current'. The electrode current or ground return currents may be used for electrode design purposes, providing that connection to the wider network contribution is reliable. If any doubt exists as to the prolonged integrity of sheath return paths and/or auxiliary electrode connections, the larger earth fault level (calculated for a zero ohm fault) should be used.

9.3.3 Target resistance

A HV electrode system must be established for the substation, that is of sufficiently low resistance to ensure reliable protection operation and to limit EPR (and touch/step voltages) to acceptable levels. The design process in this respect is no different to that outlined in Section 5.3. The resistance that must be achieved is termed the 'target resistance', and may be specified with and without contribution from parallel systems. Use of a target resistance for the substation's earthing system, which ensures compliance with the safety criteria, is useful as it is a more readily understood parameter that can be achieved and tested by installers. 'Network contribution' is discussed in Section 9.4.3.

For ground mounted substations, traditional custom and practice (permitted by previous versions of this standard) was to apply a target resistance (before connection to the network) of 1 ohm. If this could be achieved, it was permissible to combine the HV and LV earthing systems. No perimeter or grading electrodes were installed in such 'legacy' systems, and often only one vertical rod or horizontal electrode would be installed. This approach relied heavily

Commented [PR19]: All lists starting with a colon with incomplete sentences no full stops (except on the last line) or capitals.G0 pg.25

2820 on contributions from lead sheathed cables radiating away from the substation, and often
2821 passing under the operator's position. In this way, these cables provided a degree of potential
2822 grading (thus reducing touch potentials) as well as reducing the overall (combined) earth
2823 resistance of the substation. Experience has shown that this approach is no longer applicable,
2824 particularly given the now widespread use of polymeric (insulated sheath) cables.

2825 Network operators may find that different 'target values' for earth resistance are generally
2826 applicable in different geographical areas, and for overhead or underground networks, and
2827 thus may choose to adopt a 'rule of thumb' to assist designers and other connections providers.
2828 In any case, calculations or measurements sufficient to demonstrate that the installed system
2829 will be safe must be carried out at the design stage. Refer to 9.3.7.

2830 Target resistance values should consider all foreseeable running arrangements or network
2831 configurations, especially if the network is automated or remote controlled. Refer to Section
2832 9.9.

2833 9.3.4 EPR design limit

2834 A natural EPR design limit is imposed by a) consideration of transfer voltage onto the LV
2835 systems for combined HV/LV systems, and b) insulation withstand (stress voltage) between
2836 the HV and LV systems for segregated systems. See section 9.5 for more detail regarding
2837 separation distances. These considerations may for example, lead to typical design EPR limits
2838 of 3 kV (or higher, depending on equipment withstand voltage) for segregated systems, and
2839 466 V* for combined systems.

2840 9.3.5 Calculation of EPR

2841 The EPR for a distribution substation, for faults at that substation, is calculated in the
2842 conventional manner, i.e. by multiplying the ground return current by the overall (combined)
2843 substation earth resistance.

2844 9.3.5.1 Factors to consider:

2845 The ground return current value is influenced by the earth fault current 'split' between the soil
2846 return path and the cable sheath. The impedance of the cable sheath(s) is made up of a 'self
2847 impedance' (fixed), and a 'mutual impedance' that is dependent on a number of factors.

2848 The earth fault current is influenced by the resistance of the earthing system and the
2849 impedance of the cable sheath. The source impedance (primary substation), the resistance
2850 of the primary substation earthing system, and in particular the method of neutral earthing will
2851 have an effect.

2852 For most accuracy, some form of iterative calculation or computer model will be required to
2853 explore the relationship between fault current, EPR, and substation resistance. However, in
2854 any such design there are often other factors or unknowns / variables which may be of more
2855 significance. For this reason it may be sufficient for a design to err on the side of caution by
2856 using a 'zero-ohm' earth fault level (the maximum theoretical fault level at the distribution
2857 substation calculated using zero sequence impedances for the circuit). Fault impedance can
2858 then be introduced only if necessary to achieve an economic or practicable solution.

2859 ENA EREC S34 provides a detailed discussion of EPR calculations and includes worked
2860 examples to assist with the calculation of ground return current.

Commented [MD20]: Check if this is covered in S.34 and if so delete from 41-24

* This value is 2x the 1 second touch voltage limit of 233 volts, and replaces the previous design figure of 430 Volts.

2861 9.3.5.2 Transfer Potential from source

2862 A second contribution to EPR comes from **Transfer Potential** 'exported' from the source
2863 substation, since any EPR at the source will be conveyed along the cable sheath and will
2864 appear (in part) at the new substation.

2865 Transfer potential need not been considered if there is any overhead line in the circuit, or if the
2866 new substation is not the first on the feeder and transfer potential is known to be of no
2867 significance at previous distribution substations.

2868 In determining the acceptable transfer potential from source, the relevant protection clearance
2869 time at the source should be used in touch/step calculations.

2870 **9.3.6 Step/Touch Potentials at the Substation**

2871 Many network operators or connection providers opt for a 'standard' design of distribution
2872 substation, and it is possible to establish, by modelling or calculation, the step and touch
2873 potentials as a % of EPR for each 'standard' layout. These values are influenced to a small
2874 degree by the depth of rods and the proximity of other earthed metalwork, but for design
2875 purposes can be taken as fixed for each layout. Typical values for touch potential within a
2876 3x3m 'unit substation' that has a perimeter 'grading ring' and corner electrodes are 20-40% of
2877 EPR. A substation built on a fine (and bonded) rebar mesh might present a touch voltage in
2878 the region of 10% or less of EPR.

2879 Substations that employ a single rod electrode, or similar 'legacy' design, are unlikely to limit
2880 touch potentials to less than 75% of EPR away from the electrode, and may have unacceptably
2881 high step potentials (gradients) in the vicinity of the electrode, depending on its depth of burial.
2882 Computer modelling using an appropriate package and soil model will normally be necessary
2883 to demonstrate safety unless the system is simple enough to permit 'first principle' calculations
2884 such as those presented in EREC S34 or other relevant standards.

2885 The appropriate design limits for touch and step potential are given in Table 2 and are
2886 dependent on normal (calculated or worst case) protection operation.

2887 **9.3.7 Simplified approach**

2888 In some cases, a safe system can be achieved without detailed design calculations; DNOs
2889 may wish to instead adopt simple rules in certain geographic areas, provided these rules can
2890 be shown to produce a site with acceptable touch, step and transfer voltages. For example, a
2891 'standard' layout (perhaps consisting of a perimeter electrode and corner rods) might be
2892 appropriate if:

- 2893 a) 11 kV fault current is limited by reactor or resistor, and;
2894 b) there is a continuous cable connection to the primary substation, and;
2895 c) there is interconnection to the wider (HV and LV) network, and;
2896 d) the transfer potential from the Primary Substation is below the permissible touch
2897 voltage (taking into consideration clearance times at the primary);
2898 e) there is some 'potential grading' to limit step/touch to 50% or less of EPR (this assumes
2899 that site EPR will not exceed 2x permissible touch voltage limits).

2900 This approach is broadly consistent with that outlined in the design flowchart (Section 5.6.1).

2901

2902 Circumstances where the simplified approach is not appropriate:

2903 More detailed assessments might be needed if one or more of the following apply:

- 2904 a) there is any overhead line in circuit, or other break in the earth-return path;
- 2905 b) the substation is not interconnected to the HV or LV network;
- 2906 c) the secondary winding of the main transformer at the primary substation is solidly
2907 earthed.
- 2908 d) dedicated earth fault protection is not installed;
- 2909 e) the primary substation is a site where the EPR is greater than twice the permissible
2910 touch voltage limit for the applicable fault clearance times and there is a cable
2911 connection giving a transfer voltage consideration.

2912 In difficult circumstances a 'HPR*' but 'Safe (step/touch) voltage' design is allowable by
2913 appropriate use of grading electrode/mesh to control step and touch voltages. Alternatively,
2914 the EPR may be reduced by appropriate means (refer to Section 5.6.3 - Methods to improve
2915 design).

2916 * High (earth) Potential Rise

2917 **9.4 Network and other contributions**

2918 Distribution substations are commonly connected to larger metallic systems which can serve
2919 as an electrode. The following sub-sections describe typical contributions which may be
2920 included in design calculations.

2921 **9.4.1 Additional Electrode**

2922 In many cases it will be possible to supplement the substation's electrode system by laying
2923 bare copper, or a long 'rod nest' beneath incoming or outgoing cables (subject to
2924 separation/segregation where required), although when there are several parties involved in a
2925 project it may not be possible for the substation installer to do so without agreement with the
2926 cable installers (and landowners) at the design stage. Test facilities (e.g. an accessible loop)
2927 may be provided so that the integrity of buried horizontal electrode can be tested periodically.

2928 Electrode contribution such as this may be considered in calculations for EPR, touch/step
2929 voltages, and surface current density. It should not be included in design calculations if it is
2930 vulnerable to theft and/or damage. Suitable precautions should be taken to ensure the integrity
2931 of any such connections if they are safety critical.

2932 **9.4.2 Parallel contributions from interconnected HV and LV networks**

2933 If it is not practicable to achieve a 'safe' (compliant) design based on HV electrode (and
2934 additional electrode) contribution alone, then a reasonable 'parallel' contribution from the HV
2935 network may be included in the design (Section 9.4.3 below). However, this '**network
2936 contribution**' must not be the sole means of earthing and it is recommended that the local
2937 (HV) electrode contribution does not exceed **40 Ohms** or value sufficient to ensure reliable
2938 protection operation. In this way, there is some protection against failure of cable
2939 sheath/glands.

2940 The LV network contribution may also be used if it can be shown that it is safe to combine the
2941 HV and LV networks. Consideration should be given to the magnitude of fault current that will
2942 flow into other (parallel) systems, particularly in the case of solidly earthed HV systems, to
2943 ensure that the thermal ratings of any conductor or cable sheath are not exceeded.

2944 The thermal rating and surface current density requirements of sections 5.5.1 and 5.5.2 should
2945 ideally be satisfied where possible without reliance on network contribution, thus allowing the

Commented [RW21]: And an adequate earth for operational purposes

earthing system to withstand fault current without damage should the cable sheath/gland connections fail.

9.4.3 Ascertaining Network Contribution

The HV network or LV network, (if applicable), can serve as an effective electrode system, and will provide a reduction in earth resistance when combined with the substation earth.

The 'Network Contribution' element is difficult to establish accurately at the design stage, and measurements of the LV and HV network may be necessary to inform the design. However, due to the relatively routine nature of most 11 kV (or HV) connections, a conservative estimate is often made to expedite the design process.

The contribution from the network is (for older networks) made up of horizontal electrodes (un-insulated cable sheaths) and 'point' electrodes at distribution substations.

The cable connected distribution substations (whether connected with polymeric HV cables or otherwise) can be modelled as a 'ladder network', with cable sheath impedances forming the series elements, and earth electrode resistances forming the parallel parts. This is termed the 'chain impedance', and is akin to the treatment of metal EHV towers in ENA EREC S34. The 'chain impedance' contribution from the HV network substations falls as distance increases from the new substation. In practice the substations within a 1-2 km radius are those which need to be considered.

The 'horizontal electrode' contribution from any lead sheathed or hessian served HV cable sheaths can be treated in the same way as a buried horizontal conductor (EREC S34). In practice, each conductor will have an effective length, beyond which no additional contribution can be assumed. A practical HV network will radiate from a substation in more than one direction, and a contribution can be assumed from each 'leg' provided their areas of influence do not overlap. In cases of doubt, these systems should be modelled using appropriate computer software, or measurements carried out (taking care to use a method appropriate to the size of the network).

Calculated values for network contribution are often pessimistic in dense urban areas, where numerous parallel contributions (such as water and gas pipes, building foundations, etc.) may exist. If this is so, the designer may commission a measurement of network contribution (if possible), or may use an estimated value for network contribution, or may be able to demonstrate that the area is a Global Earthing System (GES) – see next section.

[Include reference to worked example here – S34?]

9.4.4 Global Earthing Systems

A 'Global Earthing System' (GES), is a system where all equipment is bonded together, and the ground is saturated with metallic 'electrode contributions' in the form of metallic cable sheaths or bare conductors laid direct in soil. In such a system, the voltage on the surface of the soil will rise in sympathy with that of bonded HV steelwork under fault conditions, and the voltage differences (leading to touch voltage risk) are minimal. The term is often used to describe dense urban networks where measurements or detailed calculation of network contribution is not practical. Refer to annex O (informative) in BS EN 50522 for more detail.

Network operators may wish to designate certain geographic areas as 'GES', in which case they will need to carry out measurements or analysis to demonstrate that the designation is appropriate. In addition they should carry out calculations to assess the 'target resistance' required in these areas; this is most easily achieved by assuming a low value of network contribution and designing an electrode system that is sufficient to satisfy protection operation, current density and thermal ratings in the absence of this network contribution. A standard

2992 design using perimeter electrode/rebar mesh etc. is usually still warranted for these reasons,
2993 using an appropriate resistance value to ensure safety.

2994 GES networks by definition operate with combined HV/LV earthing. It should be noted that
2995 touch potentials in GES networks can arise from transferred sources that may not be locally
2996 bonded, e.g. cable sheaths bonded to remote systems, metallic gas/water pipes with insulated
2997 covering, pilot/communications cables, and HV or LV insulated sheathed cables connected to
2998 metallic plant that is not bonded to the local 'global' earthing system. Such arrangements can
2999 cause 'islands' of higher potential inside a 'GES', and thus the benefits of a GES do not apply.

3000 **9.5 Transfer Potential onto LV network**

3001 **9.5.1 General**

3002 ESQC Regulations (2002) require that danger will not arise on the LV system as a
3003 consequence of HV faults. In practice, this means that the HV and LV earthing systems must
3004 be separated if the HV EPR cannot be limited to the applicable limit.

3005 NOTE: Previously, a design limit of 430 V has been applied, i.e. the HV and LV systems could be combined if the
3006 HV EPR was ≤ 430 V; in practice, this EPR would be impressed on the LV neutral/earth (star point). The voltage
3007 ultimately transferred to a consumer's LV earth terminal would be less than this, and the touch voltage appearing
3008 within an installation would be even lower.

3009 **9.5.2 Touch voltage on LV system as a result of HV faults**

3010 BS EN 50522 Section 6.1 Table 2 introduces the concept of 'F' factors. In order to combine
3011 HV and LV earthing systems, the HV EPR must not exceed $F \times U_{Tp}$, where U_{Tp} is the
3012 acceptable touch voltage as a function of HV fault clearance time.

3013 The 'F' factor described above relates to the percentage of EPR that will appear as a touch
3014 voltage on the LV network; it relates to the potential grading that will occur within an installation,
3015 as well as the decay in exported potential along a multiple earthed neutral conductor. The
3016 resultant touch voltage within the consumer's installation is necessarily subject to a number of
3017 factors beyond the control of any network operator.

3018 It is recommended that in the UK, a value of $F = 2$ is used unless:

- 3019 • The LV neutral/earth conductor is earthed at only one point, and:
- 3020 • The LV supplies only a small system that is isolated from the general mass of earth (e.g.
3021 a metal pillar on a concrete plinth without outgoing circuits).

3022 In such circumstances note (d) of BS EN 50522 Table 2 applies, which states: "*If the PEN or
3023 neutral conductor of the low voltage system is connected to earth only at the HV earthing
3024 system, the value of F shall be 1.*"

3025 In such circumstances a reduced EPR limit is applicable (e.g. 233 volts for a 1 second fault,
3026 see Table 1) because it must be assumed that the full EPR could appear as a touch voltage.

3027 In practice, for typical arrangements in the UK where $F = 2$, the HV EPR must not exceed 466
3028 volts if the systems are to be combined. This assumes a 1 second fault clearance time. Lower
3029 limits will apply for longer fault durations.

3030 **9.5.3 Stress Voltage**

3031 The Stress Voltage is the voltage across any two points in a substation or connected circuits.
3032 The Stress Voltage Limit relates to the insulation withstand requirement of cables and
3033 equipment.

3034 If HV and LV systems are combined then stress voltage limits are unlikely to be exceeded in
3035 the substation.

3036 For segregated HV and LV systems, stress voltage includes the difference in potential between
3037 the HV and LV earths, and may be assumed equal to the EPR of the substation. Typically this
3038 needs to be considered in the insulation withstand of the LV neutral bushing, LV neutral busbar
3039 supports, and LV cable screen where these are in close proximity to HV steelwork (a value of
3040 3 kV or more is often quoted for modern equipment).

3041 Care is needed if bringing (remotely earthed) LV supplies into such sites, particularly if feeding
3042 into metal equipment cabinets that are earthed to HV steelwork. In such circumstances the
3043 insulation withstand within the equipment should be verified to ensure that that breakdown
3044 between LV phase/neutral/earth and HV steelwork cannot occur internally. Isolation
3045 transformers may be required to ensure that HV and LV systems do not flash across under HV
3046 fault conditions.

3047 Where these criteria are met, the requirements of BS EN 50522 (Table 2) will be achieved.

3048 **9.6 Combined HV and LV earthing**

3049 HV and LV earthing systems will generally be combined if the EPR on HV steelwork does not
3050 exceed LV transfer voltage limits described above (Section 9.5).

3051 In general:

- 3052 • combine HV & LV earths if voltage rise due to an HV or EHV earth fault is safe to apply
3053 to the transformer LV earth;
- 3054 • segregate HV & LV earths if voltage rise on LV transformer earth is unacceptable.

3055 A substation with EPR limited to 466V will usually be suitable for combined earthing if supplying
3056 a PME network*. This limit is subject to the caveats described in Section 9.5.2.

3057 **9.7 Segregated HV and LV earthing**

3058 For segregated earth systems, it is necessary to ensure that the LV electrode system is sited
3059 at sufficient distance from the HV electrode so that the voltage rise on the LV network is
3060 acceptable.

3061 **9.7.1 Separation Distance**

3062 Table 11 below provide an approximate minimum separation distance based on the EPR and
3063 acceptable LV transfer limits. The values are not significantly dependent on soil resistivity
3064 once the EPR is known, although a uniform soil model is assumed.

3065 The tables are calculated for 3x3m substations and 5x5m substations, assuming both have a
3066 perimeter electrode. These are calculated values as given by **EREC S34 Equation P3**. They
3067 have been compared with modelled results (for uniform soil) and the most conservative values
3068 are presented in these tables; this represents the voltage contour furthest from the substation,
3069 such that any LV electrode beyond this distance from the substation boundary will be at or
3070 below the stated Vx figure under HV fault conditions.

3071

3072 **Table 11 - Separation distance (m) from 3x3m substation.**

* A factor of 2 can be assumed for PME networks compliant with ENA ER G12/4, i.e. the voltage appearing at the customer's earth terminal is expected to be no more than 50% of the substation EPR. This paragraph also assumes that HV faults will clear within 1 second.

EPR(V) Vx (V)	1000	2000	3000	5000
233	3.0	7.6	12.2	21.5
324	1.8	5.0	8.3	15.0
376	1.4	4.2	7.0	12.7
466	0.8	3.0	5.3	9.9

Table 12 – Separation distance (m) from 5x5m substation.

EPR(V) Vx (V)	1000	2000	3000	5000
233	5.0	12.7	20.4	35.8
324	3.0	8.4	13.9	25.0
376	2.3	6.9	11.7	21.2
466	1.4	5.1	8.9	16.6

NOTE: The following voltage limits are tabulated. For other values refer to Table 1:

233 V = 1 second touch voltage limit on soil (or EPR limit with F=1);
324 V = 162 V x 2, EPR limit applicable to 3 second faults with F=2;
376 V = 188 V x 2, EPR limit applicable to 1.5 second faults with F=2;
466 V = 233 V x 2, EPR limit applicable to 1 second faults with F=1.

These figures relate to the distance of the voltage contour at its furthest point from the substation; in some cases (multiple earthed systems) the first LV neutral/earth electrode may be sited inside the appropriate contour, refer to Section 9.7.4 and to worked examples in ENA EREC S34.

9.7.2 Transfer voltage to third parties

For substations that are close to third parties, refer to Section 4.3.3. Consideration must be given to railways, pipelines, telecommunications, cable TV, etc. if such utilities pass through an area of high potential. The formulae in EREC S34 (ref xxx) may be used to provide an indication of the EPR that may be transferred to nearby objects.

9.7.3 Further Considerations

The precise separation distance to be maintained between the HV and LV earthing systems is dependent on the EPR, the soil layer structure, and the physical layout of the earth electrodes. If necessary, it should be calculated during the design phase using the methods contained in

3095 **EREC S34** or via detailed simulation and must include the effect of electrodes located away
3096 from the substation (See Section 9.7.4).

3097 For existing substations or during commissioning of a new installation the transfer potential
3098 should be determined by measurement where practicable to confirm the calculated value. A
3099 'Separation Factor' of 0.9 or greater should be achieved (as described in Section 7.10).

3100 **9.7.4 Multiple LV electrodes on segregated systems**

3101 The separation distances above are those relating to the potential contour, such that the LV
3102 electrode(s) is/are sited beyond this. In practice, if these distances cannot be maintained, one
3103 or more electrodes on a multiple earthed neutral (e.g. PME system) may be sited within a
3104 higher voltage contour (but no closer than 3m) provided that the majority of the PME LV
3105 electrodes are sited beyond this. An above ground separation of 2m or more must be
3106 maintained to prevent simultaneous (hand-hand) contact between the systems.

3107 This assumes that the remainder of the LV system as a whole will have a resistance lower
3108 than that of the LV neutral electrode. The LV earthing system will have a 'centre of gravity' that
3109 lies outside the relevant contour, i.e. the transfer voltage will be the weighted average of that
3110 appearing at all LV electrodes. Any design based on these assumptions should be backed up
3111 by a measurement of separation factor for the installed arrangement.

3112 Refer also to **EREC S34** for calculations / worked examples.

3113 This relaxation does not apply to SNE systems or PNB systems where the neutral/earth is
3114 earthed at only one point.

3115 Where calculations based on the local LV electrode (closest to the substation) indicate
3116 impractical separation distances or excessive transfer potentials, the design should be
3117 reviewed and further LV electrodes installed at the end of LV feeder cables, connected via the
3118 neutral earth conductor. To maximise this beneficial effect, they should be located as far away
3119 from the HV electrode as possible and have a lower resistance than the LV electrode at the
3120 substation.

3121 **9.8 Situations where HV/LV systems cannot be segregated**

3122 In some situations it is not possible to segregate HV and LV systems safely without additional
3123 measures. One example is where an LV system exists within a HV system, or there are other
3124 similar physical constraints meaning that systems cannot reasonably be kept apart. Refer to
3125 BS EN 50522.

3126 In such circumstances, consideration should be given to combining the HV and LV systems
3127 and augmenting the electrode system(s) such that EPR and HV-LV transfer voltage is
3128 acceptable. If this is not practical, insulated mats/barriers could be considered in relevant
3129 areas.

3130 If necessary, the building or area could operate with a combined HV/LV system, safely yet with
3131 a high EPR provided all sources of transfer potential into/out of the 'high EPR area' can be
3132 excluded, and touch voltages are managed in and around the building. Refer to guidance on
3133 stress voltage given in Section 9.5.3 above.

3134 **9.9 Practical Considerations**

3135 HV networks are usually capable of being manually, or automatically reconfigured. The
3136 change in 'running arrangements' will affect various parameters including fault level, protection
3137 clearance time, and sheath return current/percentage.

3138 This complication means that a bespoke design for a distribution substation may not be valid
3139 if the running arrangement changes, and therefore the value of detailed design calculations on
3140 a 'dynamic' network is questionable. It is recommended that the design considers all
3141 foreseeable running arrangements, or (for simplicity) makes worst case assumptions regarding
3142 fault level, protection clearance time, and ground return current.

3143 A network operator may wish to adopt or provide a target resistance value (tailored to different
3144 geographic areas and different system earthing/protection scenarios), or other simplification of
3145 these design rules, for these reasons.

3146 **9.10 LV installations near High EPR sites**

3147 LV electrodes (segregated systems) as described above must be clear of the relevant voltage
3148 contour. The consideration also applies to any customer's TT electrode. If necessary the
3149 electrode(s) should be relocated or the shape of the high EPR zone altered by careful
3150 positioning of HV electrodes. In addition, where possible, LV electrode locations should place
3151 them clear of any fallen HV or EHV conductors.

3152 The siting of LV earths must consider zones with elevated potential e.g. some properties close
3153 to high EPR substations or EHV towers may themselves be in an area of high EPR, in which
3154 case provision of an LV earth derived from outside that zone may introduce a touch voltage
3155 risk at the installation, due to the LV earth being a remote earth reference. The arrangement
3156 can also pose a risk to other customers on the LV network if it will permit dangerous voltages
3157 to be impressed on the LV neutral/earth.

3158 Detailed modelling of HV/LV networks may demonstrate that voltage differences are not
3159 significant, due to the influence of the network on the shape of the contours; however such
3160 modelling may not be practicable. If any doubt exists, customers should not be offered an earth
3161 terminal, and no LV network earths shall be located in the area of high EPR. Cables passing
3162 through the area should be ducted or otherwise insulated to limit stress voltage to permissible
3163 limits. Typically a customer will use their own TT earth electrode; however if properties are in
3164 an area where EPR exceeds 1200 V, it is possible that they will experience L-E or N-E
3165 insulation failures in HV or EHV fault conditions; isolation transformers (or careful siting of
3166 HV:LV transformers and electrode systems) may be required; refer to Section 9.11 below, and
3167 to risk assessment case studies given in Section 11.

3168 For PME electrode locations, reference should be made to ENA EREC G12.

3169 **9.11 Supplies to/from High EPR (HPR) sites**

3170 Network supplies into HPR sites invariably need care if the network earth is to remain
3171 segregated from the HPR site earth. In remaining separate, this can introduce touch voltage
3172 risk within the site. It is normally necessary to use a careful combination of bonding and
3173 segregation to ensure that danger does not arise within the site, or on the wider network.
3174 Sheath breaks (insulated glands) or unearthed overhead line sections are often convenient
3175 mechanisms to segregate the earthing systems.

3176 Similar considerations are required for LV supplies derived from HPR sites if these are to
3177 'export' to a wider area. Typically the LV neutral will be earthed outside the contours of highest
3178 potential and will be kept separate from all HPR steelwork in accordance with normal best
3179 practice. It may be necessary to apply ducting or additional insulation to prevent insulation
3180 breakdown and resultant fault current diversion from the HPR site into the wider network.

3181 Refer to **EREC S34** for specific examples, and to Section 11 (Case Studies).

9.11.1 Special Arrangements

Where a standard substation earthing arrangement is not applicable, other options may include:

- combining HV & LV earths and managing touch and step potentials by installing an earth grid to enclose the installation supplied, i.e. effectively producing a large 'equipotential' safe zone, irrespective of EPR. (The design must take into account any metallic services such as Telecoms entering or leaving the installation, and is most useful in rural areas);
- using an isolation transformer with a separate earthing system where an LV supply has to be taken outside a HPR substation site with a bonded HV/LV earth system;
- use of isolation transformers to provide small capacity LV supplies to HPR ground mounted substations. E.g. LV supplies to tele-control equipment located within substations with segregated HV/LV earths (as described in 9.5.3). The (alternative) use of TT supplies (derived outside the High EPR zone) in such circumstance does not protect against insulation failure/flashover between the LV phase/neutral conductors and HV steelwork and could lead to the systems becoming inadvertently combined.
- For supplies to mobile phone base stations refer to ENA EREC G78.

See case study XXX

Commented [MD22]: Put name in references section.

3201 **10 Pole Mounted Substation and Equipment Earthing**

3202 This section describes earthing associated with HV Distribution Overhead Line Networks
3203 (excluding Tower lines).

3204 **10.1 General Comments & Assumptions**

3205 Extreme care must be taken when replacing pole mounted equipment with ground mounted
3206 equipment, since any existing earthing system is unlikely to be adequate to limit touch voltages
3207 to safe levels on the new installation.

3208 **10.2 Pole Mounted Transformers**

3209 Pole mounted transformers (PMTs) typically operate with a segregated HV and LV earthing
3210 system* (see section 9.6), and (since the metalwork is out of reach), a high EPR can be
3211 tolerated on the HV steelwork, provided that the LV electrode system is suitably separated
3212 from the HV system. Figure 4 below shows a typical arrangement where the main LV electrode
3213 is at the first pole (i.e. one span away) from the HV pole.

3214 The limiting factor for EPR is usually insulation withstand (stress voltage) on the LV cables,
3215 insulators and bushings at the pole-top; often a design value of 2 kV to 5 kV is assumed,
3216 depending on equipment specifications. A high EPR (with a small electrode system) is often
3217 inevitable on systems supplied by unearthed overhead lines as these do not enjoy the 'return
3218 path' offered by a metallic cable sheath/armour.


3219 The HV electrode must be sited and designed so that it will not present a danger in terms of
3220 hazardous step potentials (voltage gradient) around it. In this respect it is no different to that
3221 of ground mounted systems described above, except that PMTs are often in fields, close to
3222 livestock/animals, and with high ground return currents. Refer to Section 10.3.

3223

3224

* In some network areas, combined HV/LV systems were employed, so this cannot be assumed.

Figure 4 – Typical Pole Mounted transformer earthing arrangement



10.3 Electrode Configuration for Pole Mounted Equipment

The following earth electrode designs assume that the overhead network does not have a return earth conductor. With this type of system the earth potential rise (EPR) of the local earth electrode typically will exceed tolerable touch, step and transfer potentials under earth fault conditions.

Due to the possible hazardous touch potentials, earth conductors above ground shall be suitably insulated and provided with mechanical protection for a minimum height of 3 m or above the height of the anti-climbing device, whichever is greater. In addition the main earth conductor shall be suitably insulated for a minimum of 500 mm below ground level. Where the separation of electrodes is required guidance will be given in the relevant section.

It is not always reasonably practicable to ensure in all situations that step potentials directly above an installed earth electrode system remain below permissible limits under earth fault conditions*. It is generally considered that the probability of an earth fault occurring whilst an individual happens, by chance, to be walking across the earth electrode at the same time, is extremely small. Therefore, in most circumstances no special precautions are required. However, at sensitive locations that are often frequented† by people, particularly children, and concentrations of livestock in stables or pens for example, precautions may be justified to eliminate or minimise the risk. This can usually be achieved by careful site selection or at the time of installation by installing the earth electrode in a direction away from the area of concern,

* This is now less of an issue as step voltage limits have been considerably relaxed compared with previous versions of this specification.

† Refer to BS EN 50341-1 clause 6.2.4.2 for definition

3247 burying the electrode as deep as practicable, and/or fencing the electrode off to prevent
3248 access.

3249 A similar situation also applies to personnel carrying out live operations such as HV drop-out
3250 fuse replacement, live-line tapping at earthed locations or ABSD switching using hook stick
3251 (hot-stick or insulated rods) techniques on earthed poles.

3252 **10.4 HV Earth Electrode Value**

3253 The HV electrode is (usually) the only return path for HV fault current (except relatively rare
3254 instances of cable fed PMTs, or cable terminations), and its resistance must generally be low
3255 enough to operate HV protection within design limits for the network (typically 1 to 1.5 seconds
3256 maximum); electrode resistance values between 10 Ohm and 40 Ohm are often quoted for
3257 design purposes, with lower values providing increased resilience to lightning strikes. (Lower
3258 resistance values will limit the voltage rise on HV steelwork, and can prevent 'back flashover'
3259 across LV bushings resulting from lightning surges, which would otherwise destroy the
3260 transformer winding).

3261 In general the lower the earth electrode resistance the more earth fault current will flow,
3262 resulting in more reliable operation of the circuit protection. Where surge arresters are used it
3263 is generally accepted that 10 Ohm is the preferred maximum value of earth electrode
3264 resistance for satisfactory operation of the arrester. This is in line with the preferred 10 Ohm
3265 value in BS EN 62305 for high frequency lightning earth electrodes.

3266 **10.5 Electrode Arrangement Selection Method**

3267 A common arrangement of rods used for earth electrodes associated with overhead line
3268 equipment is a run of parallel rods interconnected with a horizontal conductor.

3269 Resistance values may be calculated using formulae in **EREC S34**. The calculated values are
3270 considered to be conservative and are based on uniform soil resistivity.

3271 Calculated resistance values for the same rod and soil arrangements, using earthing design
3272 software are approximately 30% lower. Where the ground conditions are difficult, i.e. of high
3273 resistivity and/or rocky, the cost of obtaining the required earth electrode resistance value may
3274 warrant carrying out a site specific design.

3275

10.6 Earthed Operating Mechanisms Accessible From Ground Level

This section deals with pole mounted auto-reclosers (PMARs), sectionalisers, and air break switch disconnectors, that are all capable of being manually operated via an earthed metallic control box or switch mechanism. It is important to note that where a low voltage supply is required for control circuits, the supply should be derived from a dedicated transformer whose LV neutral is earthed directly to the installation's main HV earth conductor.

There are several methods of minimising the risk from possibly hazardous touch and step potentials at such installations. In selecting the most appropriate method due account should be taken of the nature of the site, the accessibility of the equipment to third parties and the EPR level under fault conditions.

(1) Use of wireless remote control for a unit mounted on the pole out of reach from ground level. With this method, an HV earth electrode system may be required where surge arresters are fitted or where the manufacturer of the equipment specifies. Where equipment is unearthed its mounting height shall comply with the relevant regulations.

(2) Place the control box out of reach from ground level, access being via an insulated ladder. Again, with this method an HV earth electrode system may be required where surge arresters are fitted or where the manufacturer of the equipment specifies. Where equipment is unearthed its mounting height shall comply with the relevant regulations.

Install an operator's earth mat and grading conductors to help provide an equipotential zone for the operator. Figure 5 and Figure 7 show an example of how this may be achieved. Whilst this minimises the hazards for the operator it requires that the installation be carried out with great diligence. It is also important that the future integrity of the earth electrode is ensured. Misplacement of the earth electrode conductors can result in the operator being exposed to hazardous touch and step potentials. Consideration needs to be given to the selection of the site prior to installation to ensure that the required earth electrode configuration can be installed correctly, and maintained adequately into the future. Use of suitable personal protective equipment for switching operations may also be considered as an additional risk control measure; dielectric (insulated) footwear rated at >7 kV is now commonly used to protect operators against step potentials when stepping on/off the platform.

(3) Where mechanical damage is likely, for example in farmland, protective measures need to be considered to ensure the integrity of the earth electrode and the earth mat. An example would be to install and fix the earth mat on or in a raft of concrete or fence off the area surrounding the earth mat.

The use of grading conductors to minimise step potentials in the immediate vicinity of the operator's earth mat may prove impractical in some circumstances, particularly where there is a danger of them being damaged by ploughing. Burying the grading conductors at a greater depth will significantly reduce their effectiveness. Keeping step potentials within tolerable limits can be extremely difficult and in some case impracticable. In such circumstances alternative mitigation should be considered.

Factors such as, soil structure, operating voltage, type of HV system earthing (solid or resistance) and system impedance all have an effect on the value of step and touch potentials created around the earth electrode, whereas protection clearance times will have a bearing in determining the tolerable touch and step potential limits. At some sites it may be prudent to restrict access to the control box, for example by use of insulating barriers or fences, so that it


3323 is not possible for third parties to touch the control box and where operators can only touch the
3324 control box when standing on the earth mat.

3325 It should be noted that burying the operator's earth mat will increase the touch potential
3326 between the control box and the surface of the ground above the earth mat; the greater the
3327 depth of the mat, the greater the potential difference between the soil surface above the mat
3328 and the control box. The hazard this presents can be managed by covering the mat with a
3329 high resistivity material which will increase the impedance path between the hands and feet.
3330 Burying the mat will also have the effect of reducing the step potentials for an operator stepping
3331 off the mat. However, the prime concern is to minimise the touch potentials as these are
3332 considered to be more hazardous than step potentials. Where the mat is buried the touch
3333 potential and the hazard it presents will be site specific, being dependent upon the actual EPR
3334 and the protection clearance times for the given site, therefore a site specific design is
3335 recommended. The surface mat shown in Figure 5 results in negligible touch potentials for the
3336 operator standing on the mat, irrespective of the EPR.

3337 In all cases it is an option to use control measures to mitigate risk if a company deems this is
3338 the most appropriate solution in the circumstances.

3339

3340



NOTE: This arrangement does not exclude the use of a portable earth mat.

Figure 5 — Earthing Arrangement for a PMAR with Ground Level Control Box.




Figure 6 — Alternative Earthing Arrangement for a PMAR with Ground Level Control Box.

10.7 Air Break Switch Disconnect (ABSD) with an isolated operating mechanism

There are several methods of controlling hazardous touch and step potentials, at pole mounted ABSDs.

Install an insulated rod operated ABSD at high level that does not require an earth electrode. Where equipment is unearthed its mounting height shall comply with the relevant regulations. This option removes the risk of the operator being exposed to the hazard of touch and step potentials that could occur under certain earth fault conditions when adopting method 2 below.

(1) Install an ABSD that is operated manually from ground level with a separate HV earth electrode and operator's earth mat. This approach relies on effective separation of the HV earth electrode that connects the HV steelwork to earth, and the operator's earth mat connected to the operating handle. This arrangement is typical of existing earthed ABSD equipment found on rural overhead line distribution networks.

Separation is achieved by placing the HV earth electrode a minimum of 5m away from the base of the operator's earth mat using insulated earth conductor from the electrode to the HV steel work, and by insulating the operating handle from the switch mechanism using an insulating insert in the operating rod. The top of the insert needs to be a minimum of 3m from ground level when in its lowest position. The operating handle needs to be connected to an earth mat positioned where the operator will stand to operate the handle. If the earth mat is installed such that it is visible the operator can verify its existence and its connection to the handle prior to operating the handle. The continuing effective segregation of the HV earth electrode and the operator's earth mat is the most important aspect of the way in which this arrangement seeks to control the touch and step potentials around the operator's earth mat position. To minimise the possibility of contact between the buried insulated earth conductor and the surrounding soil, should the earth conductor's insulation fail, the conductor could be installed in plastic ducting.

Where mechanical damage is possible, for example in farmland, protective measures may need to be considered to ensure the integrity of the earth electrode and the earth mat. An example would be to install and fix the earth mat on or in a raft of concrete or fence off the area surrounding the earth mat using non-conducting fencing.

Under earth fault conditions the HV earth electrode will rise in potential with respect to remote earth. A potential gradient will be produced around the electrode; the potentials being highest immediately above the electrode and reducing rapidly with distance. The earth mat will be located within the potential gradient surrounding the HV earth electrode, but due to the separation distance of 5m the potential at that point with respect to remote earth will be relatively small. The surface level earth mat for the operating handle and the handle itself will rise in potential but there will be effectively no potential difference between the mat and handle.

Under earth fault conditions, assuming the correct separation distance between the HV earth electrode and the operating handle earth mat, should the operator have one foot on the mat and one off the mat, touch and step potentials surrounding the earth mat should not exceed tolerable limits. However, there is a risk of hazardous touch and step potentials arising if the HV earth electrode short circuits to the operating handle earth mat. The risk of such a short circuit occurring is extremely small provided that the earth installation is correctly installed, inspected and maintained.

The actual size and shape of the earth mat shall be such as to ensure that the operator will be standing towards its centre whilst operating the handle. Notwithstanding this requirement the minimum size of earth mat should be 1 m by 1 m. Due consideration needs to be taken of the type of handle, whether it is a two handed or single handed operation and whether the operator may be left or right handed. A purpose made mat is recommended in preference to a mat

3395 formed on site out of bare conductor, as this eliminates problems of variation in shape and size
3396 that can occur with the latter. Where a buried earth mat is used, the maximum depth of the
3397 mat should be no greater than 300 mm.

3398 Under normal earth fault conditions the touch potential for both buried and surface
3399 mounted scenarios will be negligible. When deciding between the use of a buried
3400 earth mat and a surface mounted mat the following issues shall be considered:

- 3401 • A surface mounted mat will allow the operator to visually confirm both the
3402 position of the earth mat relative to the handle and also the integrity of the
3403 connection between the earth mat and the handle.
- 3404 • A surface mounted mat will minimise any touch potentials between the soil
3405 surface on the mat and the handle, both under normal earth fault conditions
3406 and under second fault conditions where the handle and the earth mat become
3407 energised although this scenario should be less likely because effective
3408 segregation can be visually confirmed before operation.
- 3409 • Conversely a surface mounted mat will maximise the step potential around the
3410 mat although this will only be an issue if the mat and handle become energised
3411 under a second fault scenario.
- 3412 • A buried earth mat will not allow the operator to visually confirm either its
3413 position relative to the handle, or the integrity of its physical connection to the
3414 handle before operation.
- 3415 • Burying the earth mat will increase the value of any touch potential between
3416 the handle and the soil above the earth mat, this potential will increase with
3417 depth.
- 3418 • To maintain the same effective soil surface area with a buried earth mat for
3419 the operator to stand on and minimise any resulting touch potentials requires
3420 a significantly larger mat than for a surface mounted mat.
- 3421 • Where a second fault occurs that energises the operating handle and earth
3422 mat, with a buried earth mat the touch potential could exceed tolerable levels.
- 3423 • Conversely burying the mat will have the effect of reducing the step potentials
3424 under such conditions for an operator stepping off the mat.

3425 The use of suitably rated PPE in these situations would assist in minimising the risk of exposure
3426 to possibly hazardous potentials.




Figure 7 - Recommended Earthing Arrangement for an ABSD.

10.8 Surge Arresters

The preferred value for the surge arrester earth electrode resistance is 10 Ohm or less. Ideally this electrode system should be installed as close to the base of the pole as possible. However, for some locations where it may be necessary for an operator to carry out switching operations on the HV networks at that pole this may create unacceptable step potential hazards. In such cases the HV earth electrode should be installed away from the pole at a location where the step potential is calculated to be safe (typically 5m) for the operator to stand when carrying out any switching operations, see section 15.8. It is preferable to have a small number of deep earth rods rather than many shallow rods or plain horizontal conductor. The earth conductor connecting the base of the surge arresters to the earth electrode system should be as straight as possible, having as few bends in as is practicable. Refer to Section 6.14 for further details.

Where other HV equipment is situated on the same pole and requires an earth electrode, only one HV earth electrode needs to be installed*. The preference is to install an earth conductor directly from the surge arresters to the buried HV earth electrode, and then connect the earths of the other items of HV equipment to it on the pole. At sites where switching may take place the earth lead should be insulated to the first earth rod which should be a minimum of 5m from the operating mat for an ABSD or 5m from the operating position for equipment that requires the use of hot-sticks or insulated rods. Additional protection may be achieved by placing the earth lead in ducting to that point.

* Note: This practice differs for that in substations as described in Section 6.14, where separate power frequency and high frequency earths are required.

10.9 Cable Terminations

Typically, cable terminations on poles are associated with surge arresters or other HV equipment, in which case the cable sheath or screen is connected directly to the surge arrester

or HV equipment main earth conductor. In the absence of surge arresters or other earthed HV equipment the cable will require the installation of an earth electrode.

10.10 Operations at Earthed Equipment Locations

At earthed installations fed via overhead line systems, it is essential to have robust operational procedures to minimise the risk from the possible hazards associated with the high rise of earth potential under earth fault conditions. It should be noted that the risk increases during live fault switching operations. It is beyond the scope of this document to detail such procedures but consideration should be given to the following points.

Earth systems are usually designed to minimise hazards under main protection operation. They are not designed, unless specifically required, to minimise hazards under secondary or backup protection conditions. This is an important point to note when developing fault switching operational procedures. Temporarily disabling parts of the protection system, reconfiguring the network, or raising protection settings to aid in fault location during fault switching can give rise to touch, step and transfer potentials of a duration that the associated earth systems have not been designed to take account of.

Precautions shall be taken, by virtue of the equipment design and earthing arrangements to minimise any touch and step potential hazards. For example, where rod operated (insulated hot sticks) equipment is used, the simplest way of minimising hazards from touch and step potentials is by, where practicable, placing the earthing electrode, not serving as grading conductors, away from the position where the operator will be standing. Where several people are present during operations, any person not actively carrying out operations should stand well clear of the installed earth electrode.

10.11 Installation

The following points should be considered when installing an earth electrode system for overhead line equipment:

- (1) Materials and jointing methods shall comply with the requirements of BS 7430.
- (2) Installation teams should have a basic understanding of the functions of an earth system, and should carry out installations to a detailed specification.
- (3) Typically, installing a horizontal earth electrode system at a greater depth than 500mm will not have any significant effect on reducing the earth electrode's resistance value. However, it is recommended that the electrode is buried as deep as is practically possible to minimise surface potentials and the possibility of mechanical damage. Where ploughing is a concern the electrode should be buried at a minimum depth of 1m.
- (4) Ensure maximum separation is achieved on the pole between HV earth conductors and ABSD handle earth mat conductors.
- (5) It is recommended that a test point is made available for future connection of an earth tester above ground so that the earth electrode resistance can be measured. This test point should be installed and constructed so as to prevent unauthorised access, and on ABSD's prevent possible flashover to the operator's handle and associated earth mat.
- (6) Welded, brazed or compression connections are preferable to bolted connections for underground joints.
- (7) Corrosive materials and high resistivity materials such as sand should not be used as a backfill immediately around the electrode.
- (8) The earth resistance of the installed electrode should be measured and recorded.

- 3497 (9) Where a buried operator's earth mat has been installed, the mat should have two
3498 connections made to the operating handle.

3499 **10.12 Inspection & Maintenance of Earth Installations**

3500 **10.12.1 Items to Inspect**

3501 During routine line inspections it is recommended that the following items are visually
3502 inspected and their condition recorded, with any defects being rectified in a timely manner:

- 3503 (1) ABSD earth mat and connection to operating handle.
3504 (2) Separation of HV and operator's handle earth on an ABSD.
3505 (3) Separation of HV and LV earth conductors on the pole.
3506 (4) Check that the anti-climbing device does not compromise the separation between the
3507 HV earth conductor and the operating handle.
3508 (5) Insulation of HV and LV earth conductors.
3509 (6) Mechanical protection of HV and LV earth conductors.
3510 (7) Bonding of plant and equipment.
3511 (8) State of connections, including any test point.
3512 (9) Signs of possible mechanical damage to earth electrode and buried earth mats.

3513 **10.12.2 Items to Examine**

3514 Periodically examine a random sample of buried earth electrodes and buried ABSD handle
3515 earth mats, and rectify any defects found. The examination should check for the following:

- 3516 (1) position of earth mat and electrode locations relative to ABSD handle and operator's
3517 position;
3518 (2) insulating insert in the ABSD operating rod;
3519 (3) state of underground connections;
3520 (4) state of earth electrode components, particularly galvanised steel rods;
3521 (5) state of insulation on underground earth conductors where separation of electrodes is
3522 required.

3523 NOTE: When carrying out this work protective measures shall be taken to ensure the safety of personnel during
3524 fault conditions.

3525 The results of the examinations can then be used to assist in developing ongoing inspection
3526 and maintenance policy, and procedures.

3527 **10.12.3 Items to Test**

- 3528 (1) Periodically test the earth electrode resistance. For the relatively small earth systems
3529 typically associated with overhead line equipment, a small 3 terminal earth tester is
3530 adequate. The test should be carried out in accordance with the manufacturer's
3531 instructions.
3532 (2) Regularly test the continuity between operating handle and the operator's earth mat.

3533 (3) Regularly test the continuity of buried earth mats.

3534 (4) Periodically test a random sample of insulating inserts used in ABSD operating
3535 mechanisms.

3536 Important: When carrying out these measurements the equipment should be made dead or
3537 where this is not practicable a risk assessment should be carried out and suitable test
3538 procedures should be adopted which safeguard the operator from any rise of earth potential.
3539 Such procedures may for example include the use of insulating gloves and boots, mats and /
3540 or fully insulated test equipment.

3541

3542

3543

3544

3545 11 Case studies / examples


3546 11.1 Risk assessment – Third party metallic fence near substation

3547

3548 This case study concerns a 3rd party fence that has been erected close to (within 4 metres of)
3549 a primary substation. The EPR at the substation in this case is 3kV, and generic fault data
3550 suggests that EPR events may occur up to 2.1 times per year on average (due to a combination
3551 of local and remote faults).

3552 In this case, hand-to-hand touch voltage is not an issue between the substation fence and the
3553 third party fence (because the above-ground separation exceeds 2 metres). However a hand-
3554 to-feet touch voltage can exist at the third party fence during substation fault conditions, and
3555 this is assessed below.

3556 This case study is representative of various scenarios where a transfer voltage is introduced
3557 from a remote source; in this case the metallic fence will adopt a potential that may differ from
3558 the ground potential (particularly if the fence is on insulated supports and in contact with a
3559 remote 'earthy' structure). Similar principles can be applied to telecoms circuits, LV cables,
3560 etc. which encroach on an area of high potential rise.



3561

3562 **Figure 8: 3rd Party Fence close to substation**

3563 Figure 8 above shows the situation in outline. V_T represents the worst case touch voltage that
3564 may be assumed to be present; as shown it represents the difference between the ground
3565 potential at the point nearest to the substation, compared with a remote (zero volt) reference
3566 on the fence. In practice, the touch voltage will be less than this (described below), but a 'worst
3567 case' estimate might be sufficient in some circumstances.

3568 In this example, the substation measures 30 x 30 metres and experiences an EPR of 3kV
3569 under local and remote fault conditions. The slowest (normal) fault clearance time is 0.5
3570 seconds.

3571 Simplified calculations (rearranging EREC S34 formula P7) give the surface potential rise at a
3572 point 4m from the substation boundary. Alternatively (due to the close proximity to the
3573 substation and the non-circular contours at that point), computer modelling may be more
3574 accurate; this shows that the ground potential rise at the closest point of the fence is 1720
3575 volts.

3576 This value (1720 V) would be a worst case estimate for touch voltage. Using this value for 0.5
3577 seconds, and comparing to Table 1 shows that this touch voltage is above acceptable

3578 deterministic limits for soil, chippings, or concrete coverings (the touch voltage would be
3579 acceptable if the fence is surrounded by asphalt). Having carried out this first estimate, it is
3580 apparent that a quantified risk assessment (QRA) is appropriate to quantify the level of risk to
3581 members of public.

3582 A QRA can proceed on the basis of 'worst case' estimated data, provided these estimates are
3583 justifiable and proven not to underestimate the overall risk. It is preferable however, where
3584 possible, to collect further information to inform studies. This data collection exercise may
3585 involve one or more of: site visits, measurements, modelling, mapping/cable plans, collection
3586 of fault statistics, fault level analysis, EPR calculation/checks, interrogation of protection relay
3587 data or power quality monitors (historic fault rates and/or fault levels), aerial imagery / satellite
3588 imagery or other online sources. Video / other data sources may assist with an estimate of
3589 likely human exposure.

3590 In this case, the 3rd party fence is a metal palisade type with metal uprights that may be
3591 assumed to be buried up to 0.5m deep. The panels are 2.5m wide and supported clear of the
3592 ground. Local soil is 100 ohm·m. The fence is 50m long and effectively runs radially from the
3593 substation.

3594 The fence is on the edge of an industrial area with a footpath nearby, but not adjacent to the
3595 fence. Individuals contacting the fence can be assumed to be wearing normal footwear (4
3596 kOhm per shoe) whilst (in this example) standing on soil/grass (i.e. a shoe-to-soil contact
3597 resistance of 300 Ohms per foot), giving an 'accidental circuit resistance' of 2150 ohms in
3598 addition to the body and hand-to-feet contact impedances.

3599 **Because of the coupling between the fence and the soil along its length, the fence will not**
3600 **adopt a true 'zero' potential during EPR events at the substation but will instead adopt a**
3601 **'weighted average' value over its length. Computer modelling shows the touch potential along**
3602 **the fence, i.e. the difference in potential between the fence and the soil 1m from it, as shown in**

3603 Figure 9. It can be seen that 18m along the fence, the touch voltage falls to a 'null point' where
3604 the fence and soil potentials are equal. The maximum touch voltage appears (in this case) at
3605 the end of the fence closest to the substation; an individual standing 1m from the end of the
3606 fence could be subject to a touch voltage of 970 volts; this worst case should be used in the
3607 assessment, together with an appropriate probability for the exposure.

3608 Note: More accurate assessment could use a probability distribution function for the voltage along the fence; this is
3609 beyond the scope of this example.

3610




Figure 9: Touch voltage along fence

For 'shoes on soil' conditions, the maximum permissible touch voltage (0.5 seconds) is 578 volts. This 'deterministic limit' is based on the C2 curve from IEC 60479-1 and the body impedance model for 95% of the population, i.e. the same criteria used in the examples in BS EN 50522.

The touch potential (hand-to-feet) of 970V is therefore still above the C2 curve and fails the deterministic test. Having established this, 'order of magnitude' analysis can proceed with an assumed $P_{FB} = 1$; more detailed analysis shows the body current to be around 354mA, which is in the AC-4.2 region of IEC 60479-1 Figure 20, i.e. "Probability of ventricular fibrillation above 5% and below 50%". Interpolation of the value gives $P_{FB} = 43.4\%$, although due to uncertainties it is more appropriate to adopt the upper threshold for the region.

Thus: $P_{FB} = 0.5$.

Note: Fibrillation current calculations use the same assumptions as outlined in BS EN 50522 Annex NA, i.e. using Table 1 from IEC 60479-1 for values of human body impedance not exceeded by 95% of population, and additional 2150 ohms for the accidental circuit (shoes + soil contact patch). The body impedance is a function of voltage across the body, therefore it becomes necessary to go through some form of iterative loop to estimate the voltage drop across the body (and thus body impedance) in order to converge on the solution for final body current. An impedance factor of 0.75 is used to convert hand-to-hand impedances to hand-to-feet values. It is not normally necessary to consider 'wet' values except in permanently wet locations.

The statistical fault rate (estimated significant EPR events per year) based on historical fault data is 2.1 faults/year.

$$f_n = 2.1$$

3637 The probability of exposure (P_E) relates to the time that an individual may be exposed to risk.
3638 The most significant, and obvious risk relates to contact with the fence. The fence is in a
3639 relatively remote location on an industrial area, with little footfall and only occasional contact
3640 with the fence. An initial estimate of 2 minutes contact with the fence, per individual, per day
3641 is based on anecdotal observations from the landowner:

3642 The exposure is calculated as:

3643 $P_E = 2 \text{ (minutes)} / (24 * 60 \text{ minutes per day}) = 1.39 \times 10^{-3}$

3644

3645 The individual risk (IR) is calculated using the formula:

3646
$$IR = f_n * P_E * P_{FB}$$

3647 where

3648 f_n = number of significant EPR events, on average per year

3649 P_{FB} = probability of heart fibrillation

3650 P_E = probability of exposure

3651 HSE guidance [R2P2] defines an individual risk of 1 in 1,000,000 (pppy) as broadly acceptable,
3652 for which no further work is warranted. A risk between 1 in 10,000, and 1 in 1,000,000 is
3653 'tolerable' for members of the public. A risk greater than 1 in 10,000 (or 1 in 1000 for workers)
3654 is deemed 'unacceptable', and must be addressed regardless of cost.

3655 The overall individual risk in this case, using the assumptions above is **1.46×10^{-3}** , i.e.
3656 1.46/1000 fatalities pppy. This risk level is UNACCEPTABLE and must be addressed.

3657 The assessment at this stage is based on very conservative estimates. Having established
3658 that the risk may be significant, it is becomes necessary to either carry out mitigation work, or
3659 reassess the risk with more accurate data.

3660 Given that mitigation work will in most cases be relatively expensive, this initial assessment
3661 provides justification for further analysis.

3662 In this example, the network operator opted to carry out a more detailed site survey and
3663 investigation. The following findings were noted:

- 3664 • Whilst earth faults were observed on average 2 to 8 times a year (based on historical
3665 data), it was found that significant EPR events (i.e. those producing EPR over the
3666 deterministic threshold) at this substation occurred, on average 0.9 times per year*.
- 3667 • Over a 1 month survey period (video), individual contact with any area of the fence was
3668 noted, on average twice per week, by the same individual, for a maximum of 10 seconds
3669 per occasion. Of these contacts, 1/3rd involved the portion of fence where touch potential
3670 exceeds the deterministic limit of 578 V. [It has been assumed that all contacts with this
3671 portion will give a 970V touch voltage, to simplify analysis. The alternative is to assess
3672 the exposure and touch voltage for each 1m of the fence separately].

3673 * Note: In addition, the Network Operator also established that the full EPR for this site was 2400V rather than 3kV
3674 as assumed; however the decision was taken to work with an assumed upper limit of 3kV to allow for fault level
3675 growth. It was also found that only a small percentage of faults gave EPRs approaching 3kV, but the data was not
3676 statistically significant. For this reason, the count of EPR events greater than deterministic limits is used in the
3677 analysis below.

3678 Finally, some parts of the fence were found to be surrounded by concrete rather than soil.
3679 Calculation of P_{FB} for these areas shows a reduced risk of fibrillation (21% for 970 V), which is
3680 still in region AC-4.2. There is no difference if the upper bound (50%) is used and this fact is
3681 ignored as of no consequence.

3682

3683 Thus:

Defect	f_n	P_{FB}	P_E	Risk	Risk Band
Close proximity to substation with High EPR	0.9	0.5	1.099×10^{-5}	4.95×10^{-6} per person per year	Tolerable; requires ALARP assessment

Commented [RW23]: Italicised formulae

3684

3685 The risk is not 'broadly acceptable', in that it exceeds 1 in 1,000,000 per person per year. It is
3686 'tolerable' for members of the public. An assessment is required to justify expenditure to reduce
3687 or mitigate this risk.

3688 The ALARP principle must be applied (as low as reasonably practicable), which means that
3689 the justifiable cost of mitigation must be calculated based on current HSE guidance [R2P2] for
3690 the 'value of preventing a fatality', or VPF. This figure currently stands at £1,000,000 per life
3691 saved. The justifiable spend is calculated according to the loss of life that could occur during
3692 the lifetime of the installation, which for a substation may be taken as 100 years:

3693 Expected lifetime of installation: 100 years (assumed)

3694 Fatalities in 100 years: $4.95 \times 10^{-6} \times 100 = 0.000495$

3695 Number of individuals exposed to same risk: 1 (this value is informed by observations / data)

3696 Justifiable spend (per individual exposed) = $\text{£}1,000,000 \times 0.000495 \times 1 = \text{£}495$

3697 Therefore if the cost of reducing risk to broadly acceptable levels is less than this, mitigation
3698 of the hazard should be carried out. If the risk cannot be significantly reduced for this amount,
3699 the network operator may be able to justify the decision to do nothing.

3700 Risk reduction measures could include hazard warning signs (which will have some reduction
3701 in P_E), insulated paint (reduction in body current and P_{FB}), modifications to the fence / addition
3702 of a grading electrode, use of asphalt ground coverings and so on. However, due to ownership
3703 / access issues, such measures may not be possible, in which case alterations to the
3704 substation earthing system / voltage contours, EPR / fault levels, protection clearance times or
3705 fault rates should be considered.

3706 Modifications to customer property (if permissible) must also consider the likelihood that they
3707 may become altered or compromised as they are beyond the control of the network operator.

3708 Before calculating the justifiable spend, any 'worst case' assumptions should be revisited.

3709 If there is robust data to justify it, a further reduction factor can be applied by looking at the
3710 relationship between exposure and fault. If for example, fence contact occurs only on dry sunny
3711 days, it may be that the fault rate is lower on those days. A 'correlation factor' may be applied
3712 to account for this. In the example above, if the fault rate on dry days is $1/10^{\text{th}}$ that for the rest

of the year, a factor of 0.1 may be applied to $P_E * P_{FB}$, giving an overall risk (in this example) that becomes broadly acceptable.

This case study considers only one aspect of overall risk, i.e. hand-to-feet touch voltage on a relatively small section of a 50m fence. All similar scenarios should be considered (e.g. hand-to-hand contact if appropriate, or transfer potential to/from other sources. Also barefoot / step voltage and/or horse-riding accidents if near a riding school) and an overall risk calculated by summing the individual risks from each scenario. In this case, there is no additional foreseeable likelihood of fibrillation or falls / injuries close to the substation or third party fence but this could change and should be reviewed periodically as part of substation inspections.

This study considers only fibrillation risk. Injuries from minor shocks (e.g. falls etc.) have not been considered. A tailored approach may be required for different circumstances or for vulnerable individuals, e.g. nurseries / playgrounds (especially those with pools or wet areas), nursing homes, riding schools, hospitals, etc.

[11] HSE, Reducing Risk Protecting People, 2001

11.2 LV Supply into High EPR (HPR) site

This case study considers the provision of an LV supply into a transmission substation with an EPR which cannot safely be carried outside the substation boundary (i.e. the EPR exceeds 2 x safe step and touch voltage thresholds).

The following parameters apply:

EPR	3 kV
Protection clearance time	0.2 seconds


The substation is in a suburban location with a local underground LV network and mixed overhead / underground 11kV cable system. The LV network supplies nearby properties and remains outside the 'HOT' zone (650V) which is calculated to extend 150m from the site.

A 100A (3 phase) LV supply has been requested by the substation operator, this is to serve as a backup to local site supply transformers.

The EPR exceeds that which can safely be imposed on the LV network under fault conditions. Therefore, taking an ordinary LV supply into the site from the nearby network is not an option. (The LV neutral/earth would invariably become combined with the substation earthing).

The arrangements which may be considered by the DNO include those listed below. The merits/disadvantages of each approach are discussed:

Arrangements	Merits / Disadvantages
11kV cable taken to local transformer / RMU located on transmission site	The 11kV system can be assumed to be remotely earthed and may therefore adopt a close-to-zero voltage rise under transmission EPR events. If the cable is taken onto the site, its sheath insulation

Arrangements	Merits / Disadvantages
	<p>could puncture and a high EPR could be exported to the 11kV system.</p> <p>To avoid this, the cable must be ducted within the highest voltage contours (dependent on its sheath withstand voltage). Extending ducting to the 2kV contour is a relatively common practice to avoid this.</p> <p>Any such cable connection into a 'HOT' site requires extreme care with the earthing of the RMU/Transformer or unit substation, as the earthing systems for the 11kV cable must not be combined with site earths. It is often most practical to earth the transformer HV and LV earths to the site earth, but to introduce an insulated gland (sheath break) in the 11kV cable(s) where they enter the plant. This can cause problems a) touch voltages between cable sheath and local steelwork, b) no metallic return for 11kV faults beyond the break, requiring the substation earth to be able to limit 11kV EPR and of sufficiently low resistance to operate 11kV protection, and c) operational issues if RMU earth is applied, since the 11kV cable cores will become connected to the local site earth. This could create a hazard for staff working on the cable or elsewhere on the 11kV network unless specific operational practices are adopted.</p>
<p>11kV overhead line supply to site, with pole mounted or ground mounted transformer</p> 	<p>An 11kV supply to site, if via 3-wire (unearthed) overhead construction is a simple and effective solution to the issues described above. The OHL can effectively be carried direct into the site, where it can supply a ground mounted transformer or pole mounted transformer. For both arrangements, the transformer HV and LV earths can be combined and connected to the site earth. A 3kV EPR on the site earth is unlikely to initiate flashover between the 11kV phases and steelwork, or between any short 11kV cable sheath-to-cores, although this possibility should be considered in extreme EPR situations. (Similar insulation breakdown could occur internal to the transformer if the casing is elevated above phase voltages). Care should be taken with operational earth positions and procedures.</p> <p>The disadvantage of this method is that the supply may be more vulnerable than underground supplies and consequently might be unacceptable where a resilient supply is necessary.</p>

Arrangements	Merits / Disadvantages
LV supply from network	The DNO considered making an LV supply available direct from the network, but withholding the earth terminal. (e.g. TT arrangement). It should be borne in mind that the LV neutral / earth will remain tied close-to-zero volts under transmission EPR events, and therefore the possibility of insulation breakdown / flashover to the LV system is very real. Whilst it may be possible to duct the LV cable, there will be little or no control of the LV circuit routing arrangements etc, (e.g. some may pass close to, or in contact with site steelwork) and for this reason the unisolated LV supply should not be used when EPR can exceed e.g. 440V, (or nominal withstand voltage of LV cable or equipment insulation). Isolation transformers are an option, though care is required with the siting and protection of the isolation unit itself.
Dedicated off-site transformer and LV supply into site [diagrams to go here]	Offers little or no benefit, and introduces the risk of exporting transmission EPR to the transformer. The LV arrangements could be PNB, i.e. the neutral could be earthed at the transmission site (only), whilst the HV could be earthed to the local network. The LV neutral to HV steelwork insulation withstand voltage must be sufficient to withstand the full EPR as a stress-voltage, and the LV cable must be ducted outside the transmission substation.

3748

3749 In this case, the pole-mounted transformer and overhead 11kV line solution has been adopted.


3750 This is the minimum cost solution and (because it is a 'back up' supply) the reliability is

3751 acceptable to the transmission network operator. For operational reasons an ABSD is best

3752 located outside the site boundary and will serve as a point of isolation and earthing point for


3753 the 11kV network beyond that point.

3754




3755

3756 **Figure 10 – Overhead supply into High EPR site**



3757

3758



3759
3760
3761
3762
3763
3764
3765
3766
3767
3768
3769
3770
3771
3772
3773
3774
3775
3776
3777
3778
3779
3780
3781
3782
3783
3784

3785

3786

3787

3788

3789 This page deliberately left blank.

3790

3791